


EDI MODEL 2018EClip-NC CONFLICT MONITOR
PROGRAMMING DETAIL



(remove jumpers and set switches as shown)



REMOVE JUMPERS AS SHOWN

NOTES:

- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- Ensure that Red Enable is active at all times during normal operation.
- Integrate monitor with Ethernet network in cabinet.



NOTES

- To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the Signal Plans.
- Enable Simultaneous Gap-Out for all phases.
- Program phases 2 and 6 for volume density operation.
- Program controller to start up in phase 2 Green and 6 Green.
- The cabinet and controller are part of the Fayetteville Signal System.

EQUIPMENT INFORMATION

CONTROLLER.....2070E
 CABINET.....332 W/AUX
 SOFTWARE.....ECONOLITE ASC/3-2070
 CABINET MOUNT.....BASE
 OUTPUT FILE POSITIONS...18 WITH AUX. OUTPUT FILE
 LOAD SWITCHES USED.....S2,**S3,S4,S5,**S6,S7,
 S8,AUX S1
 PHASES USED.....2,3,4,5,6
 OVERLAP "A".....*
 OVERLAP "B".....NOT USED
 OVERLAP "C".....NOT USED
 OVERLAP "D".....NOT USED
 * See overlap programming detail on sheet 2
 ** Used for pilot lamps 1 & 2.

SIGNAL HEAD HOOK-UP CHART


LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6				
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18				
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OLA	OLB	SPARE	OLC	OLD	SPARE				
SIGNAL HEAD NO.	NU	21,22	NU	31	32	41	42	63	NU	42	51,52	62,63	NU	NU	NU	61*	NU	NU	NU	NU	NU	
RED		128		116	116	101	101					134										
YELLOW		129		117	117	102	102					135										
GREEN		130		118	118	103	103					136										
RED ARROW																						A121
YELLOW ARROW								102		132	132											A122
FLASHING YELLOW ARROW																						A123
GREEN ARROW																						
PED YELLOW			*							*												

NU = Not Used

* Denotes install load resistor. See load resistor installation detail this sheet.
 * See pictorial of head wiring in detail this sheet.

INPUT FILE POSITION LAYOUT

(front view)



EX.: 1A, 2A, ETC. = LOOP NO.'S


FS = FLASH SENSE
 ST = STOP TIME
 PRE-1 = PREEMPTOR 1 (EV)
 PRE-2 = PREEMPTOR 2 (EV)

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	DETECTOR NO.	NEMA PHASE	CALL	EXTEND TIME	DELAY TIME	DETECTOR TYPE
2A	TB2-5,6	I2U	39	2	2	YES			N
2B	TB2-7,8	I2L	43	12	2	YES			N
3A	TB4-5,6	I5U	58	3	3	YES		10	S
4A	TB4-9,10	I6U	41	4	4	YES		3	S
5A	TB3-1,2	J1U	55	5	5	YES		3	S
5B	TB3-5,6	J2U	40	6	5	YES			S
5C	TB3-7,8	J2L	44	16	5	YES		15	S
6A,6B	TB3-9,10	J3U	64	36	6	YES			N
6C	TB3-11,12	J3L	77	46	6	YES		3	G
*S6A	TB7-9,10	J9U	59	15	SYS	NO			N
*S6B	TB7-11,12	J9L	61	17	SYS	NO			N


* System detector only. Remove any assigned vehicle phase.

INPUT FILE POSITION LEGEND: J2L



FYA SIGNAL WIRING DETAIL


(wire signal head as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0383
 DESIGNED: June 2016
 SEALED: 9-28-16
 REVISED: N/A

LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown below)



Electrical Detail Sheet 1 of 4

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

Electrical and Programming Details for: SR 1141 (Cumberland Road) at SR 2920 (Upchurch Drive)/ SR 1149 (Boone Trail)

Division 6 Cumberland County Fayetteville

PLAN DATE: August 2016 REVIEWED BY: BAS

PREPARED BY: James Peterson REVIEWED BY:

REVISIONS: INIT. DATE

750 N. Greenfield Pkwy, Garner, NC 27529

Seal of Keith M. Mims, Professional Engineer, No. 036880, State of North Carolina.

Signed: Keith M. Mims, 10/21/2016

SIG. INVENTORY NO. 06-0383

24-007-2016 10:37 S:\IT\SS\115 Signal\work\hgr\oups\g_MarkPeterson\060383_smc.e_20161019.dgn T:peterson