

PROGRAMMING TO OMIT PHASES 2 AND 6 PEDESTRIAN OPERATION AT "START-UP"

INPUT ASSIGNMENT PROGRAMMING DETAIL

(program controller as shown below)

1. FROM MAIN MENU PRESS '5' (INPUTS).
2. WITH CURSOR IN "INPUT ASSIGNMENT #" FIELD, USE "-" KEY TO FIND THE INPUT ASSIGNMENT NUMBER 64, AS SHOWN BELOW.
3. PROGRAM CONTROLLER AS SHOWN:

STEP 1

```

PAGE:1 C1 PIN: 0 NOT ENABLED
INPUT ASSIGNMENT #.....64
DEBOUNCE TIME (0-25.5 SEC).....0.5
DELAY TIME (0-25.5 SEC).....0.0
HOLD-OVER TIME (0-25.5 SEC).....0.0
ASSIGNMENT SELECTION:
NOT ENABLED.....Y
VEHICLE DETECTOR (1-64).....
PEDESTRIAN DETECTOR (1-16).....
ALTERNATE PED DETECTOR (1-16).....
PREEMPT (1-10).....
INVERTED PREEMPT (1-10).....
STOP TIME (Y/N).....
FLASH SENSE (Y/N).....
DOOR OPEN (Y/N).....
MANUAL CONTROL ENABLE (Y/N).....
MANUAL CONTROL ADVANCE (Y/N).....
SPECIAL FUNCTION ALARM (1-8).....
TOD HOUR SYNCHRONIZATION (0-23).....
FORCE OFF RING (1-4).....
HOLD PHASES (1-16).....
PLAN (65=FLSH,66=FREE)... OFFSET#..
CHANGE PHASE SEQUENCE PAGE (1-12)...
CHANGE PHASE TIMING PAGE (1-4).....
CHANGE PHASE CONTROL PAGE (1-4).....
CHANGE OVERLAP CONTROL PAGE (1-4)...
CHANGE INPUT PAGE (1-4).....
CHANGE OUTPUT PAGE (1-4).....
OVERRIDE PHASE CONTROL FUNCTION (Y).Y
    
```

SCROLL
DOWN TO
VIEW ALL
DATA
↓

EXISTING DEFAULT PROGRAMMING (IGNORE FOR NOW)

STEP 2

AFTER SELECTION IS MADE, THE PHASE CONTROL FUNCTIONS TABLE APPEARS. SCROLL DOWN ON THIS TABLE AND FIND "OMIT PEDESTRIAN", THEN SELECT PHASES 2 AND 6 FOR "OMIT PEDESTRIAN".

AFTER SELECTION IS MADE PRESS "ESC". SCREEN NOW APPEARS AS SHOWN TO THE RIGHT.

SELECT "Y" FOR
"OVERRIDE PHASE CONTROL FUNCTION"

STEP 3

```



PAGE:1 C1 PIN: 0 OVERRIDE PHASE CONTROL
INPUT ASSIGNMENT #.....64
DEBOUNCE TIME (0-25.5 SEC).....0.5
DELAY TIME (0-25.5 SEC).....0.0
HOLD-OVER TIME (0-25.5 SEC).....0.0
ASSIGNMENT SELECTION:
NOT ENABLED.....
VEHICLE DETECTOR (1-64).....
PEDESTRIAN DETECTOR (1-16).....
ALTERNATE PED DETECTOR (1-16).....
PREEMPT (1-10).....
INVERTED PREEMPT (1-10).....
STOP TIME (Y/N).....
FLASH SENSE (Y/N).....
DOOR OPEN (Y/N).....
MANUAL CONTROL ENABLE (Y/N).....
MANUAL CONTROL ADVANCE (Y/N).....
SPECIAL FUNCTION ALARM (1-8).....
TOD HOUR SYNCHRONIZATION (0-23).....
FORCE OFF RING (1-4).....
HOLD PHASES (1-16).....
PLAN (65=FLSH,66=FREE)... OFFSET#..
CHANGE PHASE SEQUENCE PAGE (1-12)...
CHANGE PHASE TIMING PAGE (1-4).....
CHANGE PHASE CONTROL PAGE (1-4).....
CHANGE OVERLAP CONTROL PAGE (1-4)...
CHANGE INPUT PAGE (1-4).....
CHANGE OUTPUT PAGE (1-4).....
OVERRIDE PHASE CONTROL FUNCTION (Y).Y
    
```

AFTER INPUT PROGRAMMING IS ACCOMPLISHED PROCEED TO LOGIC PROCESSOR PROGRAMMING SHEET 3.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 13-0271
DESIGNED: April 2016
SEALED: 12/12/2016
REVISED: N/A

Electrical Detail - Sheet 2 of 3

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

Prepared In the Offices of:  750 N. Greenfield Pkwy, Garner, NC 27529	Patton Avenue / North Pack Square at US 25 (Broadway/Biltmore Ave.)	SEAL NORTH CAROLINA PROFESSIONAL ENGINEER SEAL 030530 JACOBARY M. LITTLE
	Division 13 Buncombe County Asheville PLAN DATE: December 2016 REVIEWED BY: BAS PREPARED BY: B. SIMMONS REVIEWED BY:	REVISIONS INIT. DATE Docusigned by:  12/20/2016 DATE SIG. INVENTORY NO. 13-0271