

I-5000 CROSS SECTION INDEX

ALIGNMENT	STATION	TO	STATION	SHEET NO.
-Y1-	11 + 00	TO	45 + 00	X-1 THRU X-14
-Y2-	10 + 00	TO	26 + 00	X-15 THRU X-26
-Y3-	10 + 00	TO	23 + 50	X-27 THRU X-31
-RPA-	10 + 00	TO	18 + 50	X-32 THRU X-36
-RPD-	10 + 00	TO	35 + 50	X-37 THRU X-51
-TRAIL-	15 + 00	TO	17 + 00	X-52 THRU X-53
-TRAIL-	28 + 00	TO	48 + 00	X-54 THRU X-63
-L-	52 + 00	TO	68 + 00	X-64 THRU X-72
-LPB-	10 + 00	TO	17 + 00	X-73 THRU X-75