OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

PRESS '+' THREE TIMES

PAGE 1: VEHICLE OVERLAP 'D' SETTINGS PHASE: | 12345678910111213141516 VEH OVL PARENTS: | X X VEH OVL NOT VEH: | VEH OVL NOT PED: | VEH OVL GRN EXT: | STARTUP COLOR: _ RED _ YELLOW _ GREEN FLASH COLORS: _ RED _ YELLOW X GREEN NOTICE GREEN FLASH SELECT VEHICLE OVERLAP OPTIONS: (Y/N) FLASH YELLOW IN CONTROLLER FLASH?...Y GREEN EXTENSION (0-255 SEC)..... YELLOW CLEAR (O=PARENT,3-25.5 SEC)..0.0 RED CLEAR (0=PARENT, 0.1-25.5 SEC)...0.0 OUTPUT AS PHASE # (0=NONE, 1-16)....0

OVERLAP PROGRAMMING COMPLETE

OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS). PRESS NEXT TO ADVANCE TO PAGE 2.

PRESS '+' THREE TIMES

NOTICE PAGE 2

PAGE 2: VEHICLE OVERLAP 'D' SETTINGS PHASE: 12345678910111213141516 VEH OVL PARENTS: ; VEH OVL NOT VEH: | VEH OVL NOT PED: | VEH OVL GRN EXT: STARTUP COLOR: _ RED _ YELLOW _ GREEN FLASH COLORS: _ RED _ YELLOW _ GREEN SELECT VEHICLE OVERLAP OPTIONS: (Y/N) FLASH YELLOW IN CONTROLLER FLASH?...Y GREEN EXTENSION (0-255 SEC)..... YELLOW CLEAR (O=PARENT,3-25.5 SEC)..0.0 RED CLEAR (0=PARENT, 0.1-25.5 SEC)...0.0 OUTPUT AS PHASE # (0=NONE, 1-16)....0

OVERLAP PROGRAMMING COMPLETE

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 10-2190 DESIGNED: June 2015 SEALED: August 30, 2016 REVISED:

ELECTRICAL DETAIL SHEET 2 OF 4

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

DETAILS FOR: Prepared for the Offices of:

Division 10

SR 1518 (Faith Church Road) Westbound U-turn Union County


Indian Trail REVIEWED BY: B Humfleet PLAN DATE: June 2015 PREPARED BY: LM Moon REVIEWED BY: INIT. DATE

US 74 (Andrew Jackson Hwy) EB

LOGICAL I/O PROCESSOR PROGRAMMING DETAIL TO PRODUCE SPECIAL FYA-PPLT SIGNAL SEQUENCE

(program controller as shown below)

- 1. FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1, 2 AND 3.
- 2. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).



LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

OUTPUT 39 = Overlap D Red OUTPUT 40 = Overlap D Yellow OUTPUT 41 = Overlap D Green

PLANS PREPARED BY:

DRMP, INC. 5950 FAIRVIEW ROAD, SUITE 320 CHARLOTTE, NC 28210 NC LICENSE NO. C-2213 • (704) 332-2289

750 N.Greenfield Pkwy,Garner,NC 27529

Lisa M Moon 12/12/2016 SIG. INVENTORY NO. 10-2190