

STATE OF NORTH CAROLINA  
DIVISION OF HIGHWAYS

Quantities are approximate only. The Resident Engineer will re-cross-section the work accurately when the project is staked out. These cross-section notes will be used in computing the final quantities for which the contractor will be paid.

NOTE: EMBANKMENT COLUMN DOES NOT INCLUDE BACKFILL FOR UNDERCUT

### CROSS-SECTION SUMMARY

Station	Uncl. Exc.	Embt	Station	Uncl. Exc.	Embt	Station	Uncl. Exc.	Embt	Station	Uncl. Exc.	Embt	Station	Uncl. Exc.	Embt	Station	Uncl. Exc.	Embt
L	(cu. yd.)	(cu. yd.)		(cu. yd.)	(cu. yd.)		(cu. yd.)	(cu. yd.)		(cu. yd.)	(cu. yd.)		(cu. yd.)	(cu. yd.)		(cu. yd.)	(cu. yd.)
10+10.00	0	0															
10+50.00	1	1															
11+00.00	1	2															
11+50.00	1	5															
12+00.00	0	10															
12+50.00	0	29															
13+00.00	0	57															
13+50.00	0	82															
14+00.00	0	105															
14+50.00	0	113															
15+00.00	0	95															
15+26.24	4	24															
SKIP STATION RANGE 15+26.25 TO 16+93.75																	
16+93.76	0	0															
17+00.00	5	1															
17+50.00	21	17															
18+00.00	0	23															
18+50.00	0	22															
18+75.00	1	17															
19+00.00	3	16															
19+06.68	1	3															
19+50.00	5	10															
20+00.00	1	5															
20+40.00	1	3															

8/17/99  
29-JUN-2017 14:37  
J:\B-4770\Roadway\XSC\B4770-RDY\_XPL-1A.dgn