

BR-0002

CROSS SECTION INDEX

LOCATION

SEET NO.

-L-	X-2 THRU X-20
-Y-	X-21 THRU X-29
-Y1-	X-30 THRU X-31
-DR1-	X-32 THRU X-33