
OVERLAP PROGRAMMING DETAIL

1. From Main Menu select 4 - UNIT DATA

2. From UNIT DATA Submenu select 3 - OVERLAP DATA


Use Up/Dn/Left/Right keys to position cursor on the desired Overlap. Use the NEXT key to select the overlap type. Press the ENT key and then program as per the Overlap screen(s) shown.






OVERLAP A

Use Up/Dn/Left/Right keys to position cursor on Overlap 'A', use the NEXT key to select 'FYA', then press ENT



OVERLAP C

Use Up/Dn/Left/Right keys to position cursor on Overlap 'C', use the NEXT key to select 'FYA', then press ENT



END OVERLAP PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 05-1176T1 DESIGNED: July 2019 SEALED: 8/28/2019 REVISED: N/A

