ECONOLITE ASC/3-2070 BACKUP PROTECTION ENABLE PROGRAMMING

(program controller as shown)

- 1. From Main Menu select 1. CONFIGURATION
- 2. From CONFIGURATION Submenu select 1. CONTROLLER SEQ
- 3. From CONTROLLER SEQUENCE Submenu select 3. BACKUP PREVENT PHASES

Follow programming as shown below. On the 'ENABLE BACKUP PREVENT' screen move cursor to the appropriate field and press 'YES/NO' on the controller keypad to toggle field value between 'X', 'B', 'C' and 'OFF'.

END PROGRAMMING

NOTE

1. 'B' without a 'C' programmed for the 'TIMING' (row) phase inhibits the controller from servicing the 'BACKUP' (column) phase when the 'TIMING' (row) phase is active, or next, until the controller goes through Red Revert and Red Clear. Make sure the proper Red Revert and Red Clear times shown on the Signal Design plan are programmed in the controller phase timing.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: DAVI-1T3
DESIGNED: July 2023
SEALED: 9/19/2023
REVISED: N/A

Electrical Detail - Temporary Design 3 Sheet 2 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared For:

The Town of Davidson
College Town, Lake Town, Your Town,

Griffith Street at Sloan Street/Beaty Street

Sloan Street/Beaty Street

Division 10 Mecklenburg Davidso

PLAN DATE: July 2023 REVIEWED BY: KP Baumann

PREPARED BY: SP Pennington REVIEWED BY:

REVISIONS INIT. DATE

PLAMS PREPARED IN THE OFFICE OF:

Kimley» Horn

NC License #F-0102

421 Fayetteville Street, Suite 600

Raleigh, 677-2000