OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

Overlap	1	2	3	4
Туре	FYA 4 - Section	Off	FYA 4 - Section	Off
Included Phases	2	·	6	
Modifier Phases	1		5	
Modifier Overlaps	-	-	-	-
Trail Green	0	0	0	0
Trail Yellow	0.0	0.0	0.0	0.0
Trail Red	0.0	0.0	0.0	0.0

MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

Overlap Plan 2

Overlap	1	2	3	4	
Туре	FYA 4 - Section	Off	FYA 4 - Section	Off	
Included Phases	-	÷	-	÷	NOTICE INCLUDED PHASE
Modifier Phases	1		5		
Modifier Overlaps	-	-	-	-	
Trail Green	0	0	0	0	
Trail Yellow	0.0	0.0	0.0	0.0	
Trail Red	0.0	0.0	0.0	0.0	

Note: If Loops 1A and 5A are detected using the Vehicle Detectors shown in the charts below, use the steps shown below. If different Vehicle Detectors are used, substitute the appropriate Vehicle Detector numbers for the ones shown below.

VEHICLE DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

1A

Detector	Call Phase	Delay
1	1	0.0
29	0	0.0

Detector	Call Phase	Delay
15	5	0.0
31	0	0.0

U-5757 <u>Sig.9.2</u>

PROJECT REFERENCE NO. SHEET NO.

MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface

Home >Controller >Coordination >Patterns

Pattern Parameters

Pattern	Veh Det Plan	Overlap Plan
*	2	2

*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

PHASING	OVERLAP PLAN	VEH DET PLAN
ACTIVE PLAN REQUIRED TO RUN DEFAULT PHASING	1	1
ACTIVE PLAN REQUIRED TO RUN ALTERNATE PHASING	2	2

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases

for heads 11 and 51 to run protected turns only.

VEH DET PLAN 2: Disables phase 6 call on loop 1A and reduces delay time for phase 1 call on loop 1A to 0 seconds.

> Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 0 seconds.

Electrical Detail - Sheet 2 of 2

Electrical and Programming Details For: Prepared for the Offices of:

NC 8 (Winston Road) Davidson County

11th Street May 2024 REVIEWED BY: J.T. Rowe REVIEWED BY: G.G. Murr, Jr DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL SIGNATURES COMPLETED

PLAN DATE: PREPARED BY: REVISIONS INIT. DATE SIG. INVENTORY NO. 09-0401T1

REVISED: N/A

1 Glenwood Avenue Raleigh, NC 27603 Tel:919.789.9977 Fax 919 789 9591

License: F-0453

DESIGNED: May 2024 SEALED: 05-09-2024

THIS ELECTRICAL DETAIL IS FOR

THE SIGNAL DESIGN: 09-0401T1

750 N. Greenfleld Pkwy, Garner, NC 27529