OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

Overlap	1	2	3	4
Туре	FYA 4 - Section	Off	FYA 4 - Section	Off
Included Phases	2		6	
Modifier Phases	1		5	
Modifier Overlaps	4	4	4	-
Trail Green	0		0	
Trail Yellow	0:0		0.0	
Trail Red	0.0		0.0	·

MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

Overlan Plan 2

Overlap	1	2	3	4	
Туре	FYA 4 - Section	Off	FYA 4 - Section	Off	
Included Phases	·	•			
Modifier Phases	1		5		
Modifier Overlaps	4	4	4	<u>-</u>	
Trail Green	0		0		
Trail Yellow	0.0		0.0		
Trail Red	0.0		0.0		

NOTICE CHANGES IN INCLUDED PHASE ROW

MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

1A

Detector	Call Phase	Delay
1	1	0
29	0	÷

	Detector	Call Phase	Delay
5A	15	5	0
	31	0	1

OUTPUT CHANNEL CONFIGURATION

Front Panel

Main Menu >Controller >More>Channels>Channels Config

Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

Channel Configuration

	Channel	Control Type	Control Source	Flash Yellow	Flash Red	Flash Alt	MMU Channe
	1	Phase Vehicle	1		Χ	Х	1
NOTICE CHANNEL 2 FLASHES RED	2	Phase Vehicle	2	·	Х		2
	3	Phase Vehicle	3	·	Х	Χ	3
	4	Phase Vehicle	4	·	Х		4
	5	Phase Vehicle	5	·	Х		5
NOTICE CHANNEL 6 FLASHES RED	6	Phase Vehicle	6	·	Х	Х	6
	7	Phase Vehicle	7	·	Х		7
	8	Phase Vehicle	8	·	Х	Х	8
NOTICE CHANNEL 9 FLASHES RED	9	Overlap	1	·	Х	Х	9
	10	Overlap	2	·	Х	Х	10
NOTICE CHANNEL 11 FLASHES RED	11	Overlap	3	·	Х		11
	12	Overlap	4	·	Х		12
	13	Phase Ped	2	·	·		13
	14	Phase Ped	4	·			14
	15	Phase Ped	6	·	·		15
	16	Phase Ped	8	·	·		16
	1.7	Overlap	5	·	Х	Х	17
	18	Overlap	6		Х		18
PROGRAM CHANNELS 19 & 20	19	Adv. Warning Flasher	2				19
AS ADV. WARNING FLASHER	20	Adv. Warning Flasher	6				20

MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface

Home >Controller >Coordination >Patterns

Pattern Parameters

Pattern	Veh Det Plan	Overlap Plan			
*	2	2			

*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

Unit Flash Parameters All Red Flash Exit Time

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 03-1244T1 DESIGNED: March 2025 SEALED: 3-31-2025 REVISED: N/A

Electrical Detail - Sheet 2 of 3

Electrical and Programming Details For: Prepared in the Offices of: 750 N. Greenfield Pkwy, Garner, NC 27529

US 17 (Ocean Highway West) US 17 Bus (Main Street SW) / SR 1316 (Old Shallotte Rd NW)

PLAN DATE: March 2025 REVIEWED BY: GG Murr, Jr. PREPARED BY: JT Rowe REVIEWED BY: REVISIONS INIT. DATE

008453 John T. Rowe. Jr 4-1-2025

PROJECT REFERENCE NO.

Sig. 2.2

R-5857

1 Glenwood Avenue Raleigh, NC 27603

SIG. INVENTORY NO. 03-1244T1

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED