WD ENABLE \

RP DISABLE ─ WD 1.0 SEC

- GY ENABLE

FYA COMPACT—

■ LEDguard

RF SSM

— FYA 1-9

15

= DENOTES POSITION OF SWITCH

DC ISOLATOR

ISOLATOR

NOT


USED

FYA 3-10

- SF#1 POLARITY

(remove jumpers and set switches as shown)

REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-10, 1-11, 2-5, 2-6, 2-9, 2-10, 2-11, 3-4, 3-10, 4-10, 5-9, 5-11, 6-9, 6-10, 6-11, 9-10, 9-11, and 10-11.



FILE

FILE

11 |11

USED

NOT

USED

EX.: 1A, 2A, ETC. = LOOP NO.'S

- 1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- 2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- 3. Ensure that the Red Enable is active at all times during normal operation.

INPUT FILE POSITION LAYOUT

(front view)

10

11 12 13

FS = FLASH SENSE ST = STOP TIME PRE = PREEMPT

4. Integrate monitor with Ethernet network in cabinet.

NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program controller to start up in phase 2 Green No Walk, 6 Green No Walk, 39 Phase Not On, and 40 Green No Walk.
- 3. Program Phase 39 for No Startup Veh Call.
- 4. Program phases 2, 6, and 40 for Min Recall.

Controller...

- 5. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 6. The cabinet and controller are part of the #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

EQUIPMENT INFORMATION

SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection.

NCDOT engineer -approved mounting locations to accomplish the

Perform installation according to manufacturer's directions and

detection schemes shown on the Signal Design Plans.

..2070LX

Cabinet	332 w/ Aux
Software	Q-Free MAXTIME
Cabinet Mount	Base
Output File Positions	18 With Aux. Output File
Load Switches Used	S1, S2, S4, S5, S7, S8, AUX S
	AUX S2, AUX S3, AUX S4
Phases Used	
Overlap "1"	*
Overlap "2"	*
Overlap "3"	
Overlap "4"	
Overlap "5"	
Overlap "7"	

^{*}See overlap programming detail on sheet 2

PROJECT REFERENCE NO. Sig. 15.1


					S	SIGN	NAL	.HE	AD	НО	OK-	-UP	СН	AR	Τ						
LOAD SWITCH NO.	S1	S2	S3	S4		S5		S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	Al S	JX 3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3		4		14	5	6	15	7	8	16	9	10	1	7	11	12	18
PHASE	1	2	2 PED	OL7		4		4 PED	5	6	6 PED	7	8	8 PED	OL1	OL2	O	L5	OL3	OL4	SPAR
SIGNAL HEAD NO	★ 11	21.22	NU	63	41	42	43	NU	★ 51	61,62	NU	NU	NU	NU	★ 11	6 3★	31	32	★ 51	NU	NU
RED		128				101	101			134				-		A124	A111	A111			
YELLOW	*	129		*		102	102		*	135				-	-	·	A112	A112	-		
GREEN		130				103	103			136							A113	A113			
RED ARROW					101										A121				A114		
YELLOW ARROW					102										A122	A125			A115		
FLASHING YELLOW ARROW						·									A123	A126			A116		
GREEN ARROW	127			118	103	103			133	-		·		-			A113	·		٠	
*						·				-								·			
Ķ																					


NU = Not Used

*Denotes install load resistor. See load resistor installation detail this sheet.

★See pictorial of head wiring in detail this sheet.


FYA SIGNAL WIRING DETAIL





(R)OL2 RED (A124) **\(\)** OL2 YELLOW (A125) OL2 GREEN (A126) OL7 GREEN (118) -

(wire signal heads as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T1

DESIGNED: Feb 2025

SEALED: 3/19/2025

Electrical Detail - Sheet 1 of 4

Temporary Design 1 - TMP Phase III, Step 3

REVISED:

Electrical and Programming Details For: Prepared for the Offices of:

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway Division 6 Robeson County Lumberton Feb 2025 H.M. Surti PLAN DATE: REVIEWED BY:

Trent Moody

SIG. INVENTORY NO. 06-1387T1

LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

Phase 1 Yellow Field Terminal (126) OL7 Yellow Field ACCEPTABLE VALUES Terminal (117) Value (ohms) | Wattage 1.5K - 1.9K 25W (min) Phase 5 Yellow Field 2.0K - 3.0K | 10W (min) Terminal (132) AC-AC-

* Reflects the detector utilized in the "MAXTIME DETECTOR PROGRAMMING

DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A" on Sheet 2.

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991

REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS INIT. DATE 750 N. Greenfield Pkwy, Garner, NC 27529

SEAL 040329

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL
SIGNATURES COMPLETED

3/19/2025 DATE

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

Overlap	1	2	3	5	7
Туре	FYA - 4 Section	FYA - 4 Section	FYA - 4 Section	Normal	Normal
Included Phases	2	6	6	3	4
Modifier Phases	1	4	5		-
Modifier Overlaps	-1	÷	4	ŀ	<u>-</u>
Trail Green	0	0	0	0	0
Trail Yellow	0:0	0.0	0.0	0:0	0.0
Trail Red	0.0	0.0	0.0	0:0	0:0

SEQUENCE DETAIL

PROJECT REFERENCE NO.

Sig. 15.2

Front Panel

Main Menu >Controller >Sequence & Phs Config>Sequences

Web Interface

Home >Controller >Sequence

Sequence 1

Ring	Sequence Data
1	1,2,a,3,4,b
2	5,6,a,b
3	39,c,40,d

MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

Overlap Plan 2

Overlap	1	2	3	5	7
Туре	FYA - 4 Section	FYA - 4 Section	FYA - 4 Section	Normal	Normal
Included Phases	<u>-</u>	6	-	3	4
Modifier Phases	1	4	5	-	-
Modifier Overlaps	÷	÷	-	-	-
Trail Green	0	0	0	0	0
Trail Yellow	0.0	0.0	0.0	0.0	0.0
Trail Red	0.0	0:0	0.0	0:0	0.0

MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

	Detector	Call Phase	Delay
1A	1	1	÷
	29	0	÷

Call Phase Delay Detector 5A 0

> THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T1 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:**

Temporary Design 1 - TMP Phase III, Step 3 Electrical Detail - Sheet 2 of 4

Electrical and Programming Details For: Prepared for the Offices of:

750 N**.** Greenfield Pkwy, Garner, NC 27529

NOTICE INCLUDED PHASE

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway

				•
Division 6	Robesoi	n County	L	.umberto
PLAN DATE:	Feb 2025	REVIEWED BY:	H.M. St	ırti
PREPARED BY:	J.C. Grimm	REVIEWED BY:	T.M. Mo	ody
	REVISIONS		INIT.	DATE

SEAL 040329

SIG. INVENTORY NO. 06-1387T1

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL
SIGNATURES COMPLETED

Phase Vehicle Χ Χ Phase Vehicle Χ TO CHANNEL 3 Overlap Χ Χ 3 4 Χ Phase Vehicle Phase Vehicle Χ 5 Phase Vehicle Χ Χ Phase Vehicle Χ Phase Vehicle Χ Χ Overlap Χ Χ 10 Overlap 2 Χ 10 Χ 11 Overlap Χ 11 12 12 Overlap 4 Χ 13 13 Phase Ped 2 14 Phase Ped 14

OUTPUT CHANNEL CONFIGURATION

Main Menu >Controller >More>Channels>Channels Config

Home >Controller >Advanced IO>Channels>Channels Configuration

Control Type Control Source Flash Yellow

5

Front Panel

Web Interface

Channel

15

16

17

Phase Ped

Phase Ped

Overlap

Overlap

NOTE OL7 ASSIGNED

Channel Configuration

NOTE: ALL RED FLASH

Χ

Χ

Flash Alt

Χ

Flash Red

MMU Channel

15

16

1.7

MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.


Start Up Parameters StartUp Clearance Hold **Unit Flash Parameters**

All Red Flash Exit Time 6

RAILROAD PREEMPTION WIRING DETAIL

(wire as shown below)


PREEMPTION AND BLANKOUT SIGN CONTROL BOX



NOTES

- 1. Relay K1 is shown in the energized (Preempt <u>not</u> active) normal operation state.
- 2. Relay K1 is a DPDT with 120VAC coil with octal base.
- 3. Relay SSR1 is a SPST (normally open) Solid State Relay with AC input and AC (25 amp) output.
- 4. AC Isolator Card shall activate preemption upon removal of AC+ from the input (as shown above). To accomplish this set invert dip switch on AC Isolator Card.
- 5. IMPORTANT!! A jumper must be added between input file terminals J14-E and J14-K if not already present. Also, terminal TB9-12 (on input panel) shall be connected to AC neutral (jumper may have to be added).

FRONT VIEW



PREEMPT 1 AC ISOLATOR (MODEL 252) OUTPUT PROGRAMMING DETAIL

PREEMPTION PROGRAMMING

Main Menu >Controller >Preemption >Preempt Phasing/Preempt Parameters

Home >Controller >Preempt Configuration >Preempts

Enabled

Rail Road

1, 6, 39

1, 2, 3

5

3, 5

3, 5

2, 6

1, 2, 3 0

1.0

0

Terminate

0

4.6

3.3

37

4.6

2.6

255

25.5

25.5

Exit Phases

Front Panel

Web Interface

Preempt Configuration

Preempt

Enabled

Type Track Phases

Track Overlaps

Dwell Phases

Dwell Peds

Dwell Overlaps

Cycling Phases

Cycling Peds

Cycling Overlaps

Exit Phases

Exit Overlaps

Delay Call Ext Time

Max Presence

Max Pres Act

Enter Min Green Enter Walk

Enter Ped Clear

Enter Yellow Change

Enter Red Clear

Track Green Track Yellow Clr

Track Red Clear

Dwell Green

Exit Min Green

Exit Yellow Change

Exit Red Clear

Exit Type Non Locking Memory

Not Ovrd Flash

Not Ovrd Nxt Pre


Require All Red Entry Track Clear Ovrd

Ped Clear During Yellow

Entry Omit OLTG


Track Reserve

(set DIP switches as shown below)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T1 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:**

Temporary Design 1 - TMP Phase III, Step 3 Electrical Detail - Sheet 3 of 4



NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway

					l
vision 6	Robes	on County	L	.umberton	
.AN DATE:	Feb 2025	REVIEWED BY:	H.M. St	ırti	
EPARED BY:	J.C. Grimm	REVIEWED BY:	T.M. Mo	ody	ļ
	REVISIONS		INIT.	DATE	

SEAL 040329

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

3/19/2025 SIG. INVENTORY NO. 06-1387T1

STV Engineers, Inc.

900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991

750 N**.** Greenfield Pkwy, Garner, NC 27529

PROJECT REFERENCE NO.

Sig. 15.4

MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface

Home >Controller >Coordination >Patterns

Pattern Parameters

Pattern	Veh Det Plan	Overlap Plan
*	2	2

*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

OVERLAP PLAN	VEH DET PLAN
1	1
2	2
	OVERLAP PLAN 1 2

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases

for heads 11 and 51 to run protected turns only.


VEH DET PLAN 2: Disables phase 6 call on loop 1A and reduces delay time for phase 1 call on loop 1A to 0 seconds.

> Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 0 seconds.

> > THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T1 DESIGNED: Feb 2025 SEALED: 3/19/2025 REVISED:

Temporary Design 1 - TMP Phase III, Step 3 Electrical Detail - Sheet 4 of 4

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991



NC 211 (N. Roberts Avenue) | Boomerang Drive / Restaurant Driveway

Division 6 Feb 2025 REVIEWED BY: H.M. Surti PLAN DATE: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm

3/19/2025 DATE SIG. INVENTORY NO. 06-1387T1

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL 040329

TABLE OF OPERATION TABLE OF OPERATION SIGNAL SIGNAL FACE FACE 11 21, 22 21, 22 31 32 41 42 42 43 43

DEFAULT PHASING

SIGNAL FACE I.D.

All Heads L.E.D.

	, , , , ,	moddo Everby		
"	12"	R 12"	R Y 12" 21, 22 32	12"
	11	31	43	63
	51	42	61 62	

61,62

Fully Actuated w/ Railroad Preemption

PHASE								rully Actuated W/ Railroad Preemption
Ø	Ø			R	D W RE	D W RE	F	#D06-18 Lumberton NC 211 (N. Roberts Avenue)
2 + 5	2 + 6	Ø 3	Ø 4	CLR	RE RL L	RE RL L	LASH	<u>NOTES</u>
	▼ R			-	<u></u> R	<u>₹</u>		 Refer to "Roadway Standard Drawings NCDOT" dated January 2024 and "Standard
G	G	R	R	R	R	R	R	Specifications for Roads and
R	R	G	R	R	G	R	R	Structures" dated January 2024.
R	R	G	R	R	G	R	R	2. This location contains railroad preemption
-R			-		-R	- R		phasing. Do not program signal for
R	R	R	G	R	R	R	R	late night flashing operation. 3. Phase 1 and/or phase 5 may be lagged.
R	R	R	G	R	R	R	R	4. The order of phase 3 and phase 4 may

ALTERNATE PHASING

	late night flashing operation.
3.	Phase 1 and/or phase 5 may be lagged.
4.	The order of phase 3 and phase 4 may

be reversed.


5. Program phase 40 to run concurrently with all phases during normal operation. Phase 39 must be incompatible with phase 40 and included as a track clear phase.

6 Phase

6. The Division Traffic Engineer will determine the hours of use for each phasing plan.

7. This intersection uses multi-zone microwave detection. Install detectors according to the manufacturer's instructions to achieve the desired detection.

8. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.



* Directs controller to use default phase timing.

MAXTIME PREEMPTION CHART

PRE 1 RAIL ROAD

2, 6

0.0

0

1

1

0

4.6

3.3

37 4.6

2.6

7

255 * 25.5 *

25.5 *

1.0

EXIT PHASES

FUNCTION

Exit Phases

Max Presence

Enter Walk

Enter Min Green

Enter Ped Clear

Enter Red Clear

Track Red Clear

Track Green

Dwell Green

Exit Min Green

Exit Red Clear

Call Extend Time

Ped Clear Through Yellow

Require All Red Entry

Exit Yellow Change

Enter Yellow Change

DEFAULT PHASING DIAGRAM

Ø2+6

Ø2+5

Ø1+6

		MAX	TIME T	IMING	CHART						
FFATURE	PHASE										
FEATURE	1	2	3	4	5	6	39	40			
Walk *	_	_	_	_	_	_					
Ped Clear *	_	_	_	_	_	_					
Min Green	7	12	7	7	7	12					
Passage *	2.0	2.0	2.0	2.0	2.0	2.0					
Max 1 *	20	90	30	30	20	90					
Yellow Change	3.0	4.6	3.2	3.2	3.0	4.6	4.6	4.6			
Red Clear	2.6	1.6	2.6	3.3	2.8	1.6	2.6	3.3			
Added Initial *	_	_	_	_	_	_					
Maximum Initial *	_	_	_	_	_	_					
Time Before Reduction *	_	_	_	_	_	_					
Time To Reduce *	_	_	_	_	_	_					
Minimum Gap	_	_	_	_	_	_					
Advance Walk	-	_	_	_	_	_					
Non Lock Detector	Х	_	Х	Х	Х	_					
Vehicle Recall	_	MIN RECALL	_	_	_	MIN RECALL		MIN RECAL			
				1							

DEFAULT RAIL

PREEMPT PHASES

(High Priority)

Clear (Ø1+6+39)

Dwell 1 (Ø3)

Dwell 2 (Ø5)

PHASING DIAGRAM DETECTION LEGEND

DETECTED MOVEMENT

UNSIGNALIZED MOVEMENT

PEDESTRIAN MOVEMENT

UNDETECTED MOVEMENT (OVERLAP)

,					p	
what is shown. Min	Green	for all other phases sh	hould not be lowe	r than 4 seconds.		

DETECTOR PROGRAMMING												
L00P	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	CALL PHASE	DELAY TIME	EXTEND TIME	EXTEND	ADDED INITIAL	CALL	DELAY DURING GREEN	NEW CABD
1A	6X40	0	* *	1	15**	-	Χ	-	Χ	-	*	
17	0.40				6#	-	-	Χ	-	Χ	-	*
ЗА	6X20	0	*	*	3	5	-	Χ	-	Χ	-	*
4A	6X40	0	*	*	4	-	-	Χ	-	Χ	-	*
4B	6X40	0	*	*	4	5	-	Χ	-	Χ	-	*
ΓΛ	CV 4.0				5	15**	-	Χ	-	Χ	-	*
5A	6X40	0	*	*	2#	-	-	Χ	-	Χ	-	*

ALTERNATE RAIL

PREEMPT PHASES

(High Priority)

Track

Clear (Ø1+6+39)

Dwell 1

Dwell 2 (Ø5)

61,62

ALTERNATE PHASING DIAGRAM

Ø2+6

Ø2+5

Ø1+6

Ø1+5

- * Multi-zone Microwave Detection Zone
- ★★ Disable Delay During Alternate Phasing
- # Disable Phase Call for Loop During Alternate Phasing

RADAR DETECTION SYSTEM								
FUNCTION SENSOR 1 - QA SENSOR 2 - 6A								
Channel	1	2						
Phase	2	6						
Direction of Travel	EB	WB						
Detection Zone (ft)	500 – 100	500 –100						
Enable Speed	Y	Y						
Speed Range (mph)	35 – 100	35 – 100						
Enable Estimated Time of Arrival	Y	Y						
Estimated Time of Arrival (sec)	2.5 - 6.5	2.5 - 6.5						

STV Engineers, Inc.

900 West Trade St., Suite 715

Charlotte, NC 28202

(704) 372-1885 NC License Number F-0991

Traffic Signal Head \bigcirc \longrightarrow Modified Signal Head N/A Metal Strain Pole Inductive Loop Detector Controller & Cabinet Junction Box 2-in Underground Conduit _----Directional Drill N/A Right of Way ______ Directional Arrow \longrightarrow Railroad Tracks Railroad Gate and Flasher Microwave Detection Zone Right Arrow "ONLY" Sign (R3-5R)

LEGEND

Temporary Design 2 - TMP Phase V, Step 2

1"=40'

New Installation

NC 211 (N. Roberts Avenue) Boomerang Drive / Restaurant Driveway

<u>PROPOSED</u>

Robeson County Division 6 Feb 2025 REVIEWED BY: H.M. Surti J.C. Grimm REVIEWED BY: T.M. Moody

Lumberton REVISIONS

FINAL UNLESS ALL SIGNATURES COMPLETED SEAL

DOCUMENT NOT CONSIDERED

Trent Moody 03/19/2025 SIG. INVENTORY NO. 06-1387T

<u>EXISTING</u>

(remove jumpers and set switches as shown)

WD ENABLE

- RF 2010 RP DISABLE ─ WD 1.0 SEC

■ LEDguard

RF SSM

FYA 1-9

____ FYA 3-10

FYA 5-11
FYA 7-12

14

15

= DENOTES POSITION OF SWITCH

16 17


PRE = PREEMPT

GY ENABLE

FYA COMPACT

- SF#1 POLARITY

REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-11, 2-5, 2-6, 2-9, 2-11, 5-9, 5-11, 6-9, 6-11, and 9-11.



REMOVE JUMPERS AS SHOWN

- 1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- 2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- 3. Ensure that the Red Enable is active at all times during normal operation.
- 4. Integrate monitor with Ethernet network in cabinet.

NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program controller to start up in phase 2 Green No Walk, 6 Green No Walk, 39 Phase Not On, and 40 Green No Walk.
- 3. Program Phase 39 for No Startup Veh Call.
- 4. Program phases 2, 6, and 40 for Min Recall.
- 5. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 6. The cabinet and controller are part of the #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

EQUIPMENT INFORMATION

Controller	2070LX
Cabinet	332 w/ Aux
Software	Q-Free MAXTIME
Cabinet Mount	Base
Output File Positions	18 With Aux. Output File
Load Switches Used	S1, S2, S5, S7, S8, AUX S1,
	AUX S3, AUX S4
Phases Used	1, 2, 3, 4, 5, 6
Overlap "1"	*
Overlap "2"	
Overlap "3"	
Overlap "4"	
Overlap "5"	
·	

*See overlap programming detail on sheet 2


PROJECT REFERENCE NO. Sig. 16.1

SIGNAL HEAD HOOK-UP CHART																					
LOAD SWITCH NO.	S1	S2	S3	S4		S5		S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	Al S	JX JX	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3		4		14	5	6	15	7	8	16	9	10	1	7	11	12	18
PHASE	1	2	2 PED	3		4		4 PED	5	6	6 PED	7	8	8 PED	OL1	OL2	O	L5	OL3	OL4	SPARE
SIGNAL HEAD NO.	★ 11	21.22	NU	NU	41	42	43	NU	★ 51	61,62	NU	NU	NU	NU	★ 11	NU	31	32	★ 51	NU	NU
RED	e.	128				101	101			134							A111	A111			
YELLOW	*	129				102	102		*	135							A112	A112			
GREEN		130	-			103	103	-		136			-	-			A113	A113	-		
RED ARROW	4		-		101			-	÷				-		A121			-	A114		
YELLOW ARROW			-		102			-							A122			-	A115		
FLASHING YELLOW ARROW	4														A123				A116		
GREEN ARROW	127				103	103			133								A113				
₩								-													
×	٠								-		·		-	-							
NILL - Nigt I	VIII - Not Usad																				

NU = Not Used

INPUT FILE POSITION LAYOUT

(front view)



* Reflects the detector utilized in the "MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A" on Sheet 2.

ACCEPTABLE VALUES

Value (ohms) | Wattage


1.5K - 1.9K | 25W (min) 2.0K - 3.0K | 10W (min)

SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T2 DESIGNED: Feb 2025 SEALED: 3/19/2025 REVISED:

(install resistors as shown)

Phase 1 Yellow Field Terminal (126) Terminal (132)

Temporary Design 2 - TMP Phase V, Step 2 Electrical Detail - Sheet 1 of 4 Electrical and Programming

Prepared for the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway

Division 6 Robeson County H.M. Surti Feb 2025 PLAN DATE: REVIEWED BY: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm

Lumberton REVISIONS DATE

SEAL 040329 Trent Moody 3/19/2025

SIG. INVENTORY NO. 06-1387T2

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL
SIGNATURES COMPLETED

LOAD RESISTOR INSTALLATION DETAIL

Phase 5 Yellow Field

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991

^{*}Denotes install load resistor. See load resistor installation detail this sheet.

[★]See pictorial of head wiring in detail this sheet.

Front Panel

Main Menu >Controller >More>Channels>Channels Config

Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

Channel Configuration

Channel	Control Type	Control Source	Flash Yellow	Flash Red	Flash A l t	MMU Channe
1	Phase Vehicle	1		X	X	1
2	Phase Vehicle	2		X		2
3	Phase Vehicle	3		X	X	3
4	Phase Vehicle	4		X		4
5	Phase Vehicle	5		X		5
6	Phase Vehicle	6		X	Х	6
7	Phase Vehicle	7		X		7
8	Phase Vehicle	8		X	Х	8
9	Overlap	1		X	Х	9
10	Overlap	2		X	Х	10
11	Overlap	3		X		11
12	Overlap	4		X		12
13	Phase Ped	2				13
14	Phase Ped	4				14
15	Phase Ped	6				15
16	Phase Ped	8			-	16
17	Overlap	5		X	Χ	17
18	Overlap	6		X		18



MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

All Red Flash Exit Time

6

MAXTIME OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

Overlap	1	3	5
Туре	FYA - 4 Section	FYA - 4 Section	Normal
Included Phases	2	6	3
Modifier Phases	1	5	-
Modifier Overlaps	-	-	-
Trail Green	0	0	0
Trail Yellow	0.0	0.0	0.0
Trail Red	0.0	0.0	0.0

SEQUENCE DETAIL

PROJECT REFERENCE NO.

Sig. 16.2

Front Panel

Main Menu >Controller >Sequence & Phs Config>Sequences

Web Interface

Home >Controller >Sequence

Sequence 1

Ring	Sequence Data
1	1,2,a,3,4,b
2	5,6,a,b
3	39,c,40,d

MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

Overlap Plan 2

Overlap	1	3	5	
Туре	FYA - 4 Section	FYA - 4 Section	Normal	NOTICE
Included Phases	<u>-</u>	÷	3	INCLUDED
Modifier Phases	1	5	÷	PHASE
Modifier Overlaps	<u>-</u>	÷	÷	
Trail Green	0	0	0	
Trail Yellow	0.0	0.0	0.0	
Trail Red	0.0	0.0	0.0	

MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan Z		
Detector	Call Phase	Delay
1	1	÷
29	0	<u>-</u>

Detector Call Phase Delay 5A 15 31 0

> THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T2 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:**

Temporary Design 2 - TMP Phase V, Step 2 Electrical Detail - Sheet 2 of 4

Electrical and Programming Details For:

750 N. Greenfield Pkwy, Garner, NC 27529

STV Engineers, Inc.

900 West Trade St., Suite 715

Charlotte, NC 28202

(704) 372-1885

NC License Number F-0991

1A

NC 211 (N. Roberts Avenue)

Prepared for the Offices of: Boomerang Drive / Restaurant Driveway Division 6 Feb 2025

Robeson County Lumberton REVIEWED BY: H.M. Surti REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS DATE

SEAL 040329 Trent Moody 3/19/2025

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL
SIGNATURES COMPLETED

SIG. INVENTORY NO. 06-1387T2

Unit Flash Parameters

PROJECT REFERENCE NO. SHEET NO.

Sig. 16.3

PREEMPTION PROGRAMMING

Front Panel

Main Menu >Controller >Preemption >Preempt Phasing/Preempt Parameters

Web Interface

Home >Controller >Preempt Configuration >Preempts


Preempt Configuration

Teempt Comigaration									
1									
Enabled									
Rail Road									
1, 6, 39									
1, 3									
3									
_									
5									
3, 5									
-									
3, 5									
2, 6									
1, 3									
0									
1.0									
0									
Terminate									
1									
1									
0									
4.6									
3.3									
37									
4.6									
2.6									
7									
255									
25.5									
25.5									
Exit Phases									
<u>-</u>									
X									
-									
-									
X									
-									
X									
X									

RAILROAD PREEMPTION WIRING DETAIL

(wire as shown below)

PREEMPTION AND BLANKOUT SIGN CONTROL BOX



NOTES

- 1. Relay K1 is shown in the energized (Preempt not active) normal operation state.
- 2. Relay K1 is a DPDT with 120VAC coil with octal base.
- 3. Relay SSR1 is a SPST (normally open) Solid State Relay with AC input and AC (25 amp) output.
- 4. AC Isolator Card shall activate preemption upon removal of AC+ from the input (as shown above). To accomplish this set invert dip switch on AC Isolator Card.
- 5. IMPORTANT!! A jumper must be added between input file terminals J14-E and J14-K if not already present. Also, terminal TB9-12 (on input panel) shall be connected to AC neutral (jumper may have to be added).

STV Engineers, Inc.


Charlotte, NC 28202

(704) 372-1885

NC License Number F-0991


900 West Trade St., Suite 715

FRONT VIEW



PREEMPT 1 AC ISOLATOR (MODEL 252) OUTPUT PROGRAMMING DETAIL

(set DIP switches as shown below)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T2 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:**



Electrical and Programming Details For: Prepared for the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway

Division 6 Robeson County Lumberton REVIEWED BY: H.M. Surti Feb 2025 PLAN DATE: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS

Trent Moody DATE

3/19/2025 SIG. INVENTORY NO. 06-1387T2

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL 040329

PROJECT REFERENCE NO. SHEET NO.

Sig. 16.4

MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface

Home >Controller >Coordination >Patterns

Pattern Parameters

- attorr - arametere									
Pattern	Veh Det Plan	Overlap Plan							
*	2	2							

*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

PHASING	OVERLAP PLAN	VEH DET PLAN
ACTIVE PLAN REQUIRED TO RUN DEFAULT PHASING	1	1
ACTIVE PLAN REQUIRED TO RUN ALTERNATE PHASING	2	2

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases

for heads 11 and 51 to run protected turns only.

VEH DET PLAN 2: Disables phase 6 call on loop 1A

and reduces delay time for phase 1 call on loop 1A to 0 seconds.

Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 0 seconds.

> THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T2 DESIGNED: Feb 2025 SEALED: 3/19/2025 REVISED:

Temporary Design 2 - TMP Phase V, Step 2 Electrical Detail - Sheet 4 of 4

Electrical and Programming Details For:

Prepared for the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

Boomerang Drive / Restaurant Driveway

NC 211 (N. Roberts Avenue)

Division 6 Robeson County Lumberton REVIEWED BY: H.M. Surti Feb 2025 PLAN DATE: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm

Trent Moody


3/19/2025 sig. inventory no. 06-1387T2

SEAL 040329

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

STV Engineers, Inc. 900 West Trade St., Suite 715

Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991



12"

45 MPH -1% Grade

~~~~

SIGNAL FACE I.D.

All Heads L.E.D.

|     | R   | R                | R          |
|-----|-----|------------------|------------|
| 12" | 12" | Y 12"            | $\bigcirc$ |
|     | G   | G                | (F)        |
|     |     | 21, 22<br>32     | $\bigcirc$ |
| 11  | 31  | 3 <i>2</i><br>43 | 63         |

61,62

9. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.

included as a track clear phase. 7. The Division Traffic Engineer will

8. This intersection uses multi-zone

according to the manufacturer's

determine the hours of use for each

instructions to achieve the desired

microwave detection. Install detectors

LEGEND

Traffic Signal Head

Modified Signal Head

Metal Strain Pole

Inductive Loop Detector

Controller & Cabinet

Junction Box

2-in Underground Conduit

Directional Drill

Right of Way

Directional Arrow

Railroad Tracks

Railroad Gate and Flasher

Microwave Detection Zone

Right Arrow "ONLY" Sign (R3-5R)

w/ Railroad Preemption

NOTES

NCDOT" dated January 2024 and "Standard

all phases during normal operation. Phase

39 must be incompatible with phase 40 and

Specifications for Roads and

Structures" dated January 2024.

late night flashing operation.

be reversed.

phasing plan.

detection.

22 and 51.

phasing. Do not program signal for

MAXTIME PREEMPTION CHART **FUNCTION** PRE 1 RAIL ROAD Exit Phases 2, 6 0.0 Max Presence 0 Enter Min Green 1 Enter Walk 1 Enter Ped Clear Enter Yellow Change 4.6 Enter Red Clear 3.0 Track Green 36 4.6 2.8 Track Red Clear **Dwell Green** 255 \* Exit Min Green Exit Yellow Change 25.5 \* Exit Red Clear 25.5 \* Call Extend Time 1.0 **EXIT PHASES** Ped Clear Through Yellow Require All Red Entry

\* Directs controller to use default phase timing.

7

2.0

20

3.0

2.8

**FEATURE** 

Ped Clear <sup>\*</sup>

Min Green

Passage

Yellow Change

Added Initial \*

Time Before Reduction

DEFAULT PHASING DIAGRAM

Ø2+6

Ø2+5

Ø1+6

45 MPH -1% Grade This signal was designed

DEFAULT RAIL

PREEMPT PHASES

(High Priority)

Clear (Ø1+6+39)

Dwell 1 (Ø3)

Dwell 2 (Ø5)

PHASING DIAGRAM DETECTION LEGEND

UNSIGNALIZED MOVEMENT

UNDETECTED MOVEMENT (OVERLAP)

DETECTED MOVEMENT

← − → PEDESTRIAN MOVEMENT

for Advanced Preemption.

PHASE

2.0

20

3.0

2.8

2.0

30

3.2

3.0

6

2.0

90

4.6

1.6

39

4.6 2.8

MAXTIME TIMING CHART

| 40  |        |
|-----|--------|
|     |        |
|     |        |
|     |        |
|     | LC     |
|     |        |
| 4.6 |        |
| 3.0 |        |
|     | 1      |
|     |        |
|     | 3<br>4 |
|     | 4      |
|     | 4      |
|     | _      |
|     | 5      |
|     |        |

ALTERNATE PHASING DIAGRAM

Ø2+6

Ø2+5

Ø1+6

Ø1+5

Unbag and reconnect

signal head 63

NC 211 (N Roberts Avenue)

(5A) <

DETECTOR

6X40

STOPBAR

(High Priority)

Dwell 2 (Ø5)

22

PROGRAMMING

1 | 15\*\* | - | X | - | X | -

5 | 15\*\* | - | X | - | X | - |

- | X | - | X | -

- | X | - | X | -

| - |X|-|X|-|

| - |X|-|X|-|→

O CALL DELAY EXTEND S IN S

<sub>≅</sub>|PHASE| TIME | TIME | ≿|

\* 3 | 5

4 | 15 |

\* Multi-zone Microwave Detection Zone

★★ Disable Delay During Alternate Phasing

# Disable Phase Call for Loop During Alternate Phasing

MAXTIME DETECTOR INSTALLATION CHART

| RADAR DETECTION<br>SYSTEM            |           |           |  |  |  |  |  |  |
|--------------------------------------|-----------|-----------|--|--|--|--|--|--|
| FUNCTION SENSOR 1 - QA SENSOR 2 - 6A |           |           |  |  |  |  |  |  |
| Channel                              | 1         | 2         |  |  |  |  |  |  |
| Phase                                | 2         | 6         |  |  |  |  |  |  |
| Direction of Travel                  | EB        | WB        |  |  |  |  |  |  |
| Detection Zone (ft)                  | 500 – 100 | 500 –100  |  |  |  |  |  |  |
| Enable Speed                         | Y         | Y         |  |  |  |  |  |  |
| Speed Range (mph)                    | 35 – 100  | 35 – 100  |  |  |  |  |  |  |
| Enable Estimated Time of Arrival     | Y         | Y         |  |  |  |  |  |  |
| Estimated Time of Arrival (sec)      | 2.5 - 6.5 | 2.5 - 6.5 |  |  |  |  |  |  |

NC 211

N Roberts Avenue)

New Installation Temporary Design 3 - TMP Phase VI, Step 4

> NC 211 (N. Roberts Avenue) Boomerang Drive /

**PROPOSED** 

 $\bigcirc$ 

Restaurant Driveway Division 6 Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti J.C. Grimm REVIEWED BY: T.M. Moody

Trent Moody

03/19/202 SIG. INVENTORY NO. 06-1387T

<u>EXISTING</u>

**-**

N/A

KX KX

N/A

\_\_\_\_

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL

SIGNATURES COMPLETED

SEAL

| Time To Reduce *                                                                                                | _ | _          | _ | _ | _ | _          |  |           |  |
|-----------------------------------------------------------------------------------------------------------------|---|------------|---|---|---|------------|--|-----------|--|
| Minimum Gap                                                                                                     | _ | _          | _ | _ | _ | _          |  |           |  |
| Advance Walk                                                                                                    | - | _          | _ | _ | _ | _          |  |           |  |
| Non Lock Detector                                                                                               | Х | _          | Х | Х | Х | _          |  |           |  |
| Vehicle Recall                                                                                                  | - | MIN RECALL | _ | _ | _ | MIN RECALL |  | MIN RECAL |  |
| Dual Entry                                                                                                      | _ | _          | _ | _ | _ | _          |  |           |  |
| * These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than |   |            |   |   |   |            |  |           |  |

2.0

30

3.2

2.6

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991

REVISIONS

what is shown. Min Green for all other phases should not be lower than 4 seconds.

2

12

2.0

90

4.6

1.6

1"=40'

50 N.Greenfield Pkwy,Garner,NC 27529 PREPARED BY:

OFF

= DENOTES POSITION OF SWITCH

DC ISOLATOR

**ISOLATOR** 


NOT

USED

WD ENABLE

(remove jumpers and set switches as shown)

REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-10, 1-11, 2-5, 2-6, 2-9, 2-10, 2-11, 3-4, 3-10, 4-10, 5-9, 5-11, 6-9, 6-10, 6-11, 9-10, 9-11, and 10-11.



INPUT FILE POSITION LAYOUT

(front view)

10

11 12

FS = FLASH SENSE ST = STOP TIME PRE = PREEMPT

FILE

FILE

" ["

**JSED** 

EX.: 1A, 2A, ETC. = LOOP NO.'S

- 1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- 2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- 3. Ensure that the Red Enable is active at all times during normal operation.
- 4. Integrate monitor with Ethernet network in cabinet.

## NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program controller to start up in phase 2 Green No Walk, 6 Green No Walk, 39 Phase Not On, and 40 Green No Walk.
- 3. Program Phase 39 for No Startup Veh Call
- 4. Program phases 2, 6, and 40 for Min Recall.

Controller...

- 5. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 6. The cabinet and controller are part of the #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

#### **EQUIPMENT INFORMATION**

..2070LX

| Cabinet               | 332 w/ Aux                     |
|-----------------------|--------------------------------|
| Software              | Q-Free MAXTIME                 |
| Cabinet Mount         | Base                           |
| Output File Positions | 18 With Aux. Output File       |
| Load Switches Used    | S1, S2, S4, S5, S7, S8, AUX S1 |
|                       | AUX S2, AUX S3, AUX S4         |
| Phases Used           |                                |
| Overlap "1"           | *                              |
| Overlap "2"           | *                              |
| Overlap "3"           |                                |
| Overlap "4"           |                                |
| Overlap "5"           | *                              |
| Overlap "7"           |                                |

<sup>\*</sup>See overlap programming detail on sheet 2

# PROJECT REFERENCE NO. Sig. 17.1

|                             |                |       |          |     | S   | SIGN | ۱AL | . HE     | .AD         | HO    | OK-      | -UP | CH  | IAR      | ı              |                 |         |         |             |           |           |
|-----------------------------|----------------|-------|----------|-----|-----|------|-----|----------|-------------|-------|----------|-----|-----|----------|----------------|-----------------|---------|---------|-------------|-----------|-----------|
| LOAD<br>SWITCH NO.          | S1             | S2    | S3       | S4  |     | S5   |     | S6       | S7          | S8    | S9       | S10 | S11 | S12      | AUX<br>S1      | AUX<br>S2       | Al<br>S | JX<br>3 | AUX<br>S4   | AUX<br>S5 | AUX<br>S6 |
| CMU<br>CHANNEL<br>NO.       | 1              | 2     | 13       | 3   |     | 4    |     | 14       | 5           | 6     | 15       | 7   | 8   | 16       | 9              | 10              | 1       | 7       | 11          | 12        | 18        |
| PHASE                       | 1              | 2     | 2<br>PED | OL7 |     | 4    |     | 4<br>PED | 5           | 6     | 6<br>PED | 7   | 8   | 8<br>PED | OL1            | OL2             |         | L5      | OL3         | OL4       | SPAR      |
| SIGNAL<br>HEAD NO.          | <b>★</b><br>11 | 21.22 | NU       | 63  | 41  | 42   | 43  | NU       | <b>★</b> 51 | 61,62 | NU       | NU  | NU  | NU       | <b>★</b><br>11 | 63 <sup>*</sup> | 31      | 32      | <b>★</b> 51 | NU        | NU        |
| RED                         |                | 128   |          | -   | -   | 101  | 101 |          |             | 134   |          |     | ·   |          | -              | A124            | A111    | A111    |             |           |           |
| YELLOW                      | *              | 129   |          | *   | -   | 102  | 102 |          | *           | 135   |          | ٠   |     |          | -              |                 | A112    | A112    |             | -         |           |
| GREEN                       | ·              | 130   |          | -   | -   | 103  | 103 |          |             | 136   |          | ·   |     | -        | -              |                 | A113    | A113    |             | -         |           |
| RED<br>ARROW                |                |       |          | -   | 101 |      |     |          |             | -     |          |     |     |          | A121           |                 |         |         | A114        |           |           |
| YELLOW<br>ARROW             |                |       |          |     | 102 |      | ı   |          |             |       |          | ·   |     |          | A122           | A125            |         |         | A115        |           |           |
| FLASHING<br>YELLOW<br>ARROW |                |       |          |     |     |      |     |          |             |       |          |     |     |          | A123           | A126            |         | ·       | A116        | -         |           |
| GREEN<br>ARROW              | 127            |       |          | 118 | 103 | 103  | ÷   | ·        | 133         | -     | ÷        | ·   | ·   |          | -              |                 | A113    |         |             | -         | -         |
| #                           |                |       |          |     |     |      |     |          |             | -     | ·        | ·   |     |          |                |                 | ·       |         |             | -         |           |
| Ķ                           |                |       |          |     |     |      |     |          |             |       |          |     |     |          |                |                 |         |         |             | -         |           |


NU = Not Used


\*Denotes install load resistor. See load resistor installation detail this sheet.


★See pictorial of head wiring in detail this sheet.

#### FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)








## SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

#### LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)



\* Reflects the detector utilized in the "MAXTIME DETECTOR PROGRAMMING

DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A" on Sheet 2.

#### FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO ENSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- 1. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- 2. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T3 DESIGNED: Feb 2025 SEALED: 3/19/2025 REVISED:

Temporary Design 3 - TMP Phase VI, Step 4 Electrical Detail - Sheet 1 of 4

Electrical and Programming

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway



750 N. Greenfield Pkwy, Garner, NC 27529

STV Engineers, Inc.

900 West Trade St., Suite 715

Charlotte, NC 28202

(704) 372-1885

NC License Number F-0991

Robeson County H.M. Surti Feb 2025 REVIEWED BY:

Division 6 Lumberton PLAN DATE: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS DATE

SEAL 040329 Trent Moody 3/19/2025

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL
SIGNATURES COMPLETED

SIG. INVENTORY NO. 06-1387T3


Front Panel

Main Menu >Controller >More>Channels>Channels Config

Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

Channel Configuration



NOTE: ALL RED FLASH

## MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

Unit Flash Parameters All Red Flash Exit Time

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

| Overlap           | 1               | 2               | 3               | 5      | 7      |
|-------------------|-----------------|-----------------|-----------------|--------|--------|
| Type              | FYA - 4 Section | FYA - 4 Section | FYA - 4 Section | Normal | Normal |
| Included Phases   | 2               | 6               | 6               | 3      | 4      |
| Modifier Phases   | 1               | 4               | 5               | =      | -      |
| Modifier Overlaps | <del>-</del>    | 4               | 4               | 4      | _      |
| Trail Green       | 0               | 0               | 0               | 0      | 0      |
| Trail Yellow      | 0.0             | 0.0             | 0:0             | 0.0    | 0.0    |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0    | 0.0    |

## SEQUENCE DETAIL

PROJECT REFERENCE NO.

Sig. 17.2

Front Panel

Main Menu >Controller >Sequence & Phs Config>Sequences

Web Interface

Home >Controller >Sequence

Sequence 1

| Ring | Sequence Data |
|------|---------------|
| 1    | 1,2,a,3,4,b   |
| 2    | 5,6,a,b       |
| 3    | 39.c.40.d     |

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

Overlap Plan 2

| Overlap           | 1               | 2               | 3               | 5        | 7        |          |
|-------------------|-----------------|-----------------|-----------------|----------|----------|----------|
| Type              | FYA - 4 Section | FYA - 4 Section | FYA - 4 Section | Normal   | Normal   | NOTICE   |
| Included Phases   | -               | 6               | -               | 3        | 4        | INCLUDED |
| Modifier Phases   | 1               | 4               | 5               | <u>-</u> | _        | PHASE    |
| Modifier Overlaps | 4               | <u> -</u>       | 4               | 4        | <u>-</u> |          |
| Trail Green       | 0               | 0               | 0               | 0        | 0        |          |
| Trail Yellow      | 0.0             | 0.0             | 0.0             | 0.0      | 0.0      |          |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0      | 0.0      |          |

## MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

| Detector | Call Phase | Delay    |
|----------|------------|----------|
| 1        | 1          | <u>-</u> |
| 29       | 0          | <u> </u> |

5A

1A

| Detector | Call Phase | Delay    |
|----------|------------|----------|
| 15       | 5          | ÷        |
| 31       | 0          | <u>-</u> |

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T3 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:** 

Temporary Design 3 - TMP Phase VI, Step 4 Electrical Detail - Sheet 2 of 4

Electrical and Programming Details For:

Prepared for the Offices of:

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway

Division 6 Robeson County REVIEWED BY: H.M. Surti Feb 2025 REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm

Lumberton

Trent Moody SIG. INVENTORY NO. 06-1387T3

SEAL 040329

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL
SIGNATURES COMPLETED

STV Engineers, Inc. Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991

750 N. Greenfield Pkwy, Garner, NC 27529


900 West Trade St., Suite 715

Sig. 17.3

#### RAILROAD PREEMPTION WIRING DETAIL

(wire as shown below)


#### PREEMPTION AND BLANKOUT SIGN CONTROL BOX



## NOTES

- 1. Relay K1 is shown in the energized (Preempt <u>not</u> active) normal operation state.
- 2. Relay K1 is a DPDT with 120VAC coil with octal base.
- 3. Relay SSR1 is a SPST (normally open) Solid State Relay with AC input and AC (25 amp) output.
- 4. AC Isolator Card shall activate preemption upon removal of AC+ from the input (as shown above). To accomplish this set invert dip switch on AC Isolator Card.
- 5. IMPORTANT!! A jumper must be added between input file terminals J14-E and J14-K if not already present. Also, terminal TB9-12 (on input panel) shall be connected to AC neutral (jumper may have to be added).

## FRONT VIEW



# PREEMPT 1 AC ISOLATOR (MODEL 252) OUTPUT PROGRAMMING DETAIL

PREEMPTION PROGRAMMING

Main Menu >Controller >Preemption >Preempt Phasing/Preempt Parameters

Home >Controller >Preempt Configuration >Preempts

Enabled

1, 6, 39

1, 2, 3

5

3, 5

3, 5

2, 6

1, 2, 3

0

1.0 0

Terminate

0

4.6

3.0

36

4.6

2.8

255

25.5

25.5

**Exit Phases** 

Rail Road

Front Panel

Web Interface

Preempt Configuration

Preempt

Enabled

Type Track Phases

Track Overlaps

**Dwell Phases** 

Dwell Peds

Dwell Overlaps

Cycling Phases

Cycling Peds

Cycling Overlaps Exit Phases

Exit Overlaps

Delay Call Ext Time

Max Presence

Max Pres Act Enter Min Green Enter Walk **Enter Ped Clear** 

Enter Yellow Change

**Enter Red Clear** 

Track Green

Track Yellow Clr

Track Red Clear

Dwell Green

Exit Min Green

Exit Yellow Change

Exit Red Clear

Exit Type

Non Locking Memory

Not Ovrd Flash

Not Ovrd Nxt Pre Require All Red Entry


Track Clear Ovrd

Ped Clear During Yellow


Entry Omit OLTG

Track Reserve

(set DIP switches as shown below)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T3 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:** 



Prepared for the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

Boomerang Drive / Restaurant Driveway

Division 6 Robeson County Lumberton REVIEWED BY: H.M. Surti Feb 2025 PLAN DATE: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS DATE

Trent Moody 3/19/2025

SEAL 040329

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SIG. INVENTORY NO. 06-1387T3

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202

(704) 372-1885 NC License Number F-0991

| OJECT REFERENCE NO. | SHEET   |
|---------------------|---------|
| U-5797              | Sig. 17 |

## MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface

Home >Controller >Coordination >Patterns

Pattern Parameters

| attern arametere |              |              |  |  |  |  |  |  |
|------------------|--------------|--------------|--|--|--|--|--|--|
| Pattern          | Veh Det Plan | Overlap Plan |  |  |  |  |  |  |
| *                | 2            | 2            |  |  |  |  |  |  |

\*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

## MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

| PHASING                                       | OVERLAP PLAN | VEH DET PLAN |
|-----------------------------------------------|--------------|--------------|
| ACTIVE PLAN REQUIRED TO RUN DEFAULT PHASING   | 1            | 1            |
| ACTIVE PLAN REQUIRED TO RUN ALTERNATE PHASING | 2            | 2            |

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases

for heads 11 and 51 to run

protected turns only.

VEH DET PLAN 2: Disables phase 6 call on loop 1A

and reduces delay time for phase 1 call on loop 1A to 0 seconds.

Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 0 seconds.

> THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387T3 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:**

Temporary Design 3 - TMP Phase VI, Step 4 Electrical Detail - Sheet 4 of 4

Electrical and Programming Details For:

Prepared for the Offices of:

Boomerang Drive / Restaurant Driveway

NC 211 (N. Roberts Avenue)

Division 6 Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti PLAN DATE: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm

Trent Moody

3/19/2025 sig. inventory no. 06-1387T3

SEAL 040329


DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202

(704) 372-1885


NC License Number F-0991

750 N. Greenfield Pkwy, Garner, NC 27529



(remove jumpers and set switches as shown)

REMOVE DIODE JUMPERS 1-5, 1-6, 1-9, 1-10, 1-11, 1-15, 2-5, 2-6, 2-9, 2-10, 2-11, 2-15, 3-4, 3-10, 4-10, 5-9, 5-11, 6-9, 6-10, 6-11, 6-15, 9-10, 9-11, 9-15, 10-11, 10-15,



WD ENABLE

15

= DENOTES POSITION OF SWITCH

16 17

PRE = PREEMPT

#### REMOVE JUMPERS AS SHOWN

- 1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- 2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- 3. Ensure that the Red Enable is active at all times during normal operation.
- 4. Integrate monitor with Ethernet network in cabinet.

## NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program controller to start up in phase 2 Green No Walk, 6 Green No Walk, 39 Phase Not On, and 40 Green No Walk.
- 3. Program Phase 39 for No Startup Veh Call
- 4. Program phases 2, 6, and 40 for Min Recall.
- 5. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 6. The cabinet and controller are part of the #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

#### **EQUIPMENT INFORMATION**

| Controller     |         | 2070LX                           |
|----------------|---------|----------------------------------|
| Cabinet        |         | 332 w/ Aux                       |
| Software       | (       | Q-Free MAXTIME                   |
| Cabinet Mount  |         | Base                             |
| Output File Po | sitions | 18 With Aux. Output File         |
| Load Switches  | Used    | S1, S2, S4, S5, S7, S8, S9, S12, |
|                |         | AUX S1, AUX S2, AUX S3, AUX S4   |
| Phases Used    |         | 1, 2, 3, 4, 5, 6, 6PED, 3PED     |
| Overlap "1"    |         | *                                |
| Overlap "2"    |         | *                                |
| Overlap "3"    |         | *                                |
| Overlap "4"    |         | NOT USED                         |
| Overlap "5"    |         | *                                |

\*See overlap programming detail on sheet 2

Overlap "7".....


#### SIGNAL HEAD HOOK-UP CHART S6 S7 S8 S9 S10 S11 S12 AUX S1 S2 AUX AUX AUX S4 S5 S6 LOAD S1 S2 S3 S4 CMU CHANNEL NO. 14 5 6 15 7 8 16 9 10 1 2 13 3 11 | 12 | 18 $\begin{vmatrix} 4 \\ PED \end{vmatrix}$ 5 | 6 $\begin{vmatrix} 6 \\ PED \end{vmatrix}$ 7 | 8 $\begin{vmatrix} 3 \\ PED \end{vmatrix}$ OL1 OL2 OL3 OL4 SPARE 11 21.22 NU 63 41 42 43 NU 51 61,62 P61, NU NU P31, P32 11 63 31 32 51 NU NU NU 101 | 101 RED 128 A124 A111 A111 102 | 102 | **\*** 135 A112 A112 YELLOW 129 A113 A113 130 103 | 103 | GREEN A121 A114 ARROW YELLOW 102 A115 A122 A125 ARROW FLASHING YELLOW A123 A126 A116 ARROW GREEN 127 118 | 103 | 103 133 A113 ARROW 119 110 121 112

NU = Not Used

\*Denotes install load resistor. See load resistor installation detail this sheet. ★See pictorial of head wiring in detail this sheet.

## INPUT FILE POSITION LAYOUT

(front view)



INPUT FILE CONNECTION & PROGRAMMING CHART

| PED PUSH<br>BUTTONS | LOOP<br>TERMINAL | INPUT<br>FILE POS. | PIN<br>NO. | INPUT<br>POINT | DETECTOR<br>NO. | CALL<br>PHASE |                                                |
|---------------------|------------------|--------------------|------------|----------------|-----------------|---------------|------------------------------------------------|
| P61,P62             | TB8-7,9          | I13U               | 68         | 34             | 6               | PED 6         | NOTE:                                          |
| P31,P32             | TB8-8,9          | I13L               | 70         | 36             | 8               | PED 3         | INSTALL DC ISOLATOR<br>IN INPUT FILE SLOT I13. |


INPUT FILE POSITION LEGEND: J2L FILE J SLOT 2 **LOWER** 


#### SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

## FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)





PROJECT REFERENCE NO.

Sig. 18.1


(R)OL2 RED (A124) \* OL2 YELLOW (A125)  $\left(\begin{array}{c} F \\ Y \end{array}\right)$ OL2 GREEN (A126)  $(\rightarrow)$ OL7 GREEN (118)

63

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387 DESIGNED: Feb 2025 SEALED: 3/19/2025 REVISED:

## LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)



\* Reflects the detector utilized in the "MAXTIME DETECTOR PROGRAMMING

DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A" on Sheet 2.

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

STV Engineers, Inc.

900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991

Final Design Electrical Details - Sheet 1 of 4

Prepared for the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

Electrical and Programming Details For:

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway

Division 6 Robeson County Lumberton H.M. Surti Feb 2025 PLAN DATE: REVIEWED BY: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS DATE

Trent Moody

3/19/2025 SIG. INVENTORY NO. 06-1387

SEAL 040329

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

COUNTDOWN PEDESTRIAN SIGNAL OPERATION

#### PED 3 PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Detector >Ped Det Plans

Web Interface

Home >Controller >Detector Configuration >Pedestrian Detector

#### Plan 1

|                    | Detector | Descripton | Call Phase | Call Overlap |
|--------------------|----------|------------|------------|--------------|
|                    | 2        | ·          | 2          | 0            |
| NOTICE PHASE 3 PED | 4        | ·          | 4          | 0            |
| ASSIGNED TO        | 6        | ·          | 6          | 0            |
| DETECTOR 8 PED     | 8        |            | 3          | 0            |

Front Panel

Main Menu >Controller >More>Channels>Channels Config

Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

#### **Channel Configuration**

|                        | Channel | Control Type  | Control Source | Flash Yellow | Flash Red | Flash Alt | MMU Channe |
|------------------------|---------|---------------|----------------|--------------|-----------|-----------|------------|
|                        | 1       | Phase Vehicle | 1              |              | Χ         | X         | 1          |
| NOTE OL7 ASSIGNED      | 2       | Phase Vehicle | 2              |              | X         |           | 2          |
| TO CHANNEL 3           | 3       | Overlap       | 7              |              | X         | Х         | 3          |
|                        | 4       | Phase Vehicle | 4              |              | Х         |           | 4          |
|                        | 5       | Phase Vehicle | 5              |              | Х         |           | 5          |
|                        | 6       | Phase Vehicle | 6              | ·            | Х         | Χ         | 6          |
|                        | 7       | Phase Vehicle | 7              |              | X         |           | 7          |
|                        | 8       | Phase Vehicle | 8              |              | Х         | Χ         | 8          |
|                        | 9       | Overlap       | 1              | ·            | Χ         | Х         | 9          |
|                        | 10      | Overlap       | 2              |              | X         | Χ         | 10         |
|                        | 11      | Overlap       | 3              |              | X         |           | 11         |
|                        | 12      | Overlap       | 4              |              | Х         |           | 12         |
|                        | 13      | Phase Ped     | 2              | ·            | -         |           | 13         |
|                        | 14      | Phase Ped     | 4              |              |           |           | 14         |
| NOTICE PHASE 3 PED     | 15      | Phase Ped     | 6              |              |           |           | 15         |
| ASSIGNED TO CHANNEL 16 | 16      | Phase Ped     | 3              |              |           |           | 16         |
|                        | 17      | Overlap       | 5              |              | Χ         | Х         | 17         |
|                        | 18      | Overlap       | 6              |              | Χ         |           | 18         |

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

#### Overlap Plan 1

| Overlap           | 1               | 2               | 3               | 5       | 7      |
|-------------------|-----------------|-----------------|-----------------|---------|--------|
| Type              | FYA - 4 Section | FYA - 4 Section | FYA - 4 Section | Normal  | Normal |
| Included Phases   | 2               | 6               | 6               | 3       | 4      |
| Modifier Phases   | 1               | 4               | 5               | -       | -      |
| Modifier Overlaps | -               | <u>-</u>        | ÷               | <u></u> | -      |
| Trail Green       | 0               | 0               | 0               | 0       | 0      |
| Trail Yellow      | 0.0             | 0.0             | 0.0             | 0.0     | 0.0    |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0     | 0.0    |

#### SEQUENCE DETAIL

Front Panel

Main Menu >Controller >Sequence & Phs Config>Sequences

Web Interface

Home >Controller >Sequence

#### Sequence 1

| Ring | Sequence Data |
|------|---------------|
| 1    | 1,2,a,3,4,b   |
| 2    | 5,6,a,b       |
| 3    | 39.c.40.d     |

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

#### Overlap Plan 2

|                   |                 |                 |                 |          |        | 1        |
|-------------------|-----------------|-----------------|-----------------|----------|--------|----------|
| Overlap           | 1               | 2               | 3               | 5        | 7      |          |
| Type              | FYA - 4 Section | FYA - 4 Section | FYA - 4 Section | Normal   | Normal | NOTICE   |
| Included Phases   | <u>-</u>        | 6               | -               | 3        | 4      | INCLUDED |
| Modifier Phases   | 1               | 4               | 5               | <u>-</u> | ÷      | PHASE    |
| Modifier Overlaps | <u>-</u>        | <u></u>         | -               | -        | ÷      |          |
| Trail Green       | 0               | 0               | 0               | 0        | 0      |          |
| Trail Yellow      | 0.0             | 0.0             | 0.0             | 0.0      | 0.0    |          |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0      | 0.0    |          |

## MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOPS 1A & 5A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

|    | Detector | Call Phase | Delay    |
|----|----------|------------|----------|
| 1A | 1        | 1          | <u> </u> |
|    | 29       | 0          | ÷        |

|            | Detector | Call Phase | Delay    |
|------------|----------|------------|----------|
| 5 <b>A</b> | 15       | 5          | ÷        |
|            | 31       | 0          | <u> </u> |

## MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

**Unit Flash Parameters** All Red Flash Exit Time

NOTE: ALL RED FLASH

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:** 

Final Design Electrical Details - Sheet 2 of 4

Electrical and Programming Details For:

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway

Prepared for the Offices of: Division 6

Robeson County REVIEWED BY: H.M. Surti Feb 2025 REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm

Trent Moody

SIG. INVENTORY NO. 06-1387

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991

750 N. Greenfield Pkwy, Garner, NC 27529

# PROJECT REFERENCE NO. SHEET NO.

Sig. 18.3

#### PREEMPTION PROGRAMMING

#### Front Panel

Main Menu >Controller >Preemption >Preempt Phasing/Preempt Parameters

#### Web Interface

Home >Controller >Preempt Configuration >Preempts


#### Preempt Configuration

| Preempt                 | 1           |
|-------------------------|-------------|
| Enabled                 | Enabled     |
| Type                    | Rail Road   |
| Track Phases            | 1, 6, 39    |
| Track Overlaps          | 1, 2, 3     |
| Dwell Phases            | 3           |
| Dwell Peds              | <u>-</u>    |
| Dwell Overlaps          | 5           |
| Cycling Phases          | 3, 5        |
| Cycling Peds            | -           |
| Cycling Overlaps        | 3, 5        |
| Exit Phases             | 2, 6        |
| Exit Overlaps           | 1, 2, 3     |
| Delay                   | 0           |
| Call Ext Time           | 1.0         |
| Max Presence            | 0           |
| Max Pres Act            | Terminate   |
| Enter Min Green         | 1           |
| Enter Walk              | 1           |
| Enter Ped Clear         | 4           |
| Enter Yellow Change     | 4.6         |
| Enter Red Clear         | 3.7         |
| Track Green             | 37          |
| Track Yellow Clr        | 4.6         |
| Track Red Clear         | 2.4         |
| Dwell Green             | 7           |
| Exit Min Green          | 255         |
| Exit Yellow Change      | 25.5        |
| Exit Red Clear          | 25.5        |
| Exit Type               | Exit Phases |
| Non Locking Memory      | <u>-</u>    |
| Not Ovrd Flash          | X           |
| Not Ovrd Nxt Pre        | <u> </u>    |
| Require All Red Entry   | -           |
| Track Clear Ovrd        | X           |
| Ped Clear During Yellow | Х           |
| Entry Omit OLTG         | Х           |
| Track Reserve           | Х           |

#### RAILROAD PREEMPTION WIRING DETAIL

(wire as shown below)


#### PREEMPTION AND BLANKOUT SIGN CONTROL BOX



#### **NOTES**


- 1. Relay K1 is shown in the energized (Preempt <u>not</u> active) normal operation state.
- 2. Relay K1 is a DPDT with 120VAC coil with octal base.
- 3. Relay SSR1 is a SPST (normally open) Solid State Relay with AC input and AC (25 amp) output.
- 4. AC Isolator Card shall activate preemption upon removal of AC+ from the input (as shown above). To accomplish this set invert dip switch on AC Isolator Card.
- 5. IMPORTANT!! A jumper must be added between input file terminals J14-E and J14-K if not already present. Also, terminal TB9-12 (on input panel) shall be connected to AC neutral (jumper may have to be added).

#### FRONT VIEW



# PREEMPT 1 AC ISOLATOR (MODEL 252) OUTPUT PROGRAMMING DETAIL

(set DIP switches as shown below)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:** 



Prepared for the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

STV Engineers, Inc.

Charlotte, NC 28202

(704) 372-1885

NC License Number F-0991

900 West Trade St., Suite 715

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway

Robeson County Division 6 Lumberton Feb 2025 REVIEWED BY: H.M. Surti PLAN DATE: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS

Trent Moody DATE

3/19/2025 SIG. INVENTORY NO. 06-1387

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL 040329

PROJECT REFERENCE NO. SHEET NO.

Sig. 18.4

## MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface

Home >Controller >Coordination >Patterns

Pattern Parameters

| attorii ara | 11101010     |              |
|-------------|--------------|--------------|
| Pattern     | Veh Det Plan | Overlap Plan |
| *           | 2            | 2            |

★ The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

## MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

| PHASING                                       | OVERLAP PLAN | VEH DET PLAN |
|-----------------------------------------------|--------------|--------------|
| ACTIVE PLAN REQUIRED TO RUN DEFAULT PHASING   | 1            | 1            |
| ACTIVE PLAN REQUIRED TO RUN ALTERNATE PHASING | 2            | 2            |

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases

for heads 11 and 51 to run protected turns only.

VEH DET PLAN 2: Disables phase 6 call on loop 1A and reduces delay time for phase 1

call on loop 1A to 0 seconds.

Disables phase 2 call on loop 5A and reduces delay time for phase 5 call on loop 5A to 0 seconds.

> THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1387 DESIGNED: Feb 2025 SEALED: 3/19/2025 REVISED:

Final Design Electrical Details - Sheet 4 of 4

Electrical and Programming Details For:

NC 211 (N. Roberts Avenue)

Boomerang Drive / Restaurant Driveway

Division 6 Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991


Prepared for the Offices of:

750 N. Greenfield Pkwy, Garner, NC 27529

3/19/2025 SIG. INVENTORY NO. 06-1387

SEAL 040329

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED



5 Phase Fully Actuated #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road)


PROJECT REFERENCE NO.

U-5797

Sig. 19 (

#### NOTES

- 1. Refer to "Roadway Standard Drawings NCDOT" dated January 2024 and "Standard Specifications for Roads and Structures" dated January 2024.
- 2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- 3. Phase 1 and/or phase 5 may be lagged.
- 4. Set all detector units to presence mode.
- 5. Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- 6. Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- 7. Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- 8. The Divison Traffic Engineer will determine the hours of use for each phasing plan.
- 9. This intersection uses multi-zone microwave detection. Install detectors according to the manufacturer's instructions to achieve the desired detection.
- 10. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.



2.0 30 3.9 2.8

32

\* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds

MAXTIME TIMING CHART

2

10

2.0

3.9

2.3

MIN RECALL

2.0

20

3.0

FEATURE

Ped Clear \*

Min Green

Passage \*

Red Clear

Yellow Change

Added Initial \*

Maximum Initial \*

Time To Reduce \*

Minimum Gap

Advance Walk

Vehicle Recall

**Dual Entry** 

Non Lock Detector

Time Before Reduction

PHASE

\_

7

2.0

30

3.2

3.5

\_

\_

\_

Χ

5

\_

7

2.0

20

3.0

3.2

\_

\_

Χ

6

15

10

2.0

3.9


2.3

MIN RECALL



-L- Sta 52+30±

LT 109'±



81,82

STV Engineers, Inc.

900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991



SCALE

1"=40'

New Installation

Temporary Design - TMP Phase III, Step 3

REVISIONS

SR 1997 (Fayetteville Road) at Boomerang Drive/

Highland Avenue Robeson County Division 6 Lumberton Feb 2025 REVIEWED BY: H.M. Surti 50 N.Greenfield Pkwy, Garner, NC 27529 PREPARED BY: J.C. Grimm REVIEWED BY: T.M. Moody

SIGNATURES COMPLETED SEAL SEAL 040329 INIT. DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL

3/19/202 SIGNATURE SIG. INVENTORY NO. 06-1388T

WD ENABLE (remove jumpers and set switches as shown) REMOVE DIODE JUMPERS 1-3, 1-5, 1-6, 1-9, 1-10, 1-15, 1-17, 2-5, 2-6, 2-9, 2-13, 2-15, 2-17, 3-5, 3-6, 3-9, 3-10, 3-15, 3-17, 4-8, 4-10, 4-16, 5-9, 5-10, 5-13, 6-9, 6-10, 6-13, 6-15, 6-17, 8-10, 8-16, 9-10, 9-13, 9-15, 9-17, 10-15, 10-16,

ON OFF

RP DISABLE

├─ FYA COMPACT

SF#1 POLARITY

- WD 1.0 SEC **GY ENABLE** 

■ LEDguard

RF SSM

FYA 3-10

\_\_\_ 12 <sup>1</sup> 13

14

15

= DENOTES POSITION OF SWITCH

⊅2 PED|Ø6 PED| FS

USED DC DC ISOLATOR ISOLATOR

FS = FLASH SENSE ST = STOP TIME

Ø8 PED ST

FYA 5-11 FYA 7-12

10-17, 13-15, 13-17, and 15-17. COMPONENT SIDE

#### REMOVE JUMPERS AS SHOWN

FILE

FILE

EX.: 1A, 2A, ETC. = LOOP NO.'S

- 1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- 2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- 3. Ensure that the Red Enable is active at all times during normal operation.

INPUT FILE POSITION LAYOUT

(front view)

1 2 3 4 5 6 7 8 9 10 11 12 13 14

4. Integrate monitor with Ethernet network in cabinet.

## NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program phases 4 and 8 for Dual Entry.
- 3. Program controller to start up in phase 2 Green No Walk and 6 Green No Walk.
- 4. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 5. The cabinet and controller are part of the #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

### **EQUIPMENT INFORMATION**

| Controller            | 2070LX                             |
|-----------------------|------------------------------------|
| Cabinet               | 332 w/ Aux                         |
| Software              | Q-Free MAXTIME                     |
| Cabinet Mount         | Base                               |
| Output File Positions | 18 With Aux. Output File           |
| Load Switches Used    | S1, S2, S3, S4, S5, S7, S8, S9     |
|                       | S11, S12, AUX S1, AUX S2, AUX S3   |
| Phases Used           | 1, 2, 2PED, 4, 5, 6, 6PED, 8, 8PED |
| Overlap "1"           | *                                  |
| Overlap "2"           | *                                  |
| Overlap "3"           | NOT USED                           |
| Overlap "4"           | NOT USED                           |
| Overlap "5"           | *                                  |
| Overlap "7"           |                                    |
|                       |                                    |

<sup>\*</sup>See overlap programming detail on sheet 2

#### SIGNAL HEAD HOOK-UP CHART S1 S2 S3 S4 S5 S6 S7 S8 S9 S10 S11 S12 AUX AUX AUX AUX AUX S5 S6 S6 CMU CHANNEL NO. 1 2 13 3 4 14 5 6 15 7 8 16 9 10 17 11 12 18 2 | 2 | OL7 | 4 | 4 | 5 | 6 | 6 | 7 | 8 | 8 | OL1 | OL2 | OL5 | OL3 | OL4 | SPARE $11^{*}$ 21,22 $\frac{P21}{P22}$ $83^{*}$ $\frac{41,42}{43}$ NU 51,52 61,62 $\frac{P61}{P62}$ NU 81,82 $\frac{P81}{P82}$ $11^{*}$ $83^{*}$ $63^{*}$ NU NU NU SIGNAL HEAD NO. RED A124 A111 · \* · 129 **\*** 102 YELLOW GREEN 130 109 RED A121 ARROW YELLOW A122 A125 A112 132 **ARROW** FLASHING A123 A126 A113 YELLOW ARROW **GREEN** 133 118 ARROW 113 110 112 115

**FYA SIGNAL WIRING DETAIL** 

(wire signal heads as shown)

OL2 RED (A124)

OL2 YELLOW (A125)

OL2 GREEN (A126)

OL7 GREEN (118)

U-5797

|Sig. 19.

 $\overline{\mathbb{R}}$ 

\*

63

OL1 RED (A121)

OL1 YELLOW (A122)

OL1 GREEN (A123)

01 GREEN (127)


OL5 RED (A111)

OL5 YELLOW (A112)

OL5 GREEN (A113)

## INPUT FILE CONNECTION & PROGRAMMING CHART

| P21,P22 TB8-4,6 I12U 67 33 2 PED 2 NOTE:  |                        |
|-------------------------------------------|------------------------|
| INIOTA                                    |                        |
|                                           | LL DC ISC<br>UT FILE S |
| P81,P82 TB8-8,9 I13L 70 36 8 PED 8 I12 AN |                        |



#### SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

| PED PUSH<br>BUTTONS | LOOP<br>TERMINAL | INPUT<br>FILE POS. | PIN<br>NO. | INPUT<br>POINT | DETECTOR<br>NO. | CALL<br>PHASE |                                 |
|---------------------|------------------|--------------------|------------|----------------|-----------------|---------------|---------------------------------|
| P21,P22             | TB8-4,6          | I12U               | 67         | 33             | 2               | PED 2         | NOTE:                           |
| P61,P62             | TB8-7,9          | I13U               | 68         | 34             | 6               | PED 6         | INSTALL DC ISO IN INPUT FILE SI |
| P81,P82             | TB8-8,9          | I13L               | 70         | 36             | 8               | PED 8         | 112 AND 113.                    |
|                     |                  |                    |            |                |                 |               |                                 |

# INPUT FILE POSITION LEGEND: J2L LOWER -

LOAD RESISTOR INSTALLATION DETAIL (install resistors as shown)

> Phase 1 Yellow Field Terminal (126)

ACCEPTABLE VALUES Value (ohms) Wattage 1.5K - 1.9K 25W (min) 2.0K - 3.0K | 10W (min)

\* Reflects the detector utilized in the "MAXTIME DETECTOR PROGRAMMING

DETAIL FOR ALTERNATE PHASING LOOP 1A" on Sheet 3.

**OL7 Yellow Field** Terminal (117)

### COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

Temporary Design - TMP Phase III, Step 3 Electrical Detail - Sheet 1 of 3 ELECTRICAL AND PROGRAMMING

SR 1997 (Fayetteville Road) Boomerang Drive/

THIS ELECTRICAL DETAIL IS FOR

THE SIGNAL DESIGN: 06-1388T

DESIGNED: Feb 2025

SEALED: 03/19/2025

**REVISED:** 

Highland Avenue Robeson County Feb 2025 REVIEWED BY: H.M. Surti

Division 6 Lumberton PLAN DATE: REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS INIT. DATE

SE:AL 040329 Trent Moody 03/19/2025

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL

SIGNATURES COMPLETED

SIG. INVENTORY NO. 06-1388T

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991

NU = Not Used

<sup>\*</sup>Denotes install load resistor. See load resistor installation detail this sheet.

<sup>★</sup>See pictorial of head wiring in detail this sheet.

### OUTPUT CHANNEL CONFIGURATION

Front Panel


Main Menu >Controller >More >Channels >Channel Options

Web Interface

TO CHANNEL 3

Home >Controller >Advanced IO >Channels >Channel Configuration

#### **Channel Configuration**





## MAXTIME OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

#### Overlap Plan 1

| 1               | 2                | 5                                                                                                                                   | 7                                                                                                                                                                                                   |
|-----------------|------------------|-------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| FYA - 4 Section | FYA - 4 Section  | FYA - 4 Section                                                                                                                     | Normal                                                                                                                                                                                              |
| 2               | 8                | 6                                                                                                                                   | 1                                                                                                                                                                                                   |
| 1               | 1                | -                                                                                                                                   | -                                                                                                                                                                                                   |
| <u>.</u>        | <u>.</u>         | -                                                                                                                                   | -                                                                                                                                                                                                   |
| 0               | 0                | 0                                                                                                                                   | 0                                                                                                                                                                                                   |
| 0.0             | 0.0              | 0.0                                                                                                                                 | 0.0                                                                                                                                                                                                 |
| 0.0             | 0.0              | 0.0                                                                                                                                 | 0.0                                                                                                                                                                                                 |
|                 | 2<br>1<br>-<br>0 | FYA - 4 Section       FYA - 4 Section         2       8         1       1         -       -         0       0         0.0       0.0 | FYA - 4 Section       FYA - 4 Section       FYA - 4 Section         2       8       6         1       1       -         -       -       -         0       0       0         0.0       0.0       0.0 |

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

#### Overlap Plan 2

| Overlap           | 1               | 2               | 5               | 7        |                       |
|-------------------|-----------------|-----------------|-----------------|----------|-----------------------|
| Type              | FYA - 4 Section | FYA - 4 Section | FYA - 4 Section | Normal   |                       |
| Included Phases   | ÷               | 8               | 6               | 1        | NOTICE INCLUDED PHASE |
| Modifier Phases   | 1               | 1               | <u>-</u>        | <u>-</u> |                       |
| Modifier Overlaps | ÷               | -               | -               | -        |                       |
| Trail Green       | 0               | 0               | 0               | 0        |                       |
| Trail Yellow      | 0.0             | 0.0             | 0.0             | 0.0      |                       |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0      |                       |

## MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

**Unit Flash Parameters** All Red Flash Exit Time

#### FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO ENSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.

2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.

3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1388T DESIGNED: Feb 2025 SEALED: 03/19/2025

**REVISED:** 

Temporary Design - TMP Phase III, Step 3 Electrical Detail - Sheet 2 of 3

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED SR 1997 (Fayetteville Road)

ELECTRICAL AND PROGRAMMING

Boomerang Drive/

Trent Moody 03/19/2025

SE:AL 040329

SIG. INVENTORY NO. 06-1388T

Highland Avenue Robeson County Division 6 REVIEWED BY: H.M. Surti PLAN DATE: Feb 2025 REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS INIT. DATE

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991

## MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOP 1A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

| Detector | Call Phase | Delay |
|----------|------------|-------|
| 1        | 1          | 0     |
| 29       | 0          | 0     |

## MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface Home >Controller >Coordination >Patterns

Pattern Parameters

Pattern Veh Det Plan Overlap Plan

\*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

## MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

| PHASING                                       | OVERLAP PLAN | VEH DET PLAN |
|-----------------------------------------------|--------------|--------------|
| ACTIVE PLAN REQUIRED TO RUN DEFAULT PHASING   | 1            | 1            |
| ACTIVE PLAN REQUIRED TO RUN ALTERNATE PHASING | 2            | 2            |

ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases

for head 11 to run protected turns only.

VEH DET PLAN 2: Disable phase 6 call on loop 1A and reduces delay time for phase 1

call on loop 1A to 0 seconds.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1388T DESIGNED: Feb 2025 SEALED: 03/19/2025 **REVISED:** 

Temporary Design - TMP Phase III, Step 3 Electrical Detail - Sheet 3 of 3

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED SR 1977 (Fayetteville Road)



NC License Number F-0991



PLAN DATE:

Boomerang Drive/ Highland Avenue Robeson County Division 6 Feb 2025

REVIEWED BY: H.M. Surti REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS INIT. DATE

SE:AL 040329

Trent Moody 03/19/2025 SIG. INVENTORY NO. 06-1388T

PROJECT REFERENCE NO. U-5797 Sig. 20 (

5 Phase Fully Actuated #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road)

### NOTES

- 1. Refer to "Roadway Standard Drawings NCDOT" dated January 2024 and "Standard Specifications for Roads and Structures" dated January 2024.
- 2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- 3. Phase 1 and/or phase 5 may be lagged.
- 4. Set all detector units to presence mode.
- 5. Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- 6. Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- 7. The Divison Traffic Engineer will determine the hours of use for each phasing plan.
- 8. This intersection uses multi-zone microwave detection. Install detectors according to the manufacturer's instructions to achieve the desired detection.
- 9. Maximum times shown in timing chart are for free-run operation only. Coordinate signal system timing values supersede these values.

LEGEND

Traffic Signal Head

Modified Signal Head

Pedestrian Signal Head

With Push Button & Sign

Inductive Loop Detector

Controller & Cabinet

Junction Box

2-in Underground Conduit

Right of Way

Directional Arrow

Microwave Detection Zone

Metal Strain Pole

Type II Signal Pedestal

Directional Drill

Pedestrian Crossing Sign (W11-2)

Downward Diagonal Arrow

Plaque (W16-7P)

"U-TURN YIELD TO RIGHT TURN" Sign (R10-16)

**EXISTING** 

N/A

-

N/A

MAXTIME DETECTOR INSTALLATION CHART DETECTOR PROGRAMMING | CALL | DELAY | EXTEND | FROM STOPBAR 1 | 15\*\* - | X | - | X | -6X40 | - | X | - | X | -\* |\*| 1 | 15 | - |X|-|X|-6X40 \* | \* | 4 | 3 | - | X | - | X | -\* | \* | 8 | 3 | - | X | - | X | - | \*

\* Multi-zone Microwave Detection Zone

\*\* Disable Delay During Alternate Phasing

# Disable Phase Call for Loop During Alternate Phasing

RADAR DETECTION SYSTEM SENSOR 1 – (2A) SENSOR 1 – (6A)**FUNCTION** Channel 2 **Direction of Travel** SB NB Detection Zone (ft) 200 – 70 200 - 70 Enable Speed 25 – 100 Speed Range (mph) 25 – 100 **Enable Estimated Time of Arrival** Estimated Time of Arrival (sec) 2.5 - 5.5 2.5 - 5.5

 $<\!\!--\!\!>$  PEDESTRIAN MOVEMENT SR 1997 (Fayetteville Road,

ALTERNATE PHASING DIAGRAM

Ø4+8

Metal Pole #1

Std. Case S35H2

-L- Sta 53+33±

RT 83'±

Ø2+6

Ø2+5

Ø1+6

Ø1+5

35 MPH -1% Grade

8

14

32

2.0

30

3.9

2.8

\_

7

Χ

````\`` (5B) < 21= \_\_\_\_\_\_ -----

DEFAULT PHASING

TABLE OF OPERATION

FACE

21, 22

41, 42, 43

61, 62

63

81, 82

83

P2I, P22

P6I, P62

P8I, P82

PHASE

|DW|W|DW|W|DW|DR

Metal Pole #4 Std. Case S35H2 -L- Sta 53+27± LT 75'±

Metal Pole #3 Std. Case S35H2 Grad -L- Sta 52+10± LT 85'±

ALTERNATE PHASING

TABLE OF OPERATION

SIGNAL

FACE

21, 22

41, 42, 43

61, 62

63

8I, 82

8.3

P2I, P22

P6I, P62

PHASE

DW|DW| W | W |DW|DRI

|DW|W|DW|W|DW|DRK

P81, P82 | DW | DW | DW | DW | DF

Metal Pole #2

RT 73'±

Std. Case S30H2 -L- Sta 52+06±

SR 1997 (Fayetteville Road)

SIGNAL FACE I.D.

All Heads L.E.D.

12" (Y) 12" 21,22 P61,P62 P81,P82 41,42,43 61,62 81,82

Signal Upgrade - Final Design

SR 1997 (Fayetteville Raod) Boomerang Drive/ Highland Avenue

**PROPOSED** 

N/A

Robeson County Division 6 Lumberton Feb 2025 REVIEWED BY: H.M. Surti REVIEWED BY: T.M. Moody J.C. Grimm

SEAL 040329 INIT. DATE Trent Moody 2/10/202 DATE

\* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds

MAXTIME TIMING CHART

7

2.0

30

3.2

3.5

\_

Χ

2

14

14

2.0

70

3.9

2.3

7

\_

MIN RECALL

2.0

20

3.0

3.1

**PHASE** 

5

2.0

20

3.0

3.2

6

2.0

70

3.9

2.3

MIN RECALL

DEFAULT PHASING DIAGRAM

Ø4+8

Ø2+6

Ø2+5

Ø1+6

FEATURE

Ped Clear \*

Passage

Red Clear

Yellow Change

Added Initial \*

Maximum Initial \*

Time To Reduce <sup>1</sup>

Minimum Gap

Advance Walk

Vehicle Recall

Non Lock Detector

Time Before Reduction

PHASING DIAGRAM DETECTION LEGEND

UNSIGNALIZED MOVEMENT

UNDETECTED MOVEMENT (OVERLAP)

DETECTED MOVEMENT

NC License Number F-0991

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

'50 N.Greenfield Pkwy,Garner,NC 27529 PREPARED BY: REVISIONS

SIG. INVENTORY NO. 06-1388

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL

SIGNATURES COMPLETED

SEAL

ATH CAROL

3. Program controller to start up in phase 2 Green No Walk and 6 Green

4. If this signal will be managed by an ATMS software, enable controller

5. The cabinet and controller are part of the #D06-17 Lumberton US 301

#### **EQUIPMENT INFORMATION**

| Controller            | 2070LX                             |
|-----------------------|------------------------------------|
| Cabinet               | 332 w/ Aux                         |
| Software              | Q-Free MAXTIME                     |
| Cabinet Mount         | Base                               |
| Output File Positions | 18 With Aux. Output File           |
| Load Switches Used    | S1, S2, S3, S4, S5, S7, S8, S9     |
|                       | S11, S12, AUX S1, AUX S2, AUX S3   |
| Phases Used           | 1, 2, 2PED, 4, 5, 6, 6PED, 8, 8PED |
| Overlap "1"           | *                                  |
| Overlap "2"           |                                    |
| Overlap "3"           |                                    |
| Overlap "4"           | NOT USED                           |
| Overlap "5"           |                                    |
| Overlap "7"           |                                    |

## NOTES

- 2. Program phases 4 and 8 for Dual Entry.
- No Walk.
- and detector logging for all detectors used at this location.
- and SR 1997 (Fayetteville Road).

| Controller            | .2070LX                            |
|-----------------------|------------------------------------|
| Cabinet               | .332 w/ Aux                        |
| Software              | .Q-Free MAXTIME                    |
| Cabinet Mount         | .Base                              |
| Output File Positions | .18 With Aux. Output File          |
| Load Switches Used    | S1, S2, S3, S4, S5, S7, S8, S9     |
|                       | S11, S12, AUX S1, AUX S2, AUX S3   |
| Phases Used           | 1, 2, 2PED, 4, 5, 6, 6PED, 8, 8PED |
| Overlap "1"           | *                                  |
| Overlap "2"           | *                                  |
| Overlap "3"           | NOT USED                           |
| Overlap "4"           | NOT USED                           |
| Overlap "5"           | *                                  |
| Overlap "7"           |                                    |

\*See overlap programming detail on sheet 2

CMU CHANNEL

HEAD NO.

RED

YELLOW

GREEN

RED

ARROW

YELLOW

**ARROW** FLASHING

YELLOW ARROW

**GREEN** 

ARROW

NU = Not Used

129

130

115

★See pictorial of head wiring in detail this sheet.

\*

**\*** 102

103

\*Denotes install load resistor. See load resistor installation detail this sheet

132

133

## INPUT FILE CONNECTION & PROGRAMMING CHART

| PED PUSH<br>BUTTONS | LOOP<br>TERMINAL | INPUT<br>FILE POS. | PIN<br>NO. | INPUT<br>POINT | DETECTOR<br>NO. | CALL<br>PHASE |                                          |
|---------------------|------------------|--------------------|------------|----------------|-----------------|---------------|------------------------------------------|
| P21;P22             | TB8-4,6          | I12U               | 67         | 33             | 2               | PED 2         | NOTE:                                    |
| P61;P62             | TB8-7,9          | I13U               | 68         | 34             | 6               | PED 6         | INSTALL DC ISOLATORS IN INPUT FILE SLOTS |
| P81;P82             | TB8-8,9          | I13L               | 70         | 36             | 8               | PED 8         | 112 AND 113.                             |

INPUT FILE POSITION LEGEND: J2L FILE J SLOT 2 LOWER

### SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

# (wire signal heads as shown)


**FYA SIGNAL WIRING DETAIL** 

SIGNAL HEAD HOOK-UP CHART

S1 S2 S3 S4 S5 S6 S7 S8 S9 S10 S11 S12 AUX AUX AUX S3 S4 S5 S6

1 2 13 3 4 14 5 6 15 7 8 16 9 10 17 11 12 18

 $11^{*}$  21,22  $\frac{P21}{P22}$   $83^{*}$   $\frac{41,42}{43}$  NU 51,52 61,62  $\frac{P61}{P62}$  NU 81,82  $\frac{P81}{P82}$   $11^{*}$   $83^{*}$   $63^{*}$  NU NU NU



R OL2 RED (A124) OL2 YELLOW (A125) OL2 GREEN (A126) OL7 GREEN (118)


A124 A111

A121

112

A122 A125 A112

A123 A126 A113



THIS ELECTRICAL DETAIL IS FOR

THE SIGNAL DESIGN: 06-1388 DESIGNED: Feb 2025 SEALED: 2/10/2025 **REVISED:** 

Final Design Electrical Detail - Sheet 1 of 3

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

Sig. 20

ELECTRICAL AND PROGRAMMING SR 1997 (Fayetteville Road) Division 6 Feb 2025 PLAN DATE:

Boomerang Drive/ Highland Avenue

Robeson County REVIEWED BY: H.M. Surti REVIEWED BY: T.M. Moody PREPARED BY: J.C. Grimm REVISIONS

SE:AL 040329 Trent Moody 2/10/202

INIT. DATE

# DETAIL FOR ALTERNATE PHASING LOOP 1A" on Sheet 3.

\* Reflects the detector utilized in the "MAXTIME DETECTOR PROGRAMMING

18 CHANNEL IP CONFLICT MONITOR

PROGRAMMING DETAIL

(remove jumpers and set switches as shown)

COMPONENT SIDE

1. Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.

2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.

3. Ensure that the Red Enable is active at all times during normal operation.

INPUT FILE POSITION LAYOUT

 $\emptyset$  1 S S S S S S S S S S S  $\emptyset$  2 PED  $\emptyset$  6 PED FS

2 3 4 5 6 7 8 9 10 11 12 13 14

REMOVE JUMPERS AS SHOWN

4. Integrate monitor with Ethernet network in cabinet.

FILE

FILE

3-5, 3-6, 3-9, 3-10, 3-15, 3-17, 4-8, 4-10, 4-16, 5-9, 5-10, 5-13, 6-9,

REMOVE DIODE JUMPERS 1-3, 1-5, 1-6, 1-9, 1-10, 1-15, 1-17, 2-5, 2-6, 2-9, 2-13, 2-15, 2-17,

10-17, 13-15, 13-17, and 15-17.

ON OFF

RP DISABLE

- WD 1.0 SEC

GY ENABLE

─ FYA COMPACT

LEDguard - RF SSM

FYA 3-10

\_\_\_ 12 **13** 

14

15

= DENOTES POSITION OF SWITCH

DC DC DC ISOLATOR ISOLATOR

NOT SPEI

FS = FLASH SENSE

ST = STOP TIME

Ø8 PED ST

FYA 5-11 FYA 7-12

SF#1 POLARITY

WD ENABLE

#### LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

ACCEPTABLE VALUES Value (ohms) Wattage 1.5K - 1.9K 25W (min) 2.0K - 3.0K | 10W (min)

EX.: 1A, 2A, ETC. = LOOP NO.'S

Phase 1 Yellow Field Terminal (126) OL7 Yellow Field Terminal (117)

#### COUNTDOWN PEDESTRIAN SIGNAL OPERATION

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

> STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991

Lumberton

SIG. INVENTORY NO. 06-1388

#### PROJECT REFERENCE NO. U-5797

# Sig. 20 3

### OUTPUT CHANNEL CONFIGURATION


Front Panel

Main Menu > Controller > More > Channels > Channel Options

Web Interface

Home >Controller >Advanced IO >Channels >Channel Configuration

#### **Channel Configuration**



NOTE: ALL RED FLASH

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

### Overlap Plan 1

| Overlap           | 1               | 2               | 5               | 7      |
|-------------------|-----------------|-----------------|-----------------|--------|
| Туре              | FYA - 4 Section | FYA - 4 Section | FYA - 4 Section | Normal |
| Included Phases   | 2               | 8               | 6               | 1      |
| Modifier Phases   | 1               | 1               | <u>.</u>        | -      |
| Modifier Overlaps | -               | <u>-</u>        | <u>-</u>        | -      |
| Trail Green       | 0               | 0               | 0               | 0      |
| Trail Yellow      | 0.0             | 0.0             | 0.0             | 0.0    |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0    |

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu > Controller > Overlap > Overlap Parameters / Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

#### Overlap Plan 2

| Overlap           | 1               | 2               | 5               | 7        |                       |
|-------------------|-----------------|-----------------|-----------------|----------|-----------------------|
| Туре              | FYA - 4 Section | FYA - 4 Section | FYA - 4 Section | Normal   |                       |
| Included Phases   | <u> </u>        | 8               | 6               | 1        | NOTICE INCLUDED PHASE |
| Modifier Phases   | 1               | 1               | -               | <u> </u> |                       |
| Modifier Overlaps | ÷               | <u>-</u>        | ÷               | <u>-</u> |                       |
| Trail Green       | 0               | 0               | 0               | 0        |                       |
| Trail Yellow      | 0.0             | 0.0             | 0.0             | 0.0      |                       |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0      |                       |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0      |                       |

## MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel Main Menu >Controller >Unit

Web Interface Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters StartUp Clearance Hold **Unit Flash Parameters** All Red Flash Exit Time

## FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO ENSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- 1. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- 2. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1388 DESIGNED: Feb 2025 SEALED: 2/10/2025 **REVISED:** 

Final Design Electrical Detail - Sheet 2 of 3 DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SR 1997 (Fayetteville Road) Division 6 PLAN DATE:

ELECTRICAL AND PROGRAMMING

Boomerang Drive/

REVISIONS

Highland Avenue Robeson County REVIEWED BY: H.M. Surti Feb 2025 REVIEWED BY: T.M. MOOdy PREPARED BY: J.C. Grimm

SE:AL 040329 INIT. DATE Trent Moody

2/10/2025 SIG. INVENTORY NO. 06-1388

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991

## MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOP 1A

Front Panel Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

| 1 1011 2 |            |       |
|----------|------------|-------|
| Detector | Call Phase | Delay |
| 1        | 1          | 0     |
| 29       | 0          | 0     |

## MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Coordination >Patterns

Web Interface

Home >Controller >Coordination >Patterns

Pattern Parameters

| Pattern | Veh Det Plan | Overlap Plan |
|---------|--------------|--------------|
| *       | 2            | 2            |

\*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

## MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

| PHASING                                       | OVERLAP PLAN | VEH DET PLAN |
|-----------------------------------------------|--------------|--------------|
| ACTIVE PLAN REQUIRED TO RUN DEFAULT PHASING   | 1            | 1            |
| ACTIVE PLAN REQUIRED TO RUN ALTERNATE PHASING | 2            | 2            |

#### ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases

for head 11 to run protected turns only.

VEH DET PLAN 2: Disables phase 6 call on loop 1A

and reduces delay time for phase 1 call on loop 1A to 0 seconds.

> THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1388 DESIGNED: Feb 2025 SEALED: 2/10/2025 **REVISED:**

Final Design Electrical Detail - Sheet 3 of 3 ELECTRICAL AND PROGRAMMING

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

STV Engineers, Inc. Charlotte, NC 28202

SR 1977 (Fayetteville Road) Boomerang Drive/ Highland Avenue

REVISIONS

Robeson County Division 6 Lumberton Feb 2025 REVIEWED BY: H.M. Surti PLAN DATE: PREPARED BY: J.C. Grimm REVIEWED BY: T.M. Moody


SE:AL 040329 INIT. DATE

Trent Moody 2/10/2025 SIG. INVENTORY NO. 06-1388


900 West Trade St., Suite 715 (704) 372-1885

NC License Number F-0991

#### DEFAULT PHASING DIAGRAM



## ALTERNATE PHASING DIAGRAM



#### PHASING DIAGRAM DETECTION LEGEND

DETECTED MOVEMENT UNDETECTED MOVEMENT (OVERLAP) UNSIGNALIZED MOVEMENT  $\leftarrow$  - > PEDESTRIAN MOVEMENT

PHASE

2.0

20

3.0

3.0

10

2.0

90

3.8

1.0


MIN RECALL

DEFAULT PHASING TABLE OF OPERATION PHASE SIGNAL FACE 31 61,62

| ALTERN                   | ATE  | PH  | ASI | NG          |
|--------------------------|------|-----|-----|-------------|
| TABLE                    | 0F 0 | PER | ATI | ON          |
|                          |      | Р   | HAS | E           |
| SIGN <sub>i</sub><br>FAC | · -  | Ø3  | Ø 6 | エコ母のエ       |
| 31                       |      |     | R   | ₽R          |
| 32                       |      | •   | *   | <del></del> |
| 61, 6                    | 2    | R   | G   | R           |

## SIGNAL FACE I.D.

All Heads L.E.D.



| 31 | 3 |
|----|---|
|    |   |

| MAXTIME DETECTOR INSTALLATION CHART |      |       |               |               |                |        |               |      |                    |          |   |   |
|-------------------------------------|------|-------|---------------|---------------|----------------|--------|---------------|------|--------------------|----------|---|---|
|                                     | DET  | ECTOR |               |               |                | PRO    | GRAMM         | IN   | G                  |          |   |   |
| LOOP SIZE FROM STOPBAR (FT) TURNS   |      |       | CALL<br>PHASE | DELAY<br>TIME | EXTEND<br>TIME | EXTEND | ADDED INITIAL | CALL | DELAY DURING GREEN | NEW CARD |   |   |
| 3A                                  | 6X40 | 0     | *             | *             | 3              | 15**   | -             | Χ    | -                  | Χ        | - | * |

- \* Multi-zone Microwave Detection Zone
- \*\* Disable Delay During Alternate Phasing

| RADAR DETECTION<br>SYSTEM        |                 |  |  |  |
|----------------------------------|-----------------|--|--|--|
| FUNCTION                         | SENSOR 1 – (6A) |  |  |  |
| Channel                          | 1               |  |  |  |
| Phase                            | 2               |  |  |  |
| Direction of Travel              | EB              |  |  |  |
| Detection Zone (ft)              | 200 – 70        |  |  |  |
| Enable Speed                     | Y               |  |  |  |
| Speed Range (mph)                | 25 – 100        |  |  |  |
| Enable Estimated Time of Arrival | Y               |  |  |  |
| Estimated Time of Arrival (sec)  | 2.5 - 5.5       |  |  |  |

-L- Sta. 54+65± RT 61'± Pole Mounted Cabinet --L- Sta. 54+89± RT 63'± 35 MPH 1% Grade \_\_\_\_\_\_ 35 MPH -1% Grade SR 1997 (Fayetteville Road)

#### 2 Phase Fully Actuated #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road)

### NOTES

- 1. Refer to "Roadway Standard Drawings NCDOT" dated January 2024 and "Standard Specifications for Roads and Structures" dated January 2024.
- 2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- 3. Set all detector units to presence mode.
- 4. Locate new cabinet so as not to obstruct sight distance of vehicles turning right on red.
- 5. This intersection uses multi-zone microwave detection. Install detectors according to the manufacturer's instructions to achieve the desired detection.
- 6. The Division Traffic Engineer will determine the hours of use for each phasing plan.
- 7. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.

#### LEGEND <u>EXISTING</u> **PROPOSED** Traffic Signal Head Modified Signal Head Signal Pole with Guy Signal Pole with Sidewalk Guy Inductive Loop Detector Controller & Cabinet Junction Box ----- 2-in Underground Conduit N/A Right of Way Directional Arrow Microwave Detection Zone Construction Zone

No U-turn/No Left Turn

Sign (R3-18)

New Installation Temporary Design - TMP Phase III, Step 1

SR 1997 (Fayetteville Road) Division 6 Robeson County

Boomerang Drive Temporary U-Turn South Lumberton Feb 2025 REVIEWED BY: H.M. Surti 750 N.Greenfield Pkwy.Garner.NC 27529 PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody INIT. DATE

FINAL UNLESS ALL SIGNATURES COMPLETED SEAL TH CAROL!

DOCUMENT NOT CONSIDERED

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 than what is shown. Min Green for all other phases (704) 372-1885 should not be lower than 4 seconds. NC License Number F-0991

MAXTIME TIMING CHART FEATURE Ped Clear \* Min Green Passage \* Max 1 \* Yellow Change Red Clear Added Initial \* Maximum Initial \* Time Before Reduction Time To Reduce \* Minimum Gap Advance Walk Non Lock Detector Vehicle Recall **Dual Entry** 

1"=40'

Trent Moody 2/10/202 DATE


SIG. INVENTORY NO.


(remove jumpers and set switches as shown)

Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.

2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.


Special cabinet wiring is required to utilize FYA COMPACT mode.
 See Ped Yellow Conflict Monitor Wiring Detail on this sheet.





= DENOTES POSITION OF SWITCH

ST = STOP TIME



## **NOTES**

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program controller to start up in phase 6 Green No Walk.
- 3. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 4. The cabinet and controller are part of the Signal System #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

### **EQUIPMENT INFORMATION**

| Controller                           | 2070LX             |
|--------------------------------------|--------------------|
| Cabinet                              | 336                |
| Software                             | .Q-Free MAXTIME    |
| Cabinet Mount                        | Pole               |
| Output File Positions                | .12                |
| Load Switches Used                   | S1, S3, S4, S6, S8 |
| Phases Used                          | 1, 2, 3, 6         |
| Overlap "1"                          | *                  |
| Overlap "2"                          | *                  |
| Overlap "3"                          | NOT USED           |
| Overlap "4"                          | NOT USED           |
|                                      |                    |
| *See overlap programming detail on s | sheet 2            |
|                                      |                    |

| SIGNAL HEAD HOOK-UP CHART   |                |    |                 |          |                |          |             |          |      |       |          |     |     |          |
|-----------------------------|----------------|----|-----------------|----------|----------------|----------|-------------|----------|------|-------|----------|-----|-----|----------|
| LOAD<br>SWITCH NO.          | S1             | S2 | S               | 3        | S4             | S4 S5 S6 |             | 6        | S S7 |       | S9       | S10 | S11 | S12      |
| CMU<br>CHANNEL<br>NO.       | 1              | 2  | 9               | 13       | 3              | 4        | 10          | 14       | 5    | 6     | 15       | 7   | 8   | 16       |
| PHASE                       | OL1            | 2  | 3 GRN           | 2<br>PED | OL2            | 4        | 3 GRN       | 4<br>PED | 5    | 6     | 6<br>PED | 7   | 8   | 8<br>PED |
| SIGNAL<br>HEAD NO.          | <b>★</b><br>32 | NU | 32 <sup>*</sup> | NU       | <b>★</b><br>31 | NU       | <b>★</b> 31 | NU       | NU   | 61,62 | NU       | NU  | NU  | Ŋ        |
| RED                         |                |    |                 |          |                |          |             |          |      | 134   |          |     |     |          |
| YELLOW                      |                |    |                 |          |                |          |             | -        | ·    | 135   |          |     |     |          |
| GREEN                       |                | ,  |                 |          |                |          |             |          |      | 136   |          |     |     |          |
| RED<br>ARROW                | 125            |    |                 |          | 116            |          |             |          |      |       |          |     |     |          |
| YELLOW<br>ARROW             | 126            |    |                 |          | 117            |          |             |          | ,    |       |          |     |     |          |
| FLASHING<br>YELLOW<br>ARROW | 127            |    |                 |          | 118            |          |             |          |      |       |          |     |     |          |
| *                           |                |    | -               |          |                |          |             | ٠        |      |       |          |     |     |          |
| GREEN<br>ARROW              |                |    | 114             |          |                |          | 105         |          |      |       |          |     |     |          |
|                             |                |    |                 |          |                |          |             |          |      |       |          |     |     |          |

PROJECT REFERENCE NO.

U-5797


Sig. 21.

NU = Not Used

★See pictorial of head wiring in detail this sheet.

## INPUT FILE POSITION LAYOUT

(front view)



\* Reflects the detector utilized in the "MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOP 3A" on Sheet 3.


## LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

Phase 2 Walk Field Terminal (115) Phase 4 Walk Field Terminal (106) ACCEPTABLE VALUES Value (ohms) Wattage 1.5K - 1.9K 25W (min) 2.0K - 3.0K 10W (min) AC-

## FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1415T DESIGNED: Feb 2025 SEALED 2/10/2025 **REVISED:** 

#### SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

> Temporary Design - TMP Phase III, Step 1 Electrical Detail - Sheet 1 of 3

ELECTRICAL AND PROGRAMMING SR 1997 (Fayetteville Road) Boomerang Drive

Temporary U-Turn South Robeson County Division 6 Lumberton Feb 2025 REVIEWED BY: H.M. Surti PLAN DATE: PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS INIT. DATE

TH CAROL

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL

SIGNATURES COMPLETED

750 N.Greenfield Pkwy,Garner,NC 27529

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991

Trent Moody \_ 2/10/2025 DATE SIG. INVENTORY NO. 06-1415T

NOTES:

<sup>\*</sup>Denotes install load resistor. See load resistor installation detail this sheet.

#### U-5797 Sig. 21.

#### **OUTPUT CHANNEL CONFIGURATION**

Front Panel

Main Menu >Controller >More>Channels>Channels Config

Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

#### Channel Configuration

|                   | Channel | Control Type  | Control Source | Flash Yellow | Flash Red | Flash Alt | MMU Channel |
|-------------------|---------|---------------|----------------|--------------|-----------|-----------|-------------|
| NOTE OL1 ASSIGNED | 1       | Overlap       | 1              | ·            | Х         | Х         | 1           |
| TO CHANNEL 1      | 2       | Phase Vehicle | 2              | ·            | Х         |           | 2           |
| NOTE OL2 ASSIGNED | 3       | Overlap       | 2              | ·            | Х         | Х         | 3           |
| TO CHANNEL 3      | 4       | Phase Vehicle | 4              |              | Х         |           | 4           |
|                   | 5       | Phase Vehicle | 5              | ·            | Х         |           | 5           |
|                   | 6       | Phase Vehicle | 6              | ·            | Х         | X         | 6           |
|                   | 7       | Phase Vehicle | 7              |              | Х         |           | 7           |
|                   | 8       | Phase Vehicle | 8              | ·            | Х         | X         | 8           |
|                   | 9       | Overlap       | 1              | ·            | Х         | Х         | 9           |
|                   | 10      | Overlap       | 2              | ·            | Х         | Х         | 10          |
|                   | 11      | Overlap       | 3              | ·            | Х         |           | 11          |
|                   | 12      | Overlap       | 4              | ·            | Х         |           | 12          |
|                   | 13      | Phase Ped     | 2              | ·            |           |           | 13          |
|                   | 14      | Phase Ped     | 4              | ·            | ·         |           | 14          |
|                   | 15      | Phase Ped     | 6              | ·            | ·         |           | 15          |
|                   | 16      | Phase Ped     | 8              | ·            |           |           | 16          |
|                   | 17      | Overlap       | 5              | ·            | Х         | Χ         | 17          |
|                   | 18      | Overlap       | 6              | ·            | Х         |           | 18          |



#### MAXTIME OVERLAP PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

#### Overlap Plan 1

| 1               | 2                       |  |  |  |  |
|-----------------|-------------------------|--|--|--|--|
| FYA 4 - Section | FYA 4 - Section         |  |  |  |  |
| 6               | 6                       |  |  |  |  |
| 3               | 3                       |  |  |  |  |
| <u>.</u>        | -                       |  |  |  |  |
| 0               | 0                       |  |  |  |  |
| 0.0             | 0:0                     |  |  |  |  |
| 0.0             | 0.0                     |  |  |  |  |
|                 | 6<br>3<br>-<br>0<br>0.0 |  |  |  |  |

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

#### Overlap Plan 2

| •                 |                 |                 |   |
|-------------------|-----------------|-----------------|---|
| Overlap           | 1               | 2               |   |
| Туре              | FYA 4 - Section | FYA 4 - Section |   |
| Included Phases   | ÷               | 4               | + |
| Modifier Phases   | 3               | 3               |   |
| Modifier Overlaps | 4               | 4               |   |
| Trail Green       | 0               | 0               |   |
| Trail Yellow      | 0:0             | 0:0             |   |
| Trail Red         | 0.0             | 0:0             |   |
|                   |                 |                 |   |

NOTICE INCLUDED PHASES ON OL1 AND OL2

## MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

Unit Flash Parameters

All Red Flash Exit Time

# FYA SIGNAL OUTPUT REMAPPING ASSIGNMENT PROGRAMMING DETAIL FOR SIGNAL HEADS 31&32

Front Panel

Main Menu >Controller >More >Advanced IO >Output Points

Web Interface

Home >Controller >Advanced IO >Cabinet Configuration >Output Points

#### IO Module 1

|                     |            | Output Point | Descripton | Output Control Type | Index |
|---------------------|------------|--------------|------------|---------------------|-------|
| NOTICE              | <b>→</b> [ | 33           | C1-35      | Phase Green         | 3     |
| OUTPUT<br>REMAPPING |            | 34           | C1-36      | Not Active          | ·     |
| INCIMAL LING        | → [        | 35           | C1-37      | Phase Green         | 3     |
|                     |            | 36           | C1-38      | Not Active          | ·     |

## SEQUENCE DETAIL

Front Panel

Main Menu >Controller >Sequence & Phs Config>Sequences

Web Interface

Home >Controller >Sequence

#### Sequence 1

| Ring | Sequence Data |
|------|---------------|
| 1    | 6,a,3,b       |
| 2    | -             |

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1415T DESIGNED: Feb 2025 SEALED: 2/10/2025 **REVISED:** 

Temporary Design - TMP Phase III, Step 1 Electrical Detail - Sheet 2 of 3

ELECTRICAL AND PROGRAMMING

# SR 1997 (Fayetteville Road) Boomerang Drive

Temporary U-Turn South Robeson County PLAN DATE: Feb 2025 REVIEWED BY: H.M. Surti

Lumberton INIT. DATE

Trent Moody SIG. INVENTORY NO. 06-1415T

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991

750 N.Greenfield Pkwy, Garner, NC 27529

Division 6 PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

#### PROJECT REFERENCE NO. U-5797 Sig. 21.

# PED YELLOW CONFLICT MONITOR WIRING DETAIL

(make cabinet wiring changes as shown below)

In order to use FYA COMPACT mode with the 16 or 18 Channel Monitor, the cabinet must be wired such that the (unused) Ped Yellow load switch outputs are wired to the conflict monitor as follows: From 2 PY (field term. 114) to chan. 9 green (monitor pin 13), from 4 PY (field term. 105) to chan. 9 yellow (monitor pin 16).

Follow the instructions below to make appropriate connections:

STEP 1: Fold down rear panel of output file.

STEP 2: Find unused wiring harness fom conflict monitor card edge connector (which should be tied and bundled together).

STEP 3: Find the connector that correspond to the folloeing conflict monitor card edge pins and solder wire the appropriate

terminal on the rear of the output file shown below:

CMU-13 -----2PY (term. 114) CMU-16 -----4PY (term. 105)

Some cabinet manufacturers use keyed connectors to accomplish

this wiring configuration. If connectors are used, fold down the rear panel of the output file and find the set of 3 keyed connectors

and connect them as shown below:

| 1 - 2PY             |  | 1- CMU-13                |
|---------------------|--|--------------------------|
| 2 - 4PY<br>3 - 6PY  |  | 2- CMU-16<br>3- CMU-R    |
| 3 - 6P 1<br>4 - 8PY |  | 3- CMU-R  <br>  4- CMU-U |
| 4 - 8PY             |  | 4- CMU-U                 |

#### MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

| OVERLAP PLAN | VEH DET PLAN      |
|--------------|-------------------|
| 1            | 1                 |
| 2            | 2                 |
|              | OVERLAP PLAN  1 2 |

#### ALTERNATE PHASING CHANGE SUMMARY

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE TO CALL THE "ALTERNATE PHASING":

OVERLAP PLAN 2: Modifies overlap included phases

for heads 31, and 32 to run protected turns only.

VEH DET PLAN 2: Reduces delay time for phase 3

call on loop 3A to 0 seconds.

## MAXTIME ALTERNATE PHASING PATTERN PROGRAMMING DETAIL

Front Panel Main Menu >Controller >Coordination >Patterns

Web Interface Home >Controller >Coordination >Patterns

Pattern Parameters

| attorri ara | 11101010     |              |
|-------------|--------------|--------------|
| Pattern     | Veh Det Plan | Overlap Plan |
| *           | 2            | 2            |

\*The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

## MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOP 3A

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

Call Phase Detector Delay 3

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-1415T DESIGNED: Feb 2025 SEALED 2/10/2025 **REVISED:** 

Temporary Design - TMP Phase III, Step 1 Electrical Detail - Sheet 3 of 3

ELECTRICAL AND PROGRAMMING SR 1997 (Fayetteville Road)

Boomerang Drive Temporary U-Turn South Robeson County

Lumberton PLAN DATE: Feb 2025 REVIEWED BY: H.M. Surti PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS INIT. DATE

Trent Moody


DOCUMENT NOT CONSIDERED FINAL UNLESS ALL

SIGNATURES COMPLETED

STV Engineers, Inc.
900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991

750 N.Greenfield Pkwy,Garner,NC 27529

SIG. INVENTORY NO. 06-1415T




Sig. 22.0

1"=40'

03/19/2025 SIG. INVENTORY NO. 06-0537]

#### 18 CHANNEL CONFLICT MONITOR PROGRAMMING DETAIL

(remove jumpers and set switches as shown)



- Card is provided with all diode jumpers in place. Removal of any jumper allows its channels to run concurrently.
- 2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.
- 3. Ensure that the Red Enable is active at all times during normal operation.
- 4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

### NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program controller to start up in phase 2 Green No Walk and phase 6 Green No Walk.
- 3. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 4. The cabinet and controller are part of the Signal System #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

## **EQUIPMENT INFORMATION**

| Controller            | 2070LX                   |
|-----------------------|--------------------------|
| Cabinet               | 332 w/ Aux               |
| Software              | Q-Free MAXTIME           |
| Cabinet Mount         | Base                     |
| Output File Positions | 18 With Aux. Output File |
| Load Switches Used    | S1, S2, S4, S6, S7, S8,  |
|                       | AUX S1                   |
| Phases Used           | 2, 3, **4, 4PED, 5, 6    |
| Overlap "1"           | *                        |
| Overlap "2"           | NOT USED                 |
| Overlap "3"           | NOT USED                 |
| Overlap "4"           | NOT USED                 |
| Overlap "7"           | *                        |
| Overlan "8"           | *                        |

<sup>\*</sup>See overlap programming detail on sheet 2


#### PROJECT REFERENCE NO. Sig. 22 U-5797

|                             | SIGNAL HEAD HOOK-UP CHART |       |          |       |    |            |     |       |          |     |     |          |             |           |           |           |           |           |
|-----------------------------|---------------------------|-------|----------|-------|----|------------|-----|-------|----------|-----|-----|----------|-------------|-----------|-----------|-----------|-----------|-----------|
| LOAD<br>SWITCH NO.          | S1                        | S2    | S3       | S4    | S5 | S6         | S7  | S8    | S9       | S10 | S11 | S12      | AUX<br>S1   | AUX<br>S2 | AUX<br>S3 | AUX<br>S4 | AUX<br>S5 | AUX<br>S6 |
| CMU<br>CHANNEL<br>NO.       | 1                         | 2     | 13       | 3     | 4  | 14         | 5   | 6     | 15       | 7   | 8   | 16       | 9           | 10        | 17        | 11        | 12        | 18        |
| PHASE                       | OL7                       | 2     | 2<br>PED | 3     | 4  | 4<br>PED   | OL8 | 6     | 6<br>PED | 7   | 8   | 8<br>PED | OL1         | OL2       | SPARE     | OL3       | OL4       | SPARE     |
| SIGNAL<br>HEAD NO.          | <b>★</b> 33               | 21,22 | NU       | 31,32 | NU | P41<br>P42 | 51  | 61,62 | NU       | NU  | NU  | NU       | <b>★</b> 33 | NU        | NU        | NU        | NU        | NU        |
| RED                         |                           | 128   | ·        |       |    |            |     | 134   |          | ·   |     |          | A121        |           |           |           |           |           |
| YELLOW                      | *                         | 129   |          |       |    |            |     | 135   |          | ·   |     |          |             |           |           |           |           |           |
| GREEN                       | -                         | 130   |          |       |    |            | ·   | 136   | ·        |     |     |          |             |           |           |           |           |           |
| RED<br>ARROW                |                           |       |          | 116   |    |            | 131 |       |          |     |     |          |             |           |           |           |           |           |
| YELLOW<br>ARROW             | -                         |       |          | 117   |    | -          | 132 |       |          |     |     | ·        | A122        |           |           |           | -         |           |
| FLASHING<br>YELLOW<br>ARROW | -                         |       | ·        |       |    |            |     |       | -        | ·   |     |          | A123        | -         |           |           |           |           |
| GREEN<br>ARROW              | 127                       |       |          | 118   | ·  |            | 133 |       |          | ·   |     |          |             |           |           |           |           |           |
| ₩                           | -                         |       |          |       |    | 104        |     |       |          | ·   |     |          |             | -         |           |           |           |           |
| Ķ                           |                           |       |          |       |    | 106        |     |       |          | ·   |     |          |             |           |           |           |           |           |

NU = Not Used

## INPUT FILE POSITION LAYOUT

(front view)



FS = FLASH SENSE ST = STOP TIME

ON OFF

= DENOTES POSITION OF SWITCH

WD ENABLE \

## SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.


#### INPUT FILE CONNECTION & PROGRAMMING CHART

| LOOP NO.            | LOOP<br>TERMINAL | INPUT<br>FILE POS.  | PIN<br>NO. | INPUT<br>POINT | DETECTOR<br>NO. | CALL<br>PHASE |                                             |
|---------------------|------------------|---------------------|------------|----------------|-----------------|---------------|---------------------------------------------|
| PED PUSH<br>BUTTONS |                  |                     |            |                |                 |               |                                             |
| P41,P42             | TB8-5,6          | I12L                | 69         | 35             | 4               | PED 4         | NOTE:                                       |
|                     |                  |                     |            |                |                 |               | INSTALL DC ISOLATOR IN INPUT FILE SLOT 112. |
|                     | INPUT FILE       | POSITION            | I LEG      | END: J2        | Ļ               |               |                                             |
|                     |                  | ILE J ——<br>OT 2 —— |            |                |                 |               |                                             |

## LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)


LOWER -



**OL7 Yellow Field** Terminal (126)

#### FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



33

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0537T1 DESIGNED: Feb 2025 **SEALED:** 3/19/2025 REVISED:

|Temporary Design 1 - TMP Phase I Electrical Detail - Sheet 1 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared for the Offices of:

SR 1997 (Fayetteville Road) SR 1984 (Linkhaw Road)

Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS INIT. DATE

SEAL SEAL 040329

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL

SIGNATURES COMPLETED

3/19/2025 SIG. INVENTORY NO. 06-0537T1

STV Engineers, Inc. 900 West Trade St., Suite 715

Charlotte, NC 28202

(704) 372-1885 NC License Number F-0991

<sup>\*\*</sup>Phase used for timing purposes

<sup>\*</sup>Denotes install load resistor. See load resistor installation detail this sheet.

<sup>★</sup> See pictorial of head wiring in detail this sheet.

## **OUTPUT CHANNEL CONFIGURATION**

Front Panel

Main Menu >Controller >More >Channels >Channel Options

Web Interface

Home >Controller >Advanced IO >Channels >Channel Configuration

#### **Channel Configuration**

| NOTICE OL7<br>ASSIGNED TO | Channel | Control Type  | Control Source | Flash Yellow | Flash Red | Flash Alt | MMU Channel |
|---------------------------|---------|---------------|----------------|--------------|-----------|-----------|-------------|
| CHANNEL 1                 | 1       | Overlap       | 7              |              | X         | X         | 1           |
|                           | 2       | Phase Vehicle | 2              |              | X         |           | 2           |
| NOTICE OL8                | 3       | Phase Vehicle | 3              |              | X         | Х         | 3           |
| ASSIGNED TO               | 4       | Phase Vehicle | 4              |              | Х         |           | 4           |
| CHANNEL 5                 | 5       | Overlap       | 8              |              | X         |           | 5           |
|                           | 6       | Phase Vehicle | 6              |              | Х         | Х         | 6           |
|                           | 7       | Phase Vehicle | 7              |              | Х         |           | 7           |
|                           | 8       | Phase Vehicle | 8              |              | X         | X         | 8           |
|                           | 9       | Overlap       | 1              |              | X         | X         | 9           |
|                           | 10      | Overlap       | 2              |              | Х         | X         | 10          |
|                           | 11      | Overlap       | 3              |              | X         |           | 11          |
|                           | 12      | Overlap       | 4              |              | X         |           | 12          |
|                           | 13      | Phase Ped     | 2              |              |           |           | 13          |
|                           | 14      | Phase Ped     | 4              |              |           |           | 14          |
|                           | 15      | Phase Ped     | 6              |              |           |           | 15          |
|                           | 16      | Phase Ped     | 8              |              |           |           | 16          |
|                           | 17      | Overlap       | 5              |              | Х         | X         | 17          |
|                           | 18      | Overlap       | 6              |              | Х         |           | 18          |



NOTE: ALL RED FLASH

## MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

Unit Flash Parameters

All Red Flash Exit Time

## MAXTIME OVERLAP PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

#### Overlap Plan 1

| Overlap           | 1               | 7        | 8        |
|-------------------|-----------------|----------|----------|
| Туре              | FYA 4 - Section | Normal   | Normal   |
| Included Phases   | 3               | 4,5      | 4,5      |
| Modifier Phases   | 4,5             | <u>-</u> | <u>-</u> |
| Modifier Overlaps | ±               | 4        | ÷        |
| Trail Green       | 0               | 0        | 0        |
| Trail Yellow      | 0:0             | 0.0      | 0.0      |
| Trail Red         | 0:0             | 0.0      | 0.0      |

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0537T1 DESIGNED: Feb 2025 SEALED: 03/19/2025 **REVISED:** 

Temporary Design 1 - TMP Phase I Electrical Detail - Sheet 2 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared for the Offices of:

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED SR 1997 (Fayetteville Road)

SR 1984 (Linkhaw Road) SEAL 040329 Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody

Trent Moody 03/19/2025

REVISIONS INIT. DATE SIG. INVENTORY NO. 06-0537T1

Charlotte, NC 28202

STV Engineers, Inc. 900 West Trade St., Suite 715

(704) 372-1885 NC License Number F-0991

750 N.Greenfield Pkwy,Garner,NC 27529

## 3 Phase Fully Actuated Signal System #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road)

## NOTES

- 1. Refer to "Roadway Standard Drawings NCDOT" dated January 2024 and "Standard Specifications for Roads and Structures" dated January 2024.
- 2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- 3. Phase 5 may be lagged.
- 4. Set all detector units to presence mode.
- 5. Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- 6. Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- 7. Pavement markings are existing.
- 8. This intersection uses video detection. Install detectors according to the manufacturer's instructions to achieve the desired detection.
- 9. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- 10. Bag and disconnect existing pedestrian signal head numbered P41.

#### LEGEND **EXISTING PROPOSED** Traffic Signal Head **-**Modified Signal Head Pedestrian Signal Head With Push Button & Sign Signal Pole with Guy Metal Strain Pole Inductive Loop Detector Controller & Cabinet Junction Box 2-in Underground Conduit Directional Drill N/A N/A Right of Way \_\_\_\_\_ Directional Arrow Type II Signal Pedestal Curb Ramp Guardrail

Construction Zone Pedestrian Barricade

Portable Barrier Temporary Shoring

Microwave Detection Zone

Signal Upgrade Temporary Design 2 - TMP Phase II, Step 3

Prepared for the Offices of:

1"=40'

SR 1997 (Fayetteville Road) SR 1984 (Linkhaw Road)

Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti 750 N.Greenfield Pkwy,Garner,NC 27529 PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS INIT. DATE

TH CAROL

Trent Moody 03/19/2025 SIG. INVENTORY NO. 06-0537T


XYZ

~~~~


DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL



Disconnect & Bag (See Note 10)



SR 1997 (Fayetteville Road)	P61	P62	(See Note 10)	45 MPH -1% Grade		
		21		— — — — — — — — — — — — — — — — — — —	SCH00H3S	
45 MPH -1% Grade	33 32 31					

MAXTIME TIMING CHART											
FFATURE		PHASE									
FEATURE	2	3	5	6							
Walk *	_	-	_	14							
Ped Clear *	_	-	_	22							
Min Green	12	7	7	12							
Passage *	2.0	2.0	2.0	2.0							
Max 1 *	90	30	20	90							
Yellow Change	4.6	3.0	3.0	4.6							
Red Clear	1.7	3.3	2.9	1.7							
Added Initial *	_	_	_	_							
Maximum Initial *	_	_	_	_							
Time Before Reduction *	-	_	_	_							
Time To Reduce *	_	_	_	_							
Minimum Gap	_	_	_	_							
Advance Walk	_	_	_	7							
Non Lock Detector	_	Х	Х	_							
Vehicle Recall	MIN RECALL	_	_	MIN RECALL							
Dual Entry	_	-	_	_							

PHASING DIAGRAM

Ø2+6

SIGNAL

FACE

2I**,** 22


31**,** 32

61, 62

6.3

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991



NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program controller to start up in phase 2 Green No Walk and phase 6 Green No Walk.
- 3. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 4. The cabinet and controller are part of the Signal System #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

EQUIPMENT INFORMATION

Controller	2070LX
Cabinet	332 w/ Aux
Software	Q-Free MAXTIME
Cabinet Mount	Base
Output File Positions	18 With Aux. Output File
Load Switches Used	S1, S2, S4, S7, S8, S9, S11
	AUX S1, AUX S2
Phases Used	2, 3, 5, 6, 6PED
Overlap "1"	*
Overlap "2"	
Overlap "3"	
Overlap "4"	NOT USED
Overlap "7"	
Overlap "8"	*

*See overlap programming detail on sheet 2

Sig. 23 U-5797

				S	SIGI	٧AL	HE	EAD	НО	OK	-UP	CH	IAR	Т				
LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	OL7	2	2 PED	3	4	4 PED	5	6	6 PED	7	OL8	8 PED	OL1		SPARE	OL3	OL4	SPARE
SIGNAL HEAD NO.	★ 33	21,22	NU	63 [*]	NU	NU	51	61,62	P61 P62	NU	31,32	NU	33 ★	63 [*]	NU	NU	NU	NU
RED		128						134					A121	A124				
YELLOW	*	129		*				135					-					
GREEN		130					·	136			-		-				٠	
RED ARROW							131				116							
YELLOW ARROW	·		-				132	-			117		A122	A125		-		
FLASHING YELLOW ARROW	·							-					A123	A126				
GREEN ARROW	127			118			133				118							
*	·		-			-	·	-	119	·		·	-	·				
×									121									
		1				ı		1		ı	1	1	ı	1		1	ı	

NU = Not Used

- *Denotes install load resistor. See load resistor installation detail this sheet
- ★ See pictorial of head wiring in detail this sheet.

OL1 RED (A121) -


OL1 YELLOW (A122)

OL1 GREEN (A123) -

OL7 GREEN (127)

INPUT FILE POSITION LAYOUT

(front view)



2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.

3. Ensure that the Red Enable is active at all times during normal operation.

4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

FS = FLASH SENSE ST = STOP TIME

= DENOTES POSITION OF SWITCH

ON

SPECIAL DETECTOR NOTE


Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.	INPUT POINT	DETECTOR NO.	CALL PHASE	
PED PUSH BUTTONS							
P61;P62	TB8-7,9	I13U	68	34	6	PED 6	NOTE:
	SL	E POSITION ILE J —— OT 2 —— WER ——	I LEG	END: J2	L 		INSTALL DC ISOLATOR IN INPUT FILE SLOT I13.

LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0537T2 DESIGNED: Feb 2025 **SEALED:** 3/19/2025 REVISED:

FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)

OL2 RED (A124) -

OL2 YELLOW (A125)

OL2 GREEN (A126)

03 GREEN (118)

63

|Temporary Design 2 - TMP Phase II, Step 3 Electrical Detail - Sheet 1 of 2

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED SEAL

DETAILS FOR: Prepared for the Offices of:

ELECTRICAL AND PROGRAMMING

750 N.Greenfield Pkwy,Garner,NC 27529

SR 1997 (Fayetteville Road) SR 1984 (Linkhaw Road)

Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti PREPARED BY: R.L. Aristondo Reviewed BY: T.M. Moody REVISIONS INIT. DATE

SEAL 040329 Trent Moody

3/19/2025 SIG. INVENTORY NO. 06-0537T2

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991

U-5797 Sig. 23.2

OUTPUT CHANNEL CONFIGURATION

Front Panel

Main Menu >Controller >More >Channels >Channel Options

Web Interface

Home >Controller >Advanced IO >Channels >Channel Configuration

Channel Configuration

NOTICE OLZ	Channal	Control Turns	Control Course	Floob Vollow	Floob Dod		NANALI Champal
ASSIGNED TO	Channel	Control Type	Control Source	Flash Yellow	Flash Red	Flash Alt	MMU Channel
NOTICE OL7 ASSIGNED TO CHANNEL 1 NOTICE OL8 ASSIGNED TO CHANNEL 8	1	Overlap	7		Х	X	1
	2	Phase Vehicle	2		X		2
	3	Phase Vehicle	3		Х	Х	3
	4	Phase Vehicle	4		Х		4
	5	Phase Vehicle	5		Х		5
NOTICE OLS	6	Phase Vehicle	6		Х	Х	6
	7	Phase Vehicle	7		Х		7
CHANNEL 8	8	Overlap	8		Х	Х	8
	9	Overlap	1		Х	Х	9
	10	Overlap	2		Х	Х	10
	11	Overlap	3		X		11
	12	Overlap	4		Х		12
	13	Phase Ped	2				13
	14	Phase Ped	4				14
	15	Phase Ped	6				15
ASSIGNED TO	16	Phase Ped	8				16
	17	Overlap	5		Х	Х	17
	18	Overlap	6		Х		18



MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

Unit Flash Parameters

All Red Flash Exit Time

MAXTIME OVERLAP PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

Overlap	1	2	7	8
Туре	FYA 4 - Section	FYA 4 - Section	Normal	Normal
Included Phases	3	6	5	3
Modifier Phases	5	3	÷	-
Modifier Overlaps	±			•
Trail Green	0	0	0	0
Trail Yellow	0.0	0.0	0.0	0.0
Trail Red	0.0	0.0	0.0	0.0

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- 1. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- 2. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0537T2 DESIGNED: Feb 2025 SEALED: 3/19/2025 REVISED:

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202

(704) 372-1885

NC License Number F-0991

Electrical Detail - Sheet 2 of 2 ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared for the Offices of:

750 N.Greenfield Pkwy, Garner, NC 27529

Temporary Design 2 - TMP Phase II, Step 3

SR 1997 (Fayetteville Road) SR 1984 (Linkhaw Road)

Division 6 Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti PLAN DATE: PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS INIT. DATE

SEAL 040329

3/19/2025 DATE SIG. INVENTORY NO. 06-0537T2

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

2 Phase

Fully Actuated

Signal System #D06-17 Lumberton

US 301 and SR 1997 (Fayetteville Road)

NOTES

Drawings NCDOT" dated January

2. Do not program signal for late

otherwise directed by the

numbered 31, 32, and 33. 4. Set all detector units to

night flashing operation unless

3. Reposition existing signal heads

5. Omit "WALK" and flashing "DON'T

6. Program pedestrian heads to

7. This intersection uses video

WALK" with no pedestrian calls.

countdown the flashing "Don't

detection. Install detectors

instructions to achieve the

8. Maximum times shown in timing

according to the manufacturer's

chart are for free-run operation

2024 and "Standard Specifications for Roads and Structures" dated

1. Refer to "Roadway Standard


January 2024.

presence mode.

Walk" time only.

desired detection.

Engineer.



PHASING DIAGRAM DETECTION LEGEND

DETECTED MOVEMENT UNDETECTED MOVEMENT (OVERLAP)

UNSIGNALIZED MOVEMENT ←──> PEDESTRIAN MOVEMENT


TABLE OF OPERATION


	F	'HAS	E
SIGNAL FACE	Ø6	Ø 3	IUDLI
* * 33	R	F	R
3.4	R	F	R
61, 62	G	R	R
6.3	F	-	R
P6I, P62	W	D-W	DRK

* * Bag Green Arrow on Head 33 during this Construction Phase

SIGNAL FACE I.D.

All Heads L.E.D.






63



* Multi-zone Microwave Detection Zone

	MAXTI	ME DET	INSTALLATION CHART									
	DET		PRO	GRAMM	IN	G						
L00P	SIZE (FT)	DISTANCE FROM STOPBAR (FT)	TURNS	NEW LOOP	CALL PHASE	DELAY TIME	EXTEND TIME	EXTEND	ADDED INITIAL	CALL	DELAY DURING GREEN	NEW CARD
3A	6X40	0	*	*	3	15	_	Χ	-	Χ	ı	*
3B	6X40	0	*	*	3	15	-	Χ	-	Χ	-	*



MAXTIME TIMING CHART

FEATURE	PHA	\SE
FEATURE	3	6
Walk *	_	14
Ped Clear *	_	29
Min Green	7	12
Passage *	2.0	2.0
Max 1 *	30	90
Yellow Change	3.2	4.6
Red Clear	2.1	2.0
Added Initial *	_	_
Maximum Initial *	_	_
Time Before Reduction *	_	_
Time To Reduce *	_	_
Minimum Gap	_	_
Advance Walk	_	7
Non Lock Detector	Х	
Vehicle Recall	_	MIN RECAL

Extension times for phase 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds. * Signal heads to remain bagged

-Disconnect & Bag

(See Note 9)

Disconnect & Bag-(See Note 10)

only. Coordinated signal system timing values supersede these values. 9. Bag and disconnect existing signal heads numbered 21, 22, 31, 32, and 51.

10.Bag and disconnect green arrow on signal head numbered 33.

<u>PROPOSED</u>	<u>LEGEND</u>	<u>EXISTING</u>
\bigcirc	Traffic Signal Head	•
()->	Modified Signal Head	N/A
$\dot{\Box}$	Pedestrian Signal Head	•
*	With Push Button & Sign	*
	Sign	
	Metal Strain Pole	
Si	gnal Pole with Sidewalk Guy	
	Inductive Loop Detector	
	Controller & Cabinet	× ×
	Junction Box	
	2-in Underground Conduit	
N/A	Right of Way	
\longrightarrow	Directional Arrow	\longrightarrow
\bigcirc	Type II Signal Pedestal	
N/A	Curb Ramp	
N/A	Guardrail	
	Construction Zone	
	Portable Barrier	
~~~~	Temporary Shoring	~~~~
	Microwave Detection Zone	
• • •	Construction Zone Drums	• • •
<a>Yiel</a>	Right "TURNING VEHICLES" d "TO" Pedestrians Sign R10-	-15R 🛆

No Left Turn Sign R3-2

Signal Upgrade Temporary Design 3 - TMP Phase III, Step 1

SR 1997 (Fayetteville Road) SR 1984 (Linkhaw Road)


Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti 750 N.Greenfield Pkwy,Garner,NC 27529 PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody

SIG. INVENTORY NO. 06-0537

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL SIGNATURES COMPLETED

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885 NC License Number F-0991



## NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program controller to start up in phase 6 Green No Walk.
- 3. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 4. The cabinet and controller are part of the Signal System #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

#### **EQUIPMENT INFORMATION**

Controller	2070LX
Cabinet	.332 w/ Aux
Software	.Q-Free MAXTIME
Cabinet Mount	.Base
Output File Positions	.18 With Aux. Output File
Load Switches Used	S4, S8, S9, AUX S1, AUX S2, AUX S4
Phases Used	3, 6, 6PED
Overlap "1"	* ••
Overlap "2"	* ••
Overlap "3"	* ···
Overlap "4"	NOT USED
Overlap "7"	*

*See overlap programming detail on sheet 2

#### PROJECT REFERENCE NO. U-5797

Sig. 24

				SI	GN	AL I	HE	4D F	100	K-l	JP (	CHA	\RT	1				
LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	1	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	8 PED	OL1		SPARE	OL3	OL4	SPARE
SIGNAL HEAD NO.	NU	NU	NU	<b>★</b> 63	NU	NU	NU	61,62	P61 P62	NU	NU	NU	33 [*]	63 [*]	NU	<b>34</b> ★	NU	NU
RED		-		-				134	·	·		-	A121	A124	-	A114	-	·
YELLOW				*				135										
GREEN		-		-	·			136					·		-			
RED ARROW		-		-	·							-	·		-			
YELLOW ARROW							·						A122	A125		A115		
FLASHING YELLOW ARROW		-			·							-	A123	A126	·	A116		·
GREEN ARROW	,			118														
₩		-		·					119	·								
Ķ		-		·	·	·			121	·		-					÷	
NII = No	t I Ico	4												•				

NU = Not Used

- * Denotes install load resistor. See load resistor installation detail this sheet.
- ★ See pictorial of head wiring in detail this sheet.


## INPUT FILE POSITION LAYOUT

(front view)

2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.

3. Ensure that the Red Enable is active at all times during normal operation.

4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.



FS = FLASH SENSE ST = STOP TIME

= DENOTES POSITION OF SWITCH

ON

#### SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.

### LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)

Phase 3 Yellow Field Terminal (132) ACCEPTABLE VALUES Value (ohms) Wattage 1.5K - 1.9K 25W (min) 2.0K - 3.0K | 10W (min)

#### INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.		DETECTOR NO.	CALL PHASE	
PED PUSH BUTTONS							NOTE: INSTALL DC ISOLATOR
P61,P62	TB8-7,9	I13U	68	34	6	PED 6	IN INPUT FILE SLOT I13.

INPUT FILE POSITION LEGEND: J2L FILE J -SLOT 2-LOWER -


THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0537T3 DESIGNED: Feb 2025 SEALED: 3/19/2025



NC License Number F-0991

# FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



 $\overline{\mathsf{R}}$ OL2 RED (A124) *** OL2 YELLOW (A125) -OL2 GREEN (A126) - $\rightarrow$ 03 GREEN (118) -

|Temporary Design 3 - TMP Phase III, Step 1 Electrical Detail - Sheet 1 of 2

750 N.Greenfield Pkwy,Garner,NC 27529

ELECTRICAL AND PROGRAMMING DETAILS FOR: SR 1997 (Fayetteville Road) Prepared for the Offices of: SR 1984 (Linkhaw Road) Robeson County

Feb 2025 REVIEWED BY: H.M. Surti PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS INIT. DATE

SEAL 040329

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL

SIGNATURES COMPLETED

**(+>**)

3/19/2025 SIG. INVENTORY NO. 06-0537T3

**REVISED:** 

Charlotte, NC 28202 (704) 372-1885

PROJECT REFERENCE NO. U-5797

Sig. 24 2

## **OUTPUT CHANNEL CONFIGURATION**

Front Panel


Main Menu >Controller >More>Channels>Channels Config

Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

#### **Channel Configuration**

Channel	Control Type	Control Source	Flash Yellow	Flash Red	Flash Alt	MMU Channel
1	Phase Vehicle	1		X	Х	1
2	Phase Vehicle	2		X		2
3	Phase Vehicle	3		X	Х	3
4	Phase Vehicle	4		X		4
5	Phase Vehicle	5		X		5
6	Phase Vehicle	6		X	Х	6
7	Phase Vehicle	7		X		7
8	Phase Vehicle	8		X	Х	8
9	Overlap	1		X	Х	9
10	Overlap	2		Χ	Х	10
11	Overlap	3		X		11
12	Overlap	4		X		12
13	Phase Ped	2				13
14	Phase Ped	4				14
15	Phase Ped	6				15
16	Phase Ped	8				16
17	Overlap	5		Χ	Х	17
18	Overlap	6		X		18



NOTE: ALL RED FLASH

## MAXTIME OVERLAP PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

#### Overlap Plan 1

Overlap	1	2	3
Туре	FYA 4 - Section	FYA 4 - Section	FYA 4 - Section
Included Phases	3	6	3
Modifier Phases	÷	3	<u>-</u>
Modifier Overlaps	±	÷	-
Trail Green	0	0	0
Trail Yellow	0.0	0.0	0.0
Trail Red	0.0	0.0	0.0

## MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold 6

Unit Flash Parameters All Red Flash Exit Time

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0537T3 DESIGNED: Feb 2025 SEALED: 3/19/2025 **REVISED:** 

Temporary Design 3 - TMP Phase III, Step 1 Electrical Detail - Sheet 2 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared for the Offices of:

SR 1997 (Fayetteville Road) SR 1984 (Linkhaw Road)

Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS INIT. DATE

SEAL 040329

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

3/19/2025 DATE SIG. INVENTORY NO. 06-0537T3


Charlotte, NC 28202

STV Engineers, Inc. 900 West Trade St., Suite 715

NC License Number F-0991

(704) 372-1885

750 N.Greenfield Pkwy, Garner, NC 27529



### 3 Phase Fully Actuated Signal System #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road) NOTES

- 1. Refer to "Roadway Standard Drawings NCDOT" dated January 2024 and "Standard Specifications for Roads and Structures" dated January 2024.
- 2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- 3. Remove existing signal head numbered
- 4. Reposition existing signal heads numbered 31, 32, 33, 51, 61, and 62.
- 5. Set all detector units to presence mode.
- 6. Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- 7. Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- 8. This intersection uses multi-zone microwave detection. Install detectors according to the manufacturer's instructions to achieve the desired detection.
- 9. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these
- 10. Bag and disconnect existing signal head numbered 63.
- 11. Remove bags and reconnect signal heads numbered 31, 32 and 51.
- 12. Bag and disconnect existing pedestrian signal head numbered P61.

LEGEND

Traffic Signal Head Modified Signal Head

Sign Pedestrian Signal Head With Push Button & Sign

Metal Strain Pole Inductive Loop Detector

Controller & Cabinet

Junction Box

2-in Underground Conduit

	LEGEND	
<u>PROPOSED</u>		<u>EXISTING</u>
N/A	Guardrail	<del></del>
	Construction Zone	
	Microwave Detection Zone	
	Portable Barrier	
	Pedestrian Barricade	
~~~~	Temporary Shoring	~~~~
$\langle A \rangle$ "	NO TURN ON RED" Sign (R10-1	1) 🛆

Directional Drill N/A Right of Way Directional Arrow Type II Signal Pedestal Curb Ramp

<u>PROPOSED</u>

 \bigcirc

DOCUMENT NOT CONSIDERED Temporary Design 4 - TMP Phase IV, Step 1 FINAL UNLESS ALL SIGNATURES COMPLETED SEAL SR 1997 (Fayetteville Road)



1"=40'

Signal Upgrade

SR 1984 (Linkhaw Road)


Robeson County Lumberton Feb 2025 REVIEWED BY: H.M. Surti 750 N.Greenfield Pkwy,Garner,NC 27529 PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS INIT. DATE


TH CARO! SEAL 040329

<u>EXISTING</u>

N/A

Trent Moody 03/19/202 SIG. INVENTORY NO. 06-0537]





MAXTIME TIMING CHART PHASE FEATURE 6 Walk * Ped Clear * 31 12 Min Green 12 2.0 2.0 2.0 2.0 Passage * 90 36 Yellow Change 3.0 3.0 4.6 1.3 3.9 1.1 Red Clear 1.9 Added Initial * _ Maximum Initial * Time Before Reduction Time To Reduce ' Minimum Gap Advance Walk _ Non Lock Detector Χ Vehicle Recall MIN RECALL MIN RECALL

45 MPH -1% Grade

PHASING DIAGRAM

Ø2+6

Dual Entry

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than what is shown. Min Green for all other phases should not be lower than 4 seconds.

STV Engineers, Inc. 900 West Trade St., Suite 715

SR 1997 (Fayetteville Road)

Charlotte, NC 28202

(704) 372-1885

NC License Number F-0991

MAXTIME DETECTOR INSTALLATION CHART

3A | 6X40 | 0 | * | * | 3 | 3 | - | X | - | X | - | *

5B | 6X40 | 0 | * | * | 5 | 15 | - | X | - | X | - | 5

2

6

WB

500 -100

Υ

35 – 100

2.5 - 6.5

5A | 6X40 | 0 | * | * | 5 | - | - | X | - | X | -

TURNS

PROGRAMMING

MACARIA CALL

DETECTOR


DISTANCE

FROM

STOPBAR

* Multi-zone Microwave Detection Zone

18 CHANNEL CONFLICT MONITOR PROGRAMMING DETAIL



NOTES

- 1. To prevent "flash-conflict" problems, insert red flash program blocks for all unused vehicle load switches in the output file. The installer shall verify that signal heads flash in accordance with the signal plan.
- 2. Program controller to start up in phase 2 Green No Walk and phase 6 Green No Walk.
- 3. If this signal will be managed by an ATMS software, enable controller and detector logging for all detectors used at this location.
- 4. The cabinet and controller are part of the Signal System #D06-17 Lumberton US 301 and SR 1997 (Fayetteville Road).

EQUIPMENT INFORMATION

Controller	2070LX
Cabinet	332 w/ Aux
Software	Q-Free MAXTIME
Cabinet Mount	Base
Output File Positions	18 With Aux. Output File
Load Switches Used	S1, S2, S4, S7, S8, S12, AUX S1
Phases Used	2, 3, 3PED, 5, 6
Overlap "1"	*
Overlap "2"	NOT USED
Overlap "3"	NOT USED
Overlap "4"	NOT USED
Overlap "7"	*

*See overlap programming detail on sheet 2

PROJECT REFERENCE NO. Sig. 25 U-5797


	SIGNAL HEAD HOOK-UP CHART																	
LOAD SWITCH NO.	S1	S2	S3	S4	S5	S6	S7	S8	S9	S10	S11	S12	AUX S1	AUX S2	AUX S3	AUX S4	AUX S5	AUX S6
CMU CHANNEL NO.	1	2	13	3	4	14	5	6	15	7	8	16	9	10	17	11	12	18
PHASE	OL7	2	2 PED	3	4	4 PED	5	6	6 PED	7	8	3 PED	OL1	OL2	SPARE	OL3	OL4	SPARE
SIGNAL HEAD NO	33 [*]	21,22	NU	31,32	NU	NU	51	61,62	NU	NU	NU	P31 P32	33	NU	NU	NU	NU	NU
RED		128						134					A121					
YELLOW	*	129					·	135		·			-				·	-
GREEN		130		·			·	136	·		·	·		·	·	·		
RED ARROW				116			131											
YELLOW ARROW	·	·	-	117	-		132	-	÷	÷		·	A122		·			-
FLASHING YELLOW ARROW	٠		-					-	·		٠		A123			·		-
GREEN ARROW	127	·		118			133		·	·	·	÷		·	·		·	
*			4	·				-	·	·		110	·				·	-
Ķ												112						

NU = Not Used

★ See pictorial of head wiring in detail this sheet.

INPUT FILE POSITION LAYOUT

(front view)



2. Ensure jumpers SEL2-SEL5 and SEL9 are present on the monitor board.

3. Ensure that the Red Enable is active at all times during normal operation.

4. Connect serial cable from conflict monitor to comm. port 1 of 2070 controller. Ensure conflict monitor communicates with 2070.

FS = FLASH SENSE ST = STOP TIME

ON

SPECIAL DETECTOR NOTE

Install a multizone microwave detection system for vehicle detection. Perform installation according to manufacturer's directions and NCDOT engineer -approved mounting locations to accomplish the detection schemes shown on the Signal Design Plans.


INPUT FILE CONNECTION & PROGRAMMING CHART

LOOP NO.	LOOP TERMINAL	INPUT FILE POS.	PIN NO.		DETECTOR NO.	CALL PHASE	
PED PUSH BUTTONS							
P31;P32	TB8-8,9	I13L	70	36	8	PED 3	NOTE:
							INSTALL DC ISOLATOR IN INPUT FILE SLOT I13.

INPUT FILE POSITION LEGEND: J2L FILE J-SLOT 2-LOWER -


FYA SIGNAL WIRING DETAIL

(wire signal heads as shown)



LOAD RESISTOR INSTALLATION DETAIL

(install resistors as shown)



THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0537T4 DESIGNED: Feb 2025 SEALED: 3/19/2025

|Temporary Design 4 - TMP Phase IV, Step 1 Electrical Detail - Sheet 1 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR: SR 1997 (Fayetteville Road)

REVISIONS

REVISED:

Prepared for the Offices of:

750 N.Greenfield Pkwy,Garner,NC 27529

SR 1984 (Linkhaw Road) Robeson County Feb 2025 REVIEWED BY: H.M. Surti

Lumberton PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody INIT. DATE SIG. INVENTORY NO. 06-0537T4

SEAL 040329 3/19/2025

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL

SIGNATURES COMPLETED

STV Engineers, Inc. 900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885

NC License Number F-0991

PED 3 PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Detector >Ped Det Plans

Web Interface

Home >Controller >Detector Configuration >Pedestrian Detector

Plan 1

	Detector	Descripton	Call Phase	Call Overlap
	2		2	0
NOTICE PHASE 3 PED	4		4	0
ASSIGNED TO	6		6	0
DETECTOR 8 PED	8	P31, P32	3	0


Front Panel

Main Menu >Controller >More>Channels>Channels Config

Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

Channel Configuration



MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

Unit Flash Parameters All Red Flash Exit Time

6

NOTE: ALL RED FLASH

MAXTIME OVERLAP PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

Overlap	1	7	
Туре	FYA 4 - Section	Normal	
Included Phases	3	5	
Modifier Phases	5	÷	
Modifier Overlaps	F		
Trail Green	0	0	
Trail Yellow	0:0	0:0	
Trail Red	0.0	0.0	

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- 1. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- 2. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 06-0537T4 DESIGNED: Feb 2025 SEALED: 03/19/2025 **REVISED:**

Temporary Design 4 - TMP Phase IV, Step 1 Electrical Detail - Sheet 2 of 2

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared for the Offices of:

SR 1997 (Fayetteville Road) SR 1984 (Linkhaw Road)

Robeson County Feb 2025 REVIEWED BY: H.M. Surti PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody REVISIONS INIT. DATE 750 N.Greenfield Pkwy, Garner, NC 27529

SEAL 040329

Trent Moody 03/19/2025 SIG. INVENTORY NO. 06-0537T4

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL

SIGNATURES COMPLETED

SEAL

STV Engineers, Inc.
900 West Trade St., Suite 715 Charlotte, NC 28202 (704) 372-1885


NC License Number F-0991

PHASING DIAGRAM

Ø4 PED

Ø2+6

Ø2+5



NOTES

- 1. Refer to "Roadway Standard Drawings NCDOT" dated January 2024 and "Standard Specifications for Roads and Structures" dated January 2024.
- 2. Do not program signal for late night flashing operation unless otherwise directed by the Engineer.
- 3. Reposition existing signal heads numbered 21, 22, 31, 32, 33, 51, 61, 62, and 64.
- 4. Signal head 63 was renumbered to 64.
- 5. Set all detector units to presence mode.
- 6. Omit "WALK" and flashing "DON'T WALK" with no pedestrian calls.
- 7. Program pedestrian heads to countdown the flashing "Don't Walk" time only.
- 8. This intersection uses multi-zone microwave detection. Install detectors according to the manufacturer's instructions to achieve the desired detection.
- 9. Maximum times shown in timing chart are for free-run operation only. Coordinated signal system timing values supersede these values.
- 10. Remove bags and reconnect pedestrian signal head numbered P61.

LEGEND

Microwave Detection Zone

EXISTING

-

N/A

MAXTIME DETECTOR INSTALLATION CHART **DETECTOR** PROGRAMMING DISTANCE M CALL DETAX EXTEND CALL CALL CALL CALL CALL CARE FROM L00P (FT) 0 | * |*| 1 | - | - | X | - | X | - | 3 * * 3 3 - X - X - * * |*| 3 | - | - |X|-|X|-|* 0 * * 5 - - X - X - * 0 | * | * | 5 | 15 | - | X | - | X | - | *

* Multi-zone Microwave Detection Zone

RADAR DETECTION SYSTEM			
FUNCTION	SENSOR 1 – 2A	SENSOR 2 - 6/	
Channel	1	2	
Phase	2	6	
Direction of Travel	EB	WB	
Detection Zone (ft)	500 – 100	500 –100	
Enable Speed	Y	Υ	
Speed Range (mph)	35 – 100	35 – 100	
Enable Estimated Time of Arrival	Y	Υ	
Estimated Time of Arrival (sec)	2.5 - 6.5	2.5 - 6.5	

	SR 1997 (Fayetteville Road)			P61 //
				P32
:======================================			:=====================================	=====64 → 63 →
	- — — — — - — <u>—</u> —			62
				61 11
		<u></u> <i>→</i>	5A <	
		$\stackrel{\longrightarrow}{-}$		+
		— — → =========	— — ========	P31 P31
	//			

PHASING DIAGRAM DETECTION LEGEND

DETECTED MOVEMENT

←−−> PEDESTRIAN MOVEMENT

UNSIGNALIZED MOVEMENT

UNDETECTED MOVEMENT (OVERLAP)

TABLE OF OPERATION

SIGNAL

21, 22, 23

3I**,** 32

61, 62, 63

6.4

P3I, P32

PHASE

NOR RRA

|DW|DW|DW|DW| W |DW|DRI

DW DW DW DW DW W DRI

P61, P62 DW W DW W DW DW DRK

SR 1997 (Fayetteville Road)		P61 //	P62	45 MPH 0% Grade 	
		2	P41 ====================================	//	
		30-		←	
	— — — 62 — — — 61			——————————————————————————————————————	
	61	11	51	5	
	<u> </u>	2			
	→	P31 23	— — — — — — — — — — — — — — — — — — —		
		· T - Z		SR 1997 (Fayetteville Road)	

SIGNAL FACE I.D.

All Heads L.E.D.

21, 22, 23

61, 62, 63

33

64

P31, P32

P41, P42

P61, P62

 $\frac{-L- Sta. 67+97\pm}{/RT 79'\pm}$

31, 32

	MAX	TIME T	IMING	CHART		
FEATURE	PHASE					
FEATURE	1	2	3	4 (PED)	5	6
Walk *	_	_	14	13	_	14
Ped Clear *	_	_	31	31	_	31
Min Green	7	12	7	7	7	12
Passage *	2.0	2.0	2.0	_	2.0	2.0
Max 1 *	20	90	30	39	20	90
Yellow Change	3.0	4.6	3.0	3.0	3.0	4.5
Red Clear	3.9	1.9	3.7	1.0	3.3	2.1
Added Initial *	_	-	_	_	_	-
Maximum Initial *	_	-	_	_	_	-
Time Before Reduction *	_	-	_	_	_	-
Time To Reduce *	_	-	_	_	_	-
Minimum Gap	_	-	_	_	_	-
Advance Walk	_	_	7	6	_	7
Non Lock Detector	Х	_	Х	Х	Х	_
Vehicle Recall	_	MIN RECALL	_	_	_	MIN RECALL
Dual Entry	-	_	_	_	_	_

* These values may be field adjusted. Do not adjust Min Green and Extension times for phases 2 and 6 lower than

what is shown. Min Green for all other phases should not be lower than 4 seconds.

PROPOSED Traffic Signal Head Modified Signal Head Pedestrian Signal Head With Push Button & Sign Metal Strain Pole Inductive Loop Detector Controller & Cabinet Junction Box 2-in Underground Conduit N/A Right of Way Directional Arrow Type I Pushbutton Post Type II Signal Pedestal Curb Ramp Guardrail Construction Zone Portable Barrier Pedestrian Barricade

Signal Upgrade Temporary Design 5 - TMP Phase IV, Step 2



1"=40'

STV Engineers, Inc.

900 West Trade St., Suite 715

Charlotte, NC 28202

(704) 372-1885 NC License Number F-0991 SR 1997 (Fayetteville Road) SR 1984 (Linkhaw Road)

Robeson County Lumberton June 2025 REVIEWED BY: H.M. Surti 750 N.Greenfield Pkwy.Garner.NC 27529 PREPARED BY: R.L. Aristondo REVIEWED BY: T.M. Moody

SEAL TH CARO! SEAL 040329

DOCUMENT NOT CONSIDERED

FINAL UNLESS ALL SIGNATURES COMPLETED

Trent Moody 6/11/2025 SIG. INVENTORY NO. 06-0537