

(program controller as shown below)

```

PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
PHASE:           12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR:   _ RED _ YELLOW _ GREEN
FLASH COLORS:    _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...N
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

```

PRESS ' + '

```

PAGE 1: VEHICLE OVERLAP 'B' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: X
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...N
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)...0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

```

PRESS '+'

```

PAGE 1: VEHICLE OVERLAP 'C' SETTINGS
PHASE: 12345678910111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?..Y.N
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)..0.0
RED CLEAR (0=PARENT,1-25.5 SEC)....0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

```

PRESS ' + '

```

PAGE 1: VEHICLE OVERLAP 'D' SETTINGS
PHASE: 1234567890111213141516
VEH OVL PARENTS: XX
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED _ YELLOW _ GREEN
FLASH COLORS: _ RED _ YELLOW X GREEN
SELECT VEHICLE OVERLAP OPTIONS: (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...N
GREEN EXTENSION (0-255 SEC).....0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)....0
RED CLEAR (0=PARENT,1-25.5 SEC)....0
OUTPUT AS PHASE # (0=NONE, 1-16)....0

```

← NOTICE
GREEN
FLASH

```

PAGE 1: VEHICLE OVERLAP
PHASE: 1234
VEH OVL PARENTS:
VEH OVL NOT VEH:
VEH OVL NOT PED:
VEH OVL GRN EXT:
STARTUP COLOR: _ RED
FLASH COLORS: _ RED
SELECT VEHICLE OVERLAP
FLASH YELLOW IN CONTN
GREEN EXTENSION (0-2)
YELLOW CLEAR (0=PARENT,
RED CLEAR (0=PARENT,
OUTPUT AS PHASE # (0)

```

Countdown Ped Signals are required to display timing only during Ped Clearance Interval. Consult Ped Signal Module user's manual for instructions on selecting this feature.

(program controller as shown below)

ADVANCED WALK NOTE

(program controller as shown below)

From Main Menu press '2' (Phase Control), then '1' (Phase Control Functions). Program phases 2, 4, 6 and 8 for 'Advanced Walk'. Make sure the Walk Advance Time shown on the Signal Design plans are programmed in the 'Phase Timing' menu.

In order to ensure that signals flash concurrently on the same approach, make the following flasher circuit changes:

1. On rear of PDA - Remove wire from Term. T2-4 and terminate on T2-2.
2. On rear of PDA - Remove wire from Term. T2-5 and terminate on T2-3.
3. Remove Flasher Unit 2.

The changes listed above tie all phases and overlaps to Flasher Unit 1.

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 04-0234
DESIGNED: February 2025
SEALED: 3/27/2025
REVISED: