

NCMap 6

Revision Log

(NCMap.ma)

Version : **6.2.2**

Date Released : **March 10, 2011**

Additions, Changes and Bugs Fixed

- Fixed a bug in the **NCMap Auto Text** tool for features **Exist Utilities Power Manhole, Exist Utilities Telephone Manhole, Exist Utilities Water Manhole, Exist Utilities Sanitary Sewer Manhole, Exist Structure Minor Storm Sewer Manhole**. When one of these features is selected for textting the toolsetting dialog box has an optionbutton that contains “Label” or “Elevation” at the top. The selection area was very limited. This problem has now been fixed. . Note: This bug exist in all previous versions of NCMaP 6.
- Fixed a bug in the **NCMap Property Numbers Topo** and **NCMap Numbers NonTopo** tools. If these tools where started in a drawing file that had a project scale of “0” it would cause MicroStation to lockup. Note: This bug exist in all previous versions of NCMaP 6.

Version : 6.2.1

Date Released : October 26, 2010

Additions, Changes and Bugs Fixed

- Fixed a bug. Turned OFF some programming debug messages that had been left ON in Version 6.2.0 .

Version : 6.2.0

Date Released : October 1, 2010

Additions, Changes and Bugs Fixed

- Changed the **PSD Title Sheet** tool. Changed to the person's name of the "PROPERTY SURVEY AND CADD MAPPING ENGINEER" in the bottom right corner from "J. A. DODSON, PE" to "ANTHONY C. FULP".

Version : 6.1.0

Date Released : September 17, 2010

Additions, Changes and Bugs Fixed

- Fixed a bug in **NCMap**. When a MicroStation session was started with a Locations or Photogrammetry workspace and the “directory”/”file name” was longer than 100 characters NCMap would not load and also generate a “http:/// - Bentley Software Problem Report”. Note: This bug only exists in Version 6.0.0 released 1/6/10.
- Converted **NCMap Hydro Disappearing Stream** tool to run in MicroStation V8.
- Added “**ncmap text auto allowfeainref**” hidden keyin (setting). This hidden keyin (setting) will allow users to ID features in active model or any reference when in the **NCMap Text Auto** tool. The operator will be allowed to change active models and the keyin (setting) will remain in affect. The keyin (setting) will remain in affect until the MicroStation session ends or the user does a *FILE/OPEN* for a different drawing. The user will only be able to text features in references, if the text level needed for the ID'd feature is in dgnlib that issociated with the workspace. Note: Requested by Photogrammetry.

Version : 6.0.1

Date Released : February 5, 2010

Additions, Changes and Bugs Fixed

- Fixed a bug in **NCMap Auto Text** tool. When you identified an Exist Property Line to add the bearing and distance text, the degree symbol would display as “13/64”. Note: This bug only exists in Version 6.0.0 released 1/6/10.

Version : 6.0.0

Date Released : January 6, 2010

Additions, Changes and Bugs Fixed

- Official version was released for **MicroStation V8i**.