PROJECT REFERENCE NO.	SHEET NO.
I-0914BA	Sig. 11.2

OVERLAP PROGRAMMING DETAIL

(program controller as shown below)

FROM MAIN MENU PRESS '8' (OVERLAPS), THEN '1' (VEHICLE OVERLAP SETTINGS).

```
 PAGE 1: VEHICLE OVERLAP 'A' SETTINGS
 PHASE:          ¦123456789101112131415 16
VEH OVL PARENTS:¦      X
VEH OVL NOT VEH:¦
VEH OVL NOT PED:¦
VEH OVL GRN EXT:¦
STARTUP COLOR: _ RED  _ YELLOW  _ GREEN
FLASH COLORS:  _ RED  _ YELLOW  X GREEN
SELECT VEHICLE OVERLAP OPTIONS:   (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...Y
GREEN EXTENSION (0-255 SEC).........0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)..0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0
```

← NOTICE GREEN FLASH

PRESS '+' THREE TIMES

```
 PAGE 1: VEHICLE OVERLAP 'D' SETTINGS
 PHASE:          ¦123456789101112131415 16
VEH OVL PARENTS:¦        X
VEH OVL NOT VEH:¦
VEH OVL NOT PED:¦
VEH OVL GRN EXT:¦
STARTUP COLOR: _ RED  _ YELLOW  _ GREEN
FLASH COLORS:  _ RED  _ YELLOW  X GREEN
SELECT VEHICLE OVERLAP OPTIONS:   (Y/N)
FLASH YELLOW IN CONTROLLER FLASH?...N
GREEN EXTENSION (0-255 SEC).........0
YELLOW CLEAR (0=PARENT,3-25.5 SEC)..0.0
RED CLEAR (0=PARENT,0.1-25.5 SEC)...0.0
OUTPUT AS PHASE # (0=NONE, 1-16)....0
```

← NOTICE GREEN FLASH

OVERLAP PROGRAMMING COMPLETE

LOGICAL I/O PROCESSOR PROGRAMMING DETAIL FOR FIREHOUSE PILOT LAMP CONTROL

(program controller as shown below)

1. FROM MAIN MENU PRESS '2' (PHASE CONTROL), THEN '1' (PHASE CONTROL FUNCTIONS). SCROLL TO THE BOTTOM OF THE MENU AND ENABLE ACT LOGIC COMMANDS 1 AND 2.

2. FROM MAIN MENU PRESS '6' (OUTPUTS), THEN '3' (LOGICAL I/O PROCESSOR).

```
 LOGICAL I/O COMMAND #1  (+/-COMMAND#)
IF  INPUT   ASSIGNMENT #14 IS ON
OR  ACTIVE PREEPTION   #2  IS ON

                 ↓
            SCROLL DOWN

THEN:
SET OUTPUT  ASSIGNMENT #33 ON
```

NOTE: FIRE HOUSE PILOT LAMP LOGIC.

PRESS '+'

```
 LOGICAL I/O COMMAND #2  (+/-COMMAND#)
IF  INPUT   ASSIGNMENT #14 IS OFF
AND ACTIVE PREEMPTION  #2  IS OFF

                 ↓
            SCROLL DOWN

THEN:
SET OUTPUT  ASSIGNMENT #33 OFF
```

NOTE: FIRE HOUSE PILOT LAMP LOGIC.

LOGIC I/O PROCESSOR PROGRAMMING COMPLETE

OUTPUT REFERENCE SCHEDULE

INPUT 14 = Preempt 2 Input
OUTPUT 33 = Phase 2 PED Yellow

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 05-0543T1
DESIGNED: September 2014
SEALED: 10/23/2014
REVISED: N/A

FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

Electrical Detail - Temporary Design (TMP Phases 1-3) - Sheet 2 of 3

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared in the Offices of:
Transportation Mobility and Safety Division
STATE OF NORTH CAROLINA DEPARTMENT OF TRANSPORTATION
Signal Management Section
750 N.Greenfield Pkwy,Garner,NC 27529

US 1-158 Bus. (N. Garnett St.)
at
I-85/US 158 Bypass Ramp
and SR 1271 (Bickett St.)

Division 5 Vance County Henderson

PLAN DATE:	October 2014	REVIEWED BY:	DR
PREPARED BY:	S. Armstrong	REVIEWED BY:	JTR

REVISIONS	INIT.	DATE

SEAL

NORTH CAROLINA PROFESSIONAL SEAL 008453 ENGINEER JOHN T. ROWE, JR.

DocuSigned by:
John T. Rowe, Jr.
641D60C145EE4F5...
10/27/2014
DATE

SIG. INVENTORY NO. 05-0543T1

24-OCT-2014 07:24
S:\TISAS\HTS\Signals\Workgroups\Sig Mon\Armstrong\050543_smale_xxx.dgn
sarmstrong