CROSS SECTION INDEX

X–1	CROSS SECTION INDEX		
X–1A	CROSS SECTION SUMMARY		
X–2	THRU	X–46	–L–
X–47			–Y1–
X–48	THRU	X–49	–Y4–
X–50	THRU	X–52	–Y6–
X–53			–Y8–
X–54	THRU	X–56	–Y9–

5/28/99

invoid expression
USER: \\ITS\DGN\ - ity.xsc_index.dgn