PREEMPTION PROGRAMMING

Front Panel

Main Menu >Controller >Preemption >Preempt Phasing/Preempt Parameters

Web Interface

Home >Controller >Preempt Configuration >Preempts

Preempt Configuration

Preempt Configuration		
Preempt	1	
Enabled	Enabled	
Туре	Rail Road	
Track Phases	4,39	
Track Overlaps	-	
Dwell Phases	2,6	
Dwell Peds	-	
Dwell Overlaps	3	
Cycling Phases	-	
Cycling Peds	-	
Cycling Overlaps	-	
Exit Phases	4	
Exit Overlaps	<u>-</u>	
Delay	0	
Call Ext Time	1.0	
Max Presence	0	
Max Pres Act	Terminate	
Enter Min Green	1	
Enter Walk	0	
Enter Ped Clear	0	
Enter Yellow Change	4.7	
Enter Red Clear	3.1	
Track Green	22	
Track Yellow Clr	3.2	
Track Red Clear	2.8	
Dwell Green	0	
Exit Min Green	255	
Exit Yellow Change	25.5	
Exit Red Clear	25.5	
Exit Type	Exit Phases	
Non Locking Memory	-	
Not Ovrd Flash	Х	
Not Ovrd Nxt Pre	-	
Require All Red Entry	-	
Track Clear Ovrd	Х	
Ped Clear During Yellow	-	
Entry Omit OLTG	Х	
Track Reserve	Х	

SEQUENCE DETAIL

Front Panel Main Menu >Controller >Sequence & Phs Config>Sequences

Web Interface Home >Controller >Sequence

Sequence 1

Ring	Sequence Data
1	1,2,a,3,4,b
2	5,6,a,7,8,b
3	39,c,40,d



