CULVERT CONSTRUCTION SEQUENCE STA. 82+95

PHASE I

PHASE II

SPECIAL STILLING BASIN WITH ROCK PAD

Not To Scale

Note: Provide Stabilized Outlet to Streambank

PHASE I

1. INSTALL SPECIAL STILLING BASIN.
2. CONSTRUCT IMPERVIOUS DIKES AND INSTALL 24 IN TEMPORARY PIPE.
3. CONSTRUCT UPSTREAM EXTENSION OF CULVERT.
4. REMOVE IMPERVIOUS DIKES AND TEMPORARY PIPE.
5. CONSTRUCT SOUTHBOUND LANE WIDENING.

PHASE II

1. INSTALL SPECIAL STILLING BASIN.
2. CONSTRUCT IMPERVIOUS DIKES AND INSTALL 24 IN TEMPORARY PIPE.
3. CONSTRUCT DOWNSTREAM EXTENSION OF CULVERT.
4. REMOVE IMPERVIOUS DIKES AND TEMPORARY PIPE.
5. CONSTRUCT NORTHBOUND LANE WIDENING.