## MAXTIME OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

#### Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

**Overlap Plan 1** 

| Overlap           | 3               | 4               | 5               | 7      |
|-------------------|-----------------|-----------------|-----------------|--------|
| Туре              | FYA 4 - Section | FYA 4 - Section | FYA 4 - Section | Normal |
| Included Phases   | 2               | 2               | 2               | 7      |
| Modifier Phases   | ÷               | 7               | -               | -      |
| Modifier Overlaps | 7               | <u>-</u>        | ÷               | -      |
| Trail Green       | 0               | 0               | 0               | 0      |
| Trail Yellow      | 0.0             | 0.0             | 0.0             | 0.0    |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0    |

NOTICE OVERLAP 7 ASSIGNED TO CHANNEL 5

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

Overlap Plan 2

| Overlap           | 3               | 4               | 5               | 7      |                |
|-------------------|-----------------|-----------------|-----------------|--------|----------------|
| Туре              | FYA 4 - Section | FYA 4 - Section | FYA 4 - Section | Normal |                |
| Included Phases   | ÷               | ÷               | 2               | 7      |                |
| Modifier Phases   | ÷               | 7               | <u>-</u>        | ÷      | INCLUDED PHASE |
| Modifier Overlaps | 7               | ÷               | <u>-</u>        | ÷      |                |
| Trail Green       | 0               | 0               | 0               | 0      |                |
| Trail Yellow      | 0.0             | 0.0             | 0.0             | 0.0    |                |
| Trail Red         | 0.0             | 0.0             | 0.0             | 0.0    |                |

## MAXTIME ALTERNATE PHASING PATTERN **PROGRAMMING DETAIL**

Front Panel Main Menu >Controller >Coordination >Patterns

Web Interface Home >Controller >Coordination >Patterns

Pattern Parameters

Veh Det Plan Overlap Plan Pattern \* 2 2

\* The Pattern number(s) are to be determined by the Division and/or City Traffic Engineer.

## OUTPUT CHANNEL CONFIGURATION

Front Panel

Main Menu >Controller >More>Channels>Channels Config

#### Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

#### Channel Configuration

| Channel | Control Type  | Control Source | Flash Yellow | Flash Red | Flash Alt | MMU Channel |                   | ACTIVE PL |
|---------|---------------|----------------|--------------|-----------|-----------|-------------|-------------------|-----------|
| 1       | Phase Vehicle | 1              |              | Х         | Х         | 1           |                   |           |
| 2       | Phase Vehicle | 2              | Х            |           |           | 2           |                   |           |
| 3       | Phase Vehicle | 3              |              | Х         | Х         | 3           |                   |           |
| 4       | Phase Vehicle | 4              |              | Х         | Х         | 4           |                   |           |
| 5       | Overlap       | 7              | Х            |           |           | 5           | NOTICE CHANNEL 5  |           |
| 6       | Phase Vehicle | 6              | Х            |           | Х         | 6           | YELLOW FLASH      |           |
| 7       | Phase Vehicle | 7              | Х            |           |           | 7           | NOTICE CHANNEL 7  |           |
| 8       | Phase Vehicle | 8              |              | Х         | Х         | 8           | YELLOW FLASH      |           |
| 9       | Overlap       | 1              | Х            |           | Х         | 9           |                   |           |
| 10      | Overlap       | 2              |              | Х         | Х         | 10          |                   |           |
| 11      | Overlap       | 3              | Х            |           | Х         | 11          |                   |           |
| 12      | Overlap       | 4              | Х            |           | Х         | 12          | NOTICE CHANNEL 12 |           |
| 13      | Phase Ped     | 2              |              |           |           | 13          | YELLOW FLASH      |           |
| 14      | Phase Ped     | 4              |              |           |           | 14          |                   |           |
| 15      | Phase Ped     | 6              |              |           |           | 15          |                   |           |
| 16      | Phase Ped     | 8              |              |           |           | 16          |                   |           |
| 17      | Overlap       | 5              | Х            |           |           | 17          | NOTICE CHANNEL 17 |           |
| 18      | Overlap       | 6              |              | Х         |           | 18          | YELLOW FLASH      |           |

### MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING LOOP 7A

#### Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2.

Modify Detector Plan 2 as shown below and save changes.

| Plan 2   |            |       |
|----------|------------|-------|
| Detector | Call Phase | Delay |
| 21       | 7          | 0     |

# MAXTIME ALTERNATE PHASING ACTIVATION DETAIL

To run alternate phasing, select a Pattern that is programmed to run Overlap Plan 2 and Detector Plan 2. A Pattern can be selected through the scheduler or manually by changing the Operational Mode.

PHASING LAN LAN

IN ORDER TO INSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

1. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.

2. ON REAR OF PDA - REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3. 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

|  |                           | (            |
|--|---------------------------|--------------|
|  |                           | Elec         |
|  |                           | Prepa        |
| P: (919) 878-9560<br>8601 Six Forks Road Suite 700   Raleigh,<br>NC License No. F-0112 | North Carolina 27615-2965 | OGUEL ITS &  |
| Engineers   Construction Managers   Pla<br>www.rkk.com                                 | nners   Scientists        | 750 N. Green |
| Responsive People   Creative Solutions   |                           |              |

7A

| PROJECT REFERENCE NO. | SHEET NO. |
|-----------------------|-----------|
| R-2577A               | Sig. 38.2 |

|  | OVERLAP PLAN | VEH DET PLAN |
|--|--------------|--------------|
| I REQUIRED TO <u>RUN DEFAULT PHASING</u> | 1            | 1            |
| I REQUIRED TO RUN ALTERNATE PHASING      | 2            | 2            |
|  |              |              |

THE FOLLOWING IS A SUMMARY OF WHAT TAKES PLACE WHEN **OVERLAP PLAN 2 AND VEHICLE DETECTOR PLAN 2 ACTIVATE** TO CALL THE "ALTERNATE PHASING":

| OVERLAP PLAN 2: | Modifies overlap included phases                 |
|-----------------|--|
|                 | for heads 71 and 72 to run protected turns only. |

VEH DET PLAN 2: Reduces delay time for phase 7 call on loop 7A to 0 seconds.

# **FLASHER CIRCUIT MODIFICATION DETAIL**

THE SIGNAL DESIGN: 09-1100T5 DESIGNED: February 2024 SEALED: February 12, 2024 **REVISED**: Signal Upgrade - Temporary Design 5 (TMP Phase III Step 3) - Electrical Detail - Sheet 2 of 2 DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED ctrical and Programming Details For: SEAL US 158 EB (Reidsville Rd.) TH CARO at ared for the Offices of: OFESSION SR 2014 (Vance Rd.) SEAL 056142 Walkertown Forsyth County Division 9 Z . M. GINEER. PLAN DATE: February 2024 REVIEWED BY: DT Sears PREPARED BY: WP Erickson-Jones REVIEWED BY: REVISIONS INIT. DATE Porter Jones 2/12/202 nfield Pkwy, Garner, NC 27529 DATE SIG. INVENTORY NO. 09-1100T5

THIS ELECTRICAL DETAIL IS FOR