### **OUTPUT CHANNEL CONFIGURATION**

Front Panel

Main Menu >Controller >More>Channels>Channels Config

Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

**Channel Configuration** 

Channel	Control Type	Control Source	Flash Yellow	Flash Red	Flash Alt	MMU Channel
1	Phase Vehicle	1		Χ	Х	1
2	Phase Vehicle	2	·	X	·	2
<b>→</b> 3	Overlap	7		X	Х	3
4	Phase Vehicle	4	·	Х	·	4
5	Phase Vehicle	5	·	X	·	5
6	Phase Vehicle	6	·	X	Х	6
7	Phase Vehicle	7	·	Х	·	7
8	Phase Vehicle	8	·	Х	Х	8
9	Overlap	1	•	X	Χ	9
10	Overlap	2		X	Х	10
11	Overlap	3	·	Х	·	11
12	Overlap	4		X		12
13	Phase Ped	2	•	·	·	13
14	Phase Ped	4	·	·	·	14
15	Phase Ped	6	·	·	·	15
16	Phase Ped	8	·	·	·	16
1.7	Overlap	5	·	X	Х	1.7
18	Overlap	6	·	X	·	18

NOTICE: FLASH RED

## MAXTIME DETECTOR PROGRAMMING DETAIL FOR ALTERNATE PHASING **LOOPS 1A & 5A**

Front Panel

Main Menu >Controller >Detector >Veh Det Plans

Web Interface

Home >Controller >Detector Configuration >Vehicle Detectors

In the table view of web interface right click on "Detector" in the top left corner of the table. Copy the entire contents of Detector Plan 1. Paste Detector Plan 1 into Detector Plan 2. Modify Detector Plan 2 as shown below and save changes.

Plan 2

	1 1411 2		
	Detector	Call Phase	Delay
1A	1	1	0:0
	29	0	3:0

	Detector	Call Phase	Delay
5A	15	5	0:0
	31	0	3:0

#### FLASHER CIRCUIT MODIFICATION DETAIL

IN ORDER TO ENSURE THAT SIGNALS FLASH CONCURRENTLY ON THE SAME APPROACH, MAKE THE FOLLOWING FLASHER CIRCUIT CHANGES:

- 1. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-4 AND TERMINATE ON T2-2.
- 2. ON REAR OF PDA REMOVE WIRE FROM TERM. T2-5 AND TERMINATE ON T2-3.
- 3. REMOVE FLASHER UNIT 2.

THE CHANGES LISTED ABOVE TIES ALL PHASES AND OVERLAPS TO FLASHER UNIT 1.

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR DEFAULT PHASING

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

#### Overlap Plan 1

Overlap	1	2	3	5	7
Туре	FYA 4 - Section	Normal			
Included Phases	2	8	6	6	1
Modifier Phases	1	±	5	÷	÷
Modifier Overlaps	4	7	4	4	4
FYA Ped Delay	÷	4	7	7	4
Trail Green	0	0	0	0	0
Trail Yellow	0:0	0:0	0:0	0:0	0:0
Trail Red	0:0	0:0	0:0	0:0	0:0

## MAXTIME OVERLAP PROGRAMMING DETAIL FOR ALTERNATE PHASING

Front Panel

Main Menu > Controller > Overlap > Overlap Parameters / Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

In the table view of the web interface, right click on "Overlap" in the top left corner of the table. Copy the entire contents of Overlap Plan 1. Paste Overlap Plan 1 into Overlap Plan 2. Modify Overlap Plan 2 as shown below and save changes.

#### Overlap Plan 2

Overlap	1	2	3	5	7	
Туре	FYA 4 - Section	Normal				
Included Phases	÷	8	÷	6	1	NOTICE INCLUDED PHASE
Modifier Phases	1	±	5	±	<u>.</u>	
Modifier Overlaps	<u> </u>	7	<u>-</u>	÷	<u>.</u>	NOTICE FYA PED DELAY
FYA Ped Delay	÷	Ė	÷	7	÷	
Trail Green	0	0	0	0	0	
Trail Yellow	0:0	0:0	0:0	0:0	0:0	
Trail Red	0.0	0:0	0.0	0:0	0:0	

# MAXTIME STARTUP AND SOFTWARE FLASH PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Unit

Web Interface

Home >Controller >Unit

Modify parameters as shown below and save changes.

Start Up Parameters

StartUp Clearance Hold

**Unit Flash Parameters** All Red Flash Exit Time

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 09-0482T DESIGNED: August 2024 SEALED: 07/14/2025 REVISED: N/A

INIT. DATE

Electrical Detail - Temporary Design Sheet 2 of 3

ELECTRICAL AND PROGRAMMING Prepared For: 750 N.Greenfield Pkwy, Garner, NC 27529

Big Mill Farm Road / Sr 2649 (Hopkins Road) at Bluff School Road

Forsyth County Kernersville Division 9 PLAN DATE: August 2024 REVIEWED BY: KP Baumann PREPARED BY: CF Davis REVIEWED BY:

REVISIONS

SEAL 044434 NGINEER.

SIG. INVENTORY NO. 09-0482T

**DOCUMENT NOT CONSIDERED** FINAL UNLESS ALL SIGNATURES COMPLETED

PLANS PREPARED IN THE OFFICE OF: Kimley » Horn NC License #F-0102 421 Fayetteville Street, Suite 600 Raleigh, NC 27601 (919) 677-2000