## CULVERT CONSTRUCTION SEQUENCE STA. 37+10 -L-

1. UTILIZE SPECIAL STILLING BASIN (S) DURING CULVERT CONSTRUCTION AS NEEDED. 2. CONSTRUCT IMPERVIOUS DIKES A & B 3. UTILIZE PUMP AS NEEDED TO DISCHARGE HEADWATERS DOWNSTREAM OF PROJECT LIMITS. 4. REMOVE EXISTING 48" CMP, CONSTRUCT PROPOSED 2@54" RCP-IV PIPE AND INLET AND OUTLET CHANNEL IMPROVEMENT. 5. REMOVE IMPERVIOUS DIKES A AND B AND ANY REMAINING SPECIAL STILLING BASINS. 6. COMPLETE ROADWAY

