


CULVERT CONSTRUCTION SEQUENCE STA. 127+23 -L-

PROJECT REFERENCE NO. W-5512	SHEET NO. EC-11A/CONST/11
RW SHEET NO.	
ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER

1. UTILIZE SPECIAL STILLING BASIN (S) DURING CULVERT CONSTRUCTION AS NEEDED.
2. CONSTRUCT IMPERVIOUS DIKES A & B
3. UTILIZE PUMP AS NEEDED TO DISCHARGE HEADWATERS DOWNSTREAM OF PIPE CONSTRUCTION.
4. REMOVE EXISTING 42" CMP, CONSTRUCT PROPOSED 60" RCP-III WITH HEADWALL.
5. REMOVE IMPERVIOUS DIKES A AND B AND ANY REMAINING SPECIAL STILLING BASINS.
6. COMPLETE ROADWAY



MI ENGINEERING
 1011 SCHAUB DRIVE, SUITE 100
 RALEIGH, NC 27606
 (919) 851-6606
 FIRM PE NUMBER : P-0671

