


**TYPICAL SECTION NO. 11**  
 -L1- STA.  
 97+21.91 TO 103+00.00

STEPS FOR TYPICAL SECTION NO. 11:  
 STEP 1: PERFORM WIDENING WITH BASE COURSE. LEAVE BASE COURSE 4" BELOW EXISTING GRADE.  
 STEP 2: MILL EXISTING PAVEMENT.  
 STEP 3: PLACE INTERMEDIATE LAYER ACROSS ENTIRE ROADWAY.  
 STEP 4: PLACE SURFACE COURSE ACROSS ENTIRE ROADWAY.



**TYPICAL SECTION NO. 12**  
 -L1- STA.  
 147+74.95 TO 159+20.85

STEPS FOR TYPICAL SECTION NO. 12:  
 STEP 1: PERFORM WIDENING WITH BASE COURSE. LEAVE BASE COURSE 1 1/2" BELOW EXISTING GRADE.  
 STEP 2: MILL EXISTING PAVEMENT.  
 STEP 3: PLACE INTERMEDIATE LAYER ACROSS ENTIRE ROADWAY.  
 STEP 4: PLACE SURFACE COURSE ACROSS ENTIRE ROADWAY.

PAVEMENT SCHEDULE	
C1	1 1/2" S9.5B
D	2 1/2" I19.0B
E	4 1/2" B25.0B
T	EARTH
U	EXISTING PAVEMENT.
V	1 1/2" FINE MILLING
V1	4" MILLING

NOTE: PAVEMENT EDGE SLOPES ARE 1:1 UNLESS NOTED OTHERWISE.

5/14/99  
 03-AUG-2015 14:04  
 Relat (use this file) \ROADWAY\Proo\Plan\_Sheets\W5103A\_D03\_Rdwy\_2A-6.dgn  
 10:51:33 AM