
## CULVERT CONSTRUCTION SEQUENCE STA. 142



- 1. CONSTRUCT STILLING BASIN (40 CY).
- 2. CONSTRUCT IMPERVIOUS DIKES AND INSTALL 36 INCH TEMPORARY PIPE, DIVERTING FLOW.
- 3. UTILIZING TEMPORARY SHORING, WIDEN ROAD TO ACCOMODATE TEMPORARY TRAFFIC SHIFTS AND SHIFT TRAFFIC ACCORDING TO THE TRAFFIC CONTROL PLAN.
- 4. REMOVE PORTIONS OF THE EXISTING CULVERT AND BUILD PROPOSED CULVERT PER TRAFFIC CONTROL PHASING.
- 5. CONSTRUCT LOW FLOW BENCHES.
- 6. REMOVE IMPERVIOUS DIKES AND 36 INCH TEMPORARY PIPE.
- 7. REMOVE STILLING BASIN.
- 8. COMPLETE ROADWAY.

2+79_L_	project reference no. $R-4753$	SHEET NO. EC-14/CONST.13
	R/W SHEET NO.	
	ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER