ECONOLITE ASC/3-2070 OVERLAP
PROGRAMMING DETAIL
(program controller as shown)

1. From Main Menu select | 2. CONTROLLER |

2. From CONTROLLER Submenu select | 2. VEHICLE OVERLAPS |

Toggle Three Times

OVERLAP D

Select TMG VEH OVLP [D] and 'PPLT FYA'

```
TMG VEH OVLP...[D] TYPE: .....|PPLT FYA|

PROTECTED LEFT TURN....   PHASE   M
OPPOSING THROUGH.......   PHASE   2

FLASHING ARROW OUTPUT.....CH12 ISOLATE

DELAY START OF: FYA..0.0 CLEARANCE..0.0
ACTION PLAN SF BIT DISABLE........... 0
```

Toggle to advance
to Overlap 'M'

OVERLAP M

Select TMG VEH OVLP [M] and 'NORMAL'

```
TMG VEH OVLP...[M] TYPE: ......|NORMAL|
    PHASES 1 2 3 4 5 6 7 8 9 0 1 2 3 4 5 6
INCLUDED . . . . . . X . . . . . . . . .

LAG GRN 0.0 YEL 0.0 RED 0.0
```

END PROGRAMMING

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 06-1303
DESIGNED: May 2016
SEALED: 8-23-16
REVISED: N/A

Electrical Detail - Sheet 2 of 2

**DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED**