

CHANNEL CHANGE CONSTRUCTION SEQUENCE STA. 15 + 36 -L-

PHASE I

1. UTILIZE SPECIAL STILLING BASIN(S) AS NEEDED THROUGHOUT STREAM RELOCATION.
2. INSTALL IMPERVIOUS DIKE AND PUMP AROUND OPERATION.
3. DEWATER PROPOSED CHANNEL CHANGE CONSTRUCTION AREA AS NEEDED.
4. STABILIZE EXCAVATED AREA ACCORDING TO CHANNEL CHANGE DESIGN PLANS AND DETAILS.

PHASE II

5. FILL IN EXISTING CHANNEL WITH CHANNEL CHANGE EXCAVATION MATERIAL.
6. REMOVE IMPERVIOUS DIKES AND PUMP AROUND OPERATION ALLOWING NORMAL FLOW THROUGH PROPOSED CHANNEL.
7. ALL INACTIVE WORK AREAS IMPACTED BY CHANNEL CHANGE CONSTRUCTION SHALL BE STABILIZED SEED AND MULCH TEMPORARILY.

