

PHASING

PHASE 1

WHILE MAINTAINING TRAFFIC USING RSD 1101.04 FOR SHOULDER CLOSURES AND RSD 1101.02 FOR LANE CLOSURES AS NECESSARY, PERFORM THE FOLLOWING AS SHOWN ON SHEETS TMP-4 AND TMP-5;

STEP 1: INSTALL ADVANCE WARNING SIGNS IN ACCORDANCE WITH RSD 1101.01 AND INSTALL TRAFFIC CONTROL DEVICES AS SHOWN ON THE PLAN SHEETS.

STEP 2: AWAY FROM TRAFFIC BEGIN CONSTRUCTION OF THE NEW LOCATION ROADWAY INCLUDING GRADING, GUARDRAIL, DRAINAGE, BRIDGE CONSTRUCTION, AND PAVING UP TO BUT NOT INCLUDING THE FINAL ASPHALT SURFACE COURSE.

NOTE: PROVIDE WEDGING AS REQUIRED TO ENSURE SMOOTH TRANSITIONS AND MAINTAIN POSITIVE DRAINAGE

PHASE 2

WHILE MAINTAINING TRAFFIC USING RSD 1101.04 FOR SHOULDER CLOSURES AND RSD 1101.02 FOR LANE CLOSURES AS NECESSARY, PERFORM THE FOLLOWING AS SHOWN ON SHEETS TMP-6 AND TMP-7:


STEP 1: INSTALL PAINT VERSION OF FINAL ROADWAY MARKINGS. REMOVE CONFLICTING MARKINGS AND SHIFT TRAFFIC ONTO NEW PATTERN. USING DRUMS AND TYPE III BARRICADES AS REQUIRED, CLOSE ACCESS TO OLD ROADWAY.


STEP 2: AWAY FROM TRAFFIC, REMOVE EXISTING ROADWAY AND COMPLETE ALL ASSOCIATED DRAINAGE AND GRADING.

STEP 3: PLACE FINAL SURFACE COURSE, FINAL PAVEMENT MARKINGS, AND PERMANENT SIGNAGE ALONG NEW ROADWAY (REFER TO PAVEMENT MAKING AND SIGNAGE PLANS). REMOVE ALL TRAFFIC CONTROL DEVICES AND OPEN ALL LANES TO TRAFFIC.

K:\RAL_Roadway\01036483 - B-5534\TrafficControl\TCP\Plan_Sheets\B-5534_rdy_tmp_1.rsdgn
3/13/2020

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

APPROVED:	DATE:
	3/16/2020



Kimley»Horn

PHASING NOTES