OUTPUT CHANNEL CONFIGURATION

Front Panel

Main Menu >Controller >More>Channels>Channels Config

Web Interface

Home >Controller >Advanced IO>Channels>Channels Configuration

Channel Configuration



Channel	Control Type	Control Source	Flash Yellow	Flash Red	Flash Alt	MMU Channel
1	Overlap	7		Χ	X	1
2	Phase Vehicle	2	Х			2
3	Phase Vehicle	3		Х	Χ	3
4	Phase Vehicle	4		Х		4
5	Phase Vehicle	5		Х		5
6	Phase Vehicle	6	Х	·	Х	6
7	Phase Vehicle	7		Х		7
8	Phase Vehicle	8		Х	Χ	8
9	Overlap	1	Х	·	Χ	9
10	Overlap	2	Х		Χ	10
11	Overlap	3	Х			11
12	Overlap	4		Х		12
13	Phase Ped	2	·	·		13
14	Phase Ped	4				14
15	Phase Ped	6				15
16	Phase Ped	8				16
1.7	Overlap	5	·	Χ	Χ	17
18	Overlap	6		Х		18

MAXTIME OVERLAP PROGRAMMING DETAIL

Front Panel

Main Menu >Controller >Overlap >Overlap Parameters/Overlap Timings

Web Interface

Home >Controller >Overlap Configuration >Overlaps

Overlap Plan 1

Overlap	1	2	7
Туре	FYA 4 - Section	FYA 4 - Section	Normal
Included Phases	6	6	3
Modifier Phases	3	3	÷
Trail Green	0	0	0
Trail Yellow	0.0	0.0	0.0
Trail Red	0.0	0.0	0.0

THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 11-1468T2 DESIGNED: May 2023 SEALED: 5/24/2023 REVISED: N/A



DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED

SEAL

Temporary Installation - Electrical Detail 2 of 2 (Phase 10)

ELECTRICAL AND PROGRAMMING DETAILS FOR:

Prepared for the Offices of:

US 421 - NC 16 at SR 1323 (Dancy Road)/ Lowe's Entrance East U-Turn Division 11 Wilkes County

Wilkesboro May 2023 REVIEWED BY: M.L.Stygles PREPARED BY: S.R.Chiluka REVIEWED BY: J.Ma REVISIONS

5/24/2023 DATE

SIG. INVENTORY NO. | |-|468T2