


# CULVERT CONSTRUCTION SEQUENCE STA. 51+60.50 -L-



1. INSTALL IMPERVIOUS DIKES A AND B AND CONSTRUCT TEMPORARY CHANNEL CHANGE WITH LINER (4 FT BASE, 2 FT DEEP, 2:1 SIDE SLOPES). SEE DETAIL X.
2. INSTALL IMPERVIOUS DIKES C AND D AND REMOVE IMPERVIOUS DIKES A AND B TO DIVERT FLOW THROUGH TEMPORARY CHANNEL.
3. INSTALL SPECIAL STILLING BASINS AS NEEDED FOR DEWATERING WORK AREA.
4. INSTALL PROPOSED 60" RCP.
5. UTILIZE IMPERVIOUS DIKES AND PUMP AROUND OPERATIONS AS NEEDED TO REMOVE TEMPORARY CHANNEL CHANGE WITH LINER AND CONSTRUCT INLET/OUTLET CHANNEL IMPROVEMENTS.
6. REMOVE ALL IMPERVIOUS DIKES AND ALLOW FLOW THROUGH 60" RCP.

