PROJECT NOTES & PHASING

GENERAL NOTES

THE FOLLOWING GENERAL NOTES APPLY AT ALL TIMES FOR THE DURATION OF THE CONSTRUCTION PROJECT, EXCEPT WHEN OTHERWISE NOTED IN THE PLAN, OR DIRECTED BY THE ENGINEER.

- A) ADAPT THE TRAFFIC CONTROL PLANS, WHEN DIRECTED BY THE ENGINEER, TO MEET FIELD CONDITIONS TO PROVIDE SAFE AND EFFICIENT TRAFFIC MOVEMENT. CHANGES MAY BE REQUIRED WHEN PHYSICAL DIMENSIONS IN THE DETAIL DRAWINGS, STANDARD DETAILS AND ROADWAY DETAILS ARE NOT ATTAINABLE, OR RESULT IN DUPLICATE, OR UNDESIRED OVERLAPPING OF DEVICES. MODIFICATION MAY INCLUDE: MOVING, SUPPLEMENTING, COVERING OR REMOVAL OF DEVICES.
- B) NOTIFY THE ENGINEER 21 CALENDAR DAYS PRIOR TO ANY TRAFFIC PATTERN ALTERATION.
- C) CONTRACTOR SHALL INSTALL SIGNS AND BARRICADES TO CLOSE SR 1107.
- D) STATE FORCE WILL BE RESPONSIBLE FOR OFF-SITE DETOUR SIGNING.
- E) STATE FORCES WILL COVER OR REMOVE OFF-SITE DETOUR SIGNS, WHEN A DETOUR IS NOT IN OPERATION.
- F) INSURE ALL NECESSARY SIGNING IS IN PLACE PRIOR TO ALTERING ANY TRAFFIC PATTERN.
- G) PLACE TYPE III BARRICADES, WITH "ROAD CLOSED TO THRU TRAFFIC" SIGN R11-4 ATTACHED, OF SUFFICIENT LENGTH TO CLOSE ENTIRE ROADWAY. STAGGER OR OVERLAP BARRICADES TO ALLOW FOR INGRESS OR EGRESS.
- H) INSTALL PAVEMENT MARKINGS AND PAVEMENT MARKERS ON THE FINAL SURFACE AS FOLLOWS:

ROAD NAME

SR 1107

MARKING

MARKER

PERMANENT RAISED

I) TIE PROPOSED PAVEMENT MARKING LINES TO EXISTING PAVEMENT MARKING LINES.

THERMOPLASTIC

J) REPLACE ANY PAVEMENT MARKINGS THAT HAVE BEEN OBLITERATED BY THE END OF EACH DAY'S OPERATION.

PROJ. REFERENCE NO.	SHEET NO.
B-2963	TCD 2
	107-2


PHASING

- STEP 1) CLOSE ROADWAY TO TRAFFIC ACCORDING TO RDWY. STD. DRWG. NO. 1101.03. (SHEET 1 OF 9). CLOSE SR 1107 AT STA. 10+18+/- AND AT STA. 38+05+/-. MAINTAIN ACCESS TO THE DRIVEWAY AT STA. 35+00+/-.
- NOTE: OMIT SIGNS "ROAD CLOSED AHEAD" AND "DETOUR AHEAD" ON THE WEST AND EAST ENDS OF THE PROJECT. THE SECOND "ROAD CLOSED AHEAD" SIGN SHALL BE OMITTED ON THE EAST END ALSO.
- STEP 2) OBLITERATE EXISTING BRIDGE AND CONSTRUCT PROPOSED BRIDGE AND APPROACHES FROM STA. 23+61+/- TO STA. 26+11+/-.

 INSTALL ALL GUARDRAIL AND DELINEATION ACCORDING TO RDWY. STD. DRWG. 1261.01.
- STEP 3) PLACE FINAL LAYER OF ASPHALT.

PLACE PAVEMENT MARKINGS AND MARKERS.

STEP 4) REMOVE ALL SIGNS AND REOPEN SR 1107 TO TRAFFIC.



PROJECT NOTES & PHASING

DATE: AUGUST 2002
DWG. BY: MM
DESIGN BY: MM
REVIEWED BY: JSK

NGINEER AND COLUMN TO SHORT WORK TO SHORT WO

REVISIONS