



28-OCT-2004 15:58  
 d:\PREU\ti8\proj\Roadway\proj\2562c.e2b\psh



	PROJECT REFERENCE NO.	SHEET NO.
	R-2562C	EC-31/CONST.28
R / W SHEET NO.		
ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER	
CONST.REV.		
R / W REV.		



- CULVERT REMOVAL SEQUENCE (STA. 178+79)**
1. INSTALL SPECIAL STILLING BASIN
  2. INSTALL TEMPORARY DIKES
  3. USE BYPASS PUMPING TO DIVERT FLOW
  4. REMOVE CULVERT AND FILL
  5. STABILIZE SIDE SLOPES WITH MATTING
  6. REMOVE DIKES AND RESTORE FLOW THROUGH NEW CHANNEL

