


ROAD CLOSED R11-4 60" X 30"

THRU TRAFFIC

TYPE III BARRICADE





## **PHASING**

STEP 1: AFTER INSTALLATION OF ALL OFFSITE DETOUR SIGNING, USING SIGNS AND DEVICES AS SHOWN ON SITE PLAN AND INSET "A", TCP-2, CLOSE SR 3000 FROM THE INTERSECTION OF SR 3143 TO THE INTERSECTION OF SR 3219 TO THRU TRAFFIC. MAINTAIN ACCESS AT ALL TIMES TO ALL DRIVEWAYS WITHIN THE PROJECT LIMITS.

> IF WORK IS NOT PURSUED WITHIN THREE DAYS OF SIGN INSTALLATION, THE SIGNS SHALL BE COVERED OR REMOVED IN A METHOD APPROVED BY THE ENGINEER ACCORDING TO STANDARD SPECS SECTION 1110 AT NO EXPENSE TO THE DEPARTMENT.

- STEP 2: REMOVE THE EXISTING BRIDGE, AND CONSTRUCT PROPOSED BRIDGE AND ROADWAY APPROACHES FROM STA. 10+00 +/- TO STA. 22+00 +/- UP TO AND INCLUDING FINAL LAYER OF SURFACE COURSE. PLACE FINAL PAVEMENT MARKINGS AND MARKERS AND TIE TO EXISTING MARKINGS.
- STEP 3: REMOVE ALL TYPE III BARRICADES AND ALL DETOUR SIGNING AND RE-OPEN SR 3000 TO TWO LANE, TWO WAY TRAFFIC.





∠ INSET "A"

TYPE III BARRICADE(S)

ROAD CLOSED 60" X 30"