
## CULVERT CONSTRUCTION SEQUENCE (STA. 106 + 32)

PROJECT REFERENCE NO	<b>)</b> .	SHEET NO.
U-0620		EC-II/CONST.II
RW SHEET NO.		
ROADWAY DESIGN ENGINEER		HYDRAULICS ENGINEER



## CONSTRUCTION SEQUENCE (STA. 106+32)

- 1. CONSTRUCT STILLING BASIN (200CY).
  2. CONSTRUCT TEMPORARY CHANNEL CHANGE
- 2. CONSTRUCT TEMPORARY CHANNEL CHANGE WITH LINER (3FT BASE, 3FT DEEP, 2:1 SIDE SLOPES).
- 3. CONSTRUCT IMPERVIOUS DIKES.
  4. CONSTRUCT CULVERT.
- 5. DIVERT WATER THROUGH CULVERT.
- 6. CONSTRUCT 2 @ 72IN RCP OVERFLOW PIPES.
- 7. COMPLETE ROADWAY