
PLANTING DETAILS


SEEDLING / LINER BAREROOT PLANTING DETAIL

HEALING IN


2. Excavate a flat bottom trench 12 inches deep and provide drainage.



4. Place a single layer of plants against the sloping end so that the root collar is at ground level.





5. Place a 2 inch layer of well rotted sawdust over the roots maintaining a sloping angle.




6. Repeat layers of plants and sawdust as necessary and water thoroughly.


DIBBLE PLANTING METHOD USING THE KBC PLANTING BAR






2. Remove planting bar and place seedling at






4. Pull handle of bar toward planter, firming soil at bottom.




5. Push handle forward firming soil at top.




6. Leave compaction hole open. Water thoroughly.

PLANTING NOTES:

PLANTING BAG
During planting, seedlings
shall be kept in a moist
canvas bag or similar container to prevent the root systems from drying.



ROOT PRUNING All seedlings shall be root pruned, if necessary, so that no roots extend more than 10 inches below the



	PROJECT REFERENCE NO.		SHEET NO.
1	B-4011		RF-I
	RW SHEET NO.		
	ROADWAY DESIGN ENGINEER		HYDRAULICS ENGINEER

REFORESTATION

☐ TREE REFORESTATION SHALL BE PLANTED 6 FT. TO 10 FT. ON CENTER, RANDOM SPACING, AVERAGING 8 FT. ON CENTER, APPROXIMATELY 680 PLANTS PER ACRE.

REFORESTATION

MIXTURE, TYPE, SIZE, AND FURNISH SHALL CONFORM TO THE FOLLOWING:

25% QUERCUS ALBA

WHITE OAK

12 in - 18 in BR

25% LIRIODENDRON TULIPIFERA

YELLOW POPLAR

12 in - 18 in BR

25% QUERCUS RUBRA

NORTHERN RED OAK

12 in - 18 in BR

25% PRUNUS SEROTINA

BLACK CHERRY

12 in - 18 in BR

REFORESTATION DETAIL SHEET

N.C.D.O.T. - ROADSIDE ENVIRONMENTAL UNIT