


CULVERT CONSTRUCTION SEQUENCE STA. 136+13 -L-

PROJECT REFERENCE NO. W-5512	SHEET NO. EC-12A/CONSTJ2
RW SHEET NO.	
ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER

1. UTILIZE SPECIAL STILLING BASIN (S) DURING CULVERT CONSTRUCTION AS NEEDED.
2. CONSTRUCT IMPERVIOUS DIKES A & B
3. UTILIZE PUMP AS NEEDED TO DISCHARGE HEADWATERS DOWNSTREAM OF PIPE CONSTRUCTION.
4. REMOVE EXISTING 2@36" RCP, CONSTRUCT PROPOSED 95"X67" CSAP WITH HEADWALLS.
5. REMOVE IMPERVIOUS DIKES A AND B AND ANY REMAINING SPECIAL STILLING BASINS.
6. COMPLETE ROADWAY



MI ENGINEERING
1011 SCHAUB DRIVE, SUITE 100
RALEIGH, NC 27606
(919) 851-6606
FIRM PE NUMBER : P-0671

