



EXISTING INTERSECTION
NO WORK REQUIRED THIS PHASE
SHOWN FOR INFORMATIONAL
PURPOSE ONLY





MATCHLINE A2




EXISTING INTERSECTION
NO WORK REQUIRED THIS PHASE
SHOWN FOR INFORMATIONAL
PURPOSE ONLY

EXISTING INTERSECTION
NO WORK REQUIRED THIS PHASE
SHOWN FOR INFORMATIONAL
PURPOSE ONLY




EXISTING INTERSECTION
NO WORK REQUIRED THIS PHASE
SHOWN FOR INFORMATIONAL
PURPOSE ONLY

EXISTING POLE TO BE REMOVED.
ANTENNA TO BE RELOCATED TO
NEW METAL MAST ARM



INSTALL 8.5 DB GAIN YAGI ANTENNA
VERTICALLY POLARIZED

ATTACH ANTENNA ALONG MAST ARM
A MINIMUM OF 6 FEET AWAY FROM
THE VERTICAL SHAFT MEMBER



EXISTING INTERSECTION
NO WORK REQUIRED THIS PHASE
SHOWN FOR INFORMATIONAL
PURPOSE ONLY

MATCHLINE A2

LEGEND

- YAGI ANTENNA (DOUBLE) FOR REPEATER OPERATION
- YAGI ANTENNA (SINGLE)
- OMNI ANTENNA
- EXISTING CONTROLLER AND CABINET
- EXISTING MASTER CONTROLLER AND CABINET
- SIGNAL INVENTORY NUMBER
- NEW METAL POLE W/MAST ARM
- EXISTING WOOD POLE
- NEW METAL POLE
- SIGNAL POLE
- EXISTING METAL POLE
- NEW OVERSIZED JUNCTION BOX
- EXISTING OVERSIZED JUNCTION BOX
- EXISTING CONDUIT
- EXISTING COMMUNICATIONS CABLE

- NOTES FOR WIRELESS COMMUNICATIONS:**
- INSTALL COAXIAL CABLE:
 - ON WOOD POLES, REQUIRING A NEW RIGID GALVANIZED STEEL RISER, INSTALL A 2" RISER WITH WEATHERHEAD AND ROUTE THE COAXIAL CABLE TO THE ANTENNA.
 - ON METAL POLES WITH MAST ARMS, RUN COAXIAL CABLE UP THROUGH THE POLE AND OUT THE MAST ARM; FIELD DRILL A 1/2" HOLE UP THROUGH THE BOTTOM OF MAST ARM FOR INSTALLATION OF THE COAXIAL CABLE TO THE ANTENNA.
 - ON METAL STRAIN POLES, RUN COAXIAL CABLE UP THROUGH THE POLE AND OUT THE WEATHERHEAD AND ROUTE THE COAXIAL CABLE TO THE ANTENNA.
 - BETWEEN THE POINT OF EXITING THE RISER, METAL POLE OR MAST ARM AND THE ANTENNA, SECURE THE COAXIAL CABLE TO THE STRUCTURE USING 3/4" STAINLESS STEEL STRAPS EVERY 12".
 - IF AN EXISTING 2" SPARE RIGID GALVANIZED STEEL RISER IS AVAILABLE, INSTALL THE COAXIAL CABLE IN THE SPARE RISER.
 - INSTALL WIRELESS ANTENNA ON POLE WITH RF WARNING SIGN.
(NOTE: RF WARNING SIGN NOT REQUIRED WHEN ANTENNA IS INSTALLED ON AN NCDOT-OWNED POLE.)
 - MAINTAIN PROPER CLEARANCE FROM ALL UTILITIES PER THE NATIONAL ELECTRICAL SAFETY CODE.
 - INSTALL WIRELESS SERIAL RADIO MODEM WITH EXTERIOR DISCONNECT SWITCH LOCATED ON CABINET.
(NOTE: RF ANTENNA DISCONNECT SWITCH AND DECAL ARE NOT REQUIRED WHEN THE ANTENNA IS INSTALLED ON AN NCDOT-OWNED POLE.)
 - REFERENCE "WIRELESS RADIO ANTENNA TYPICAL DETAILS."

TMP PHASE 2

<p>750 N. Greenfield Pkwy., Garner, NC 27529</p>	<p>WIRELESS COMMUNICATIONS PLANS</p>		
	<p>DIVISION 9 DAVIDSON COUNTY</p> <p>PLAN DATE: JUNE 2015</p> <p>PREPARED BY: A. J. SKUCE</p>	<p>REVIEWED BY: <i>Neil Lively</i></p> <p>REVIEWED BY: G. A. FULLER</p>	

SCALE: 1" = 50'

CADD Filename: