



PROJ. REFERENCE NO.	SHEET NO.
B-4461	TMP-3

PHASING

PHASE I

STEP 1

PRIOR TO CONSTRUCTION, USING RSD 1101.01, SHEET 3 OF 3, INSTALL WORK ZONE ADVANCE WARNING SIGNS ALONG EXISTING SR 1916 (CORINTH ROAD).

STEP 2

AWAY FROM TRAFFIC, AND USING RSD 1101.02 (SHEET 1 OF 15) AND 1101.04, AS NECESSARY, CONSTRUCT THE FOLLOWING UP THROUGH THE FINAL LAYER OF SURFACE COURSE (SEE SHEET TMP-4 AND ROADWAY AND STRUCTURE PLANS):

- CONSTRUCT THE TEMPORARY DETOUR BRIDGE FROM -LDET- STA.14+51± TO STA.15+31±.
- CONSTRUCT -LDET- FROM STA. 10+76± TO STA.14+51± AND FROM STA.15+31± TO STA.19+47±, TYING INTO THE EDGE AND ELEVATION OF EXISTING SR 1916. INSTALL TEMPORARY GUARDRAIL.

PHASE II

STEP 1

USING , RSD 1101.02 (SHEET 1 OF 15) AND RSD 1101.03 (SHEET 3 OF 9), COMPLETE THE FOLLOWING (SEE SHEET TMP-5):

- A) REMOVE CONFLICTING PAVEMENT MARKINGS AND PLACE TEMPORARY PAVEMENT MARKINGS AND MARKERS ON -LDET- AND TIE TO EXISTING MARKINGS
- B) SHIFT TRAFFIC ONTO -LDET- IN A TWO-LANE, TWO-WAY PATTERN
- C) CLOSE EXISTING SR 1916 (CORINTH ROAD) BETWEEN -LDET- LIMITS

STEP 2

AWAY FROM TRAFFIC AND USING RSD 1101.02 (SHEET 1 OF 15), CONSTRUCT THE FOLLOWING UP TO BUT NOT INCLUDING THE FINAL LAYER OF SURFACE COURSE (SEE SHEET TMP-5):

- REMOVE EXISTING BRIDGE.
- CONSTRUCT PROPOSED BRIDGE AND APPROACH SLABS ON -L- FROM STA.18+43± TO STA.19+80±.
- CONSTRUCT -L- FROM STA. 17+00± TO STA. 18+43± AND FROM STA. 19+80± TO STA. 21+00±. INSTALL PROPOSED GUARDRAIL.

PHASE III

STEP 1

USING RSD 1101.02 (SHEET 1 OF 15) AS NEEDED, COMPLETE THE FOLLOWING (SEE SHEET TMP-6 AND FINAL PAVEMENT MARKING PLANS):

- A) PLACE INTERMEDIATE LAYER OF SURFACE COURSE ON -L- FROM STA. 14+00± TO STA. 17+00± AND FROM STA. 21+00± TO STA. 26+00±.
- B) PLACE TEMPORARY PAVEMENT MARKINGS AND MARKERS ON -L- AND TIE TO EXISTING MARKINGS.
- C) SHIFT TRAFFIC ONTO -L- INTO FINAL PATTERN

STEP 2

AWAY FROM TRAFFIC AND USING RSD 1101.02 (SHEET 1 OF 15) AS NEEDED, REMOVE TEMPORARY DETOUR BRIDGE AND -LDET-. GRADE TO FINAL CONDITION (SEE SHEET TMP-6 AND ROADWAY PLANS).

STEP 3

USING RSD 1101.02 (SHEET 1 OF 15), COMPLETE THE FOLLOWING (SEE ROADWAY PLANS):



- A) PLACE FINAL LAYER OF SURFACE COURSE ALONG -L- FROM STA. 14+00± TO STA. 26+00±.
- B) PLACE FINAL PAVEMENT MARKINGS AND MARKERS ALONG -L- FROM STA. 14+00± TO STA. 26+00±, AS SHOWN ON FINAL PAVEMENT MARKING PLANS, AND TIE TO EXISTING PAVEMENT MARKINGS.

STEP 4

REMOVE ALL REMAINING WORK ZONE TRAFFIC CONTROL DEVICES AND OPEN -L- TO FINAL TRAFFIC PATTERN.

2/9/2016
R:\B4461_tmp_phasing.dgn
ICA Engineering

DOCUMENT NOT CONSIDERED FINAL
UNLESS ALL SIGNATURES COMPLETED

APPROVED: <i>Michael T. Rzepka</i> DATE: 2/9/2016 		PHASING
--	---	---------