OVERLAP [3] PROGRAMMING DETAIL

Program overlaps as follows:
Main Menu – 4) OVERLAP

PRESS '+' TWICE

OVERLAP [3]:

LOADSWITCH = 11   NOTE: FOR SIGNAL HEAD 21
VEH SET 1   = 2,6
YELLOW CLEARANCE = 3,7
RED CLEARANCE = 1,3

END OF OVERLAP PROGRAMMING

EMERGENCY VEHICLE PREEMPTION PROGRAMMING

1.   Program EVB preempt as follows:
Main Menu – 2) PREEMPT – 4) EMERGENCY VEHICLE
EVB Clear = 2
EVB Clearance Phases = 6

2.   Program general preemption parameters as follows:
Main Menu – 2) PREEMPT – 6) MISC PREEMPTION PARAMETERS
Min Time Before PE ForceOff = 1

Program extend time on optical detector units for 2.0 sec for EVB.

OVERLAP GREEN FLASH PROGRAMMING
FOR 3 SECTION FYA

The following will cause the overlap green outputs to flash, which
are wired to the flashing yellow arrow. Program as follows:

Main Menu – 1) PHASE – 2) PHASE FUNCTIONS PAGE TWO
OLAP G FL = 3

THIS ELECTRICAL DETAIL IS FOR
THE SIGNAL DESIGN: 05-0228T1
DESIGNED: September 2014
SEALED: 04/02/2015
REVISED: N/A

Electrical Detail - Temporary 1 - Sheet 2 of 2