

	TIV UL	R QUANTITY TABLE						
BENT 2 REPAIRS	ESTI	STIMATE ACTUAL						
SHOTCRETE REPAIRS	AREA SF	VOLUME CF	AREA SF	VOLUME CF				
САР	5,5	3.5 *	3F	Cr				
COLUMN	0.0	0.0						
CONCRETE REPAIRS	AREA	VOLUME	AREA	VOLUME				
	SF 24.9	CF 15.6 *	SF	CF				
COLUMN	0.0	0.0						
		LN.		LN.				
EPOXY RESIN INJECT	FT.		FT.					
CAP	0.0							
COLUMN		1.0						
EPOXY COATING	SQ. FT		SQ.					
TOP OF BENT CAP		149						
WITH THE BEST INFORMATION AVAILABLE. IF ADDITIONAL REPAIRS NOT SHOWN ON THE DRAWINGS ARE DEEMED NECESSARY BY THE ENGINEER, THE ENGINEER SHALL NOTE ON THE DRAWINGS THE APPROXIMATE LOCATION AND DESCRIPTION OF THE REPAIRS AND ADJUST THE ACTUAL QUANTITIES ENTERED INTO THE REPAIR QUANTITY TABLE. FOR REPAIRS, SEE "TYPICAL CAP AND COLUMN REPAIR DETAILS" SHEET. CLEAN AND REMOVE DEBRIS FROM THE TOP OF THE CAP AND APPLY EPOXY PROTECTIVE COATING. EPOXY COATING SHALL BE APPLIED TO THE TOP FACE OF THE CAP. THE CONTRACTOR SHALL NOT COAT THE AREA OF THE CAP BENEATH THE MASONRY PLATES. FOR EPOXY COATING, SEE SPECIAL PROVISION. * QUANTITY HAS BEEN INCREASED DUE TO THE POTENTIAL FOR FURTHER DETERIORATION SINCE THE FIELD INSPECTION BY STRUCTURES MANAGEMENT UNIT.								
CLEAN AND REMOVE DEBRIS FR EPOXY PROTECTIVE COATING. TO THE TOP FACE OF THE CAP. THE AREA OF THE CAP BENEATI COATING, SEE SPECIAL PROVIS * OUANTITY HAS BEEN INCREASE FURTHER DETERIORATION SINC STRUCTURES MANAGEMENT UNIT	OM THE T EPOXY CC THE COI H THE MAS SION. D DUE TO E THE FI F.	OP OF THE NATING SHAL NIRACTOR S SONRY PLAT THE POTEN ELD INSPEC	IR DETAI CAP AND L BE APF HALL NOT ES. FOR	LS″ SHEET. APPLY PLIED COAT EPOXY				
CLEAN AND REMOVE DEBRIS FR EPOXY PROTECTIVE COATING. TO THE TOP FACE OF THE CAP. THE AREA OF THE CAP BENEATI COATING, SEE SPECIAL PROVIS * OUANTITY HAS BEEN INCREASE FURTHER DETERIORATION SINC STRUCTURES MANAGEMENT UNIT	OM THE T EPOXY CC . THE COI H THE MASSION. D DUE TO E THE FI MAGED ARE	OP OF THE NATING SHAL NIRACTOR S SONRY PLAT THE POTEN ELD INSPEC	IR DETAI CAP AND L BE APF HALL NOT ES. FOR	LS″ SHEET. APPLY PLIED COAT EPOXY				
CLEAN AND REMOVE DEBRIS FR EPOXY PROTECTIVE COATING. TO THE TOP FACE OF THE CAP THE AREA OF THE CAP BENEATI COATING, SEE SPECIAL PROVIS * OUANTITY HAS BEEN INCREASE FURTHER DETERIORATION SINC STRUCTURES MANAGEMENT UNIT COMMONSTRUCTURES MANAGEMENT COMMONSTRUCTURES MANAGEMENT COMMONSTRUCTURES MANAGEMENT COMMONSTRUCTURES MANAGEMENT COMMONSTRUCTURES MANAGEMENT COMMONST	CT NC	OP OF THE NATING SHAL NIRACTOR S SONRY PLATI THE POTEN ELD INSPEC	IR DETAIL CAP AND L BE APF HALL NOT ES. FOR ITIAL FOR TION BY	LS" SHEET.				
CLEAN AND REMOVE DEBRIS FR EPOXY PROTECTIVE COATING. TO THE TOP FACE OF THE CAP. BENEATI COATING, SEE SPECIAL PROVIS * OUANTITY HAS BEEN INCREASE FURTHER DETERIORATION SINC STRUCTURES MANAGEMENT UNIT PROJE BRIDC COUSIGNED by: SHEET 3 W A	AAGED ARE MAGED ARE DXY RESIN CCT NC BUNC CCT NC BUNC OF 4	OP OF THE INTRACTOR S SONRY PLATI THE POTEN ELD INSPEC	IR DETAIL CAP AND L BE APP HALL NOT ES. FOR ITIAL FOR TION BY -5892 -21	LS" SHEET.				

BENT 2 SPAN B FACE

21/2017							
			SHEET NO.				
DOCUMENT NOT CONSIDERED	NO.	BY:	DATE:	N0.	BY:	DATE:	S-25
FINAL UNLESS ALL	บ			3			TOTAL SHEETS
SIGNATURES COMPLETED	2			4			68

AGINEE