## CULVERT CONSTRUCTION SEQUENCE STA. 16 + 58 - RPA-

UTILIZE SKIMMER BASIN 5.2 AS STILLING BASIN THROUGHOUT CULVERT CONSTRUCTION.
CONSTRUCT IMPERVIOUS DIKES AND INSTALL 54 INCH TEMPORARY PIPES, DIVERTING FLOW.
CONSTRUCT PROPOSED CULVERT EXTENSION AND OUTLET CHANNEL IMPROVEMENTS.
REMOVE IMPERVIOUS DIKES AND 54 INCH TEMPORARY PIPES, ALLOWING NORMAL FLOW THROUGH PROPOSED CULVERT.
COMPLETE ROADWAY.



