

- 2) CONTRACTOR TO RECORD EXISTING SPLICE ARRANGEMENT FOR COMPARISON TO THE SUPPLIED SPLICE DETAILS. IF DISCREPANCIES EXIST, CONTACT THE ENGINEER TO DETERMINE HOW TO PROCEED WITH RESPLICING. PROVIDE AS-BUILT PLANS TO THE ENGINEER IF FINAL SPLICE ARRANGEMENT DIFFERS FROM THE SUPPLIED SPLICE DETAILS.
- 3) BACK PULL EXISTING 12-FIBER CABLE TO "NEW SPLICE ENCLOSURE 1".
- 4) ABANDON EXISTING CONDUIT, REMOVE JUNCTION BOXES AND FILL TO GRADE WITH SUITABLE MATERIAL.
- 5) RELOCATE EXISTING FIELD ETHERNET SWITCH TO NEW CABINET.

