


PROJECT REFERENCE NO. 1-5506	SHEET NO. EC-8/CONST.7
RW SHEET NO.	
ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER

# CULVERT CONSTRUCTION SEQUENCE STA. 67+46 -Y-

1. UTILIZE SPECIAL STILLING BASIN(S) AS NEEDED THROUGHOUT CULVERT CONSTRUCTION.
2. CONSTRUCT IMPERVIOUS DIKES AND INSTALL 36 INCH TEMPORARY PIPE, DIVERTING FLOW.
3. CONSTRUCT PROPOSED CULVERT EXTENSION.
4. CONSTRUCT FLOODPLAIN BENCH AND BANK STABILIZATION.
5. REMOVE IMPERVIOUS DIKES AND 36 INCH TEMPORARY PIPE, ALLOWING NORMAL FLOW THROUGH THE CULVERT.
6. REMOVE ANY REMAINING SPECIAL STILLING BASIN(S), AND COMPLETE ROADWAY.



MAD 8/21/88 JYM