
## ECONOLITE ASC/3-2070 LOAD SWITCH ASSIGNMENT DETAIL

(program controller as shown)

To assign load switches 2 and 5 as vehicle load switches, program LD SWITCH 2 as PHASE  $^{\prime}2^{\prime}$  TYPE  $^{\prime}$ V  $^{\prime}$  and LD SWITCH 5 as PHASE '5' TYPE 'V' as shown below.

- 1. From Main Menu select | 1. CONFIGURATION |
- 2. From CONFIGURATION Submenu select 3. LOAD SW ASSIGN



THIS ELECTRICAL DETAIL SUPERSEDES THE DETAIL SEALED ON 8/1/2019.

> THIS ELECTRICAL DETAIL IS FOR THE SIGNAL DESIGN: 05-1168T3 DESIGNED: September 2019 SEALED: 10/2/2019 REVISED: N/A

Electrical Detail - Temp Design 3 (TMP Phase III, Step B) Sheet 3 of 3

ELECTRICAL AND PROGRAMMING DETAILS FOR: Prepared in the Offices of:

SR 3015 (Airport Boulevard) I-40 WB Ramps

Division 5 Wake County Morrisville PLAN DATE: October 2019 REVIEWED BY: PREPARED BY: S. Armstrong REVIEWED BY: REVISIONS INIT. DATE

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED 036833

SIG. INVENTORY NO. 05-1168T3