

CULVERT CONSTRUCTION SEQUENCE STA. 54+91 -L-

- CONSTRUCTION SEQUENCE FOR ALUMINUM BOX CULVERT
1. UTILIZE SPECIAL STILLING BASIN(S) DURING CONSTRUCTION AS NEEDED.
 2. CONSTRUCT IMPERVIOUS DIKES AND INSTALL 1 24-INCH TEMPORARY PIPE AT 2% SLOPE FOR DIVERTING STREAM FLOW.
 3. DEWATER CONSTRUCTION AREA UTILIZING SPECIAL STILLING BASIN(S).
 4. REMOVE EXISTING PIPE ARCHES.
 5. CONSTRUCT NEW PIPE CULVERTS.
 6. REMOVE IMPERVIOUS DIKES, TEMPORARY PIPE, AND SPECIAL STILLING BASIN(S).
 7. COMPLETE ROADWAY.

