

PROJECT REFERENCE NO.	SHEET NO.
W-5600	EC-16A/CONST.16
RW SHEET NO.	
ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER

PIPE INSTALLATION SEQUENCE

STA. 20+96 -Y7RPA-

PHASE I (Looking in downstream direction)

- 1: INSTALL SPECIAL STILLING BASIN(S)
- 2: DRAIN THE POND
- 3: CONSTRUCT THE TEMPORARY CHANNEL CHANGE w/LINER IN THE DRY
- 4: CONSTRUCT TIES OF TEMPORARY CHANNEL TO EXISTING CHANNEL AND INSTALL IMPERVIOUS DIKE 1

PHASE II (Looking in downstream direction)

- 5: INSTALL THE PROPOSED 72" RCP
- 6: INSTALL IMPERVIOUS DIKE 2. REMOVE IMPERVIOUS DIKE 1 AND DIVERT WATER INTO THE 72" RCP
- 7: BACKFILL THE TEMPORARY CHANNEL CHANGE AND REMOVE IMPERVIOUS DIKE 2
- 8: REMOVE SPECIAL STILLING BASIN(S)

