

## WATTLE BARRIER DETAIL

## NOTES:

USE MINIMUM 18 IN. AND LENGTH OF 10 F

DO NOT PLACE WATTLES ON TOE OF SLOPE.

USE 2 FT. WOODEN STAKES WITH A 2 IN. BY 2 IN. NOMINAL CROSS SECTION.


INSTALL A MINIMUM OF 2 UPSLOPE STAKES AND 4 DOWNSLOPE STAKES AT AN ANGLE TO WEDGE WATTLE TO GROUND. PROVIDE STAPLES MADE OF 0.125 IN. DIAMETER STEEL WIRE FORMED INTO A U SHAPE NOT LESS THAN 12" IN LENGTH.


INSTALL STAPLES APPROXIMATELY EVERY 1 LINEAR FOOT ON BOTH SIDES OF WATTLE AND AT EACH END TO SECURE IT TO THE SOIL.

FOR BREAKS ALONG LARGE SLOPES, USE MAXIMUM SPACING OF 25 FT.

## FILL SLOPE

INSET A





## TOP VIEW

EXCAVATE A 2 TO 3 INCH TRENCH FOR WATTLE TO BE PLACED.

	NOWITNAL	DIAMETER	EXCELSION	WAIILE
I				

NOMINAL	DIAMETER	EXCELSIOR	WATTLE
Τ.			

PROJECT REFERENCE NO	SHEET NO.
R-5737	EC-2B
R/W SHEET N	0.
ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER