PROJ. REFERENCE NO. SHEET NO. TMP-1G I-5939 301 FAYETTEVILLE STREET SUITE 1500 RALEIGH, NC 27601 KISINGER CAMPO (919) 882-7839 ASSOCIATES NC FIRM LICENSE: C-1506

USE TMP-27 AND TMP-28 TO INSTALL SIGNS AND DEVICES TO CLOSE THE CORRESPONDING LANE OF SR 2430 (DAVIS RD) WITH A FLAGGING OPERATION.

PERFORM EPOXY OVERLAY (5) PER STRUCTURE PLANS.

ONCE EPOXY OVERLAY WORK IS COMPLETE

PERFORM JOINT REPLACEMENT (6) PER STRUCTURE PLANS.

ONCE JOINT REPLACEMENT WORK IS COMPLETE

PERFORM CLEAR SHOULDERS OF DEBRIS AND VEGETATION (4), PROPOSED TYPE III STRUCTURE ANCHOR UNITS (1). PROPOSED STEEL BEAM GUARDRAIL (2), APPROACH ROADWAY MILLING AND RESURFACING (3) PER STRUCTURE PLANS.

AT THE END OF EACH WORK PERIOD REOPEN THE ROADWAY TO TRAFFIC. REPEAT STEP 1 UNTIL ALL WORK IS COMPLETE.

STEP 2:

STEP 1:

USE RSD 1101.02 SHEET 4 OF 14 TO INSTALL SHOULDER CLOSURE. USE RSD 1101.04 TO INSTALL SIGNS AND DEVICES TO CLOSE THE CORRESPONDING SHOULDERS OF 195 TO COMPLETE THE FOLLOWING WORK:

PERFORM SUBSTRUCTURE EPOXY RESIN INJECTION (7), SILICONE JOINT SEAL REPLACEMENTS AT COLUMN BASES (8) PER STRUCTURE PLANS.

REPEAT STEP 2 UNTIL ALL WORK IS COMPLETE. ONCE ALL WORK IS COMPLETE REMOVE ALL SIGNS AND DEVICES AND REOPEN THE SHOULDERS OF 195.

S13 770130

SEE STRUCTURES SHEET S13-1, GENERAL DRAWING FOR BRIDGE 770130 FOR SCOPE LENGED. 195 MILLING AND RESURFACING

STEP 1:

USE TMP-29, TMP-30 AND TMP-31 TO INSTALL SIGNS AND DEVICES TO CLOSE THE CORRESPONDING LANE OF SR 1003 (CHICKEN RD) WITH A FLAGGING OPERATION.

PERFORM CONCRETE DECK REPAIRS (5) PER STRUCTURE PLANS.

ONCE CONCRETE DECK REPAIR WORK IS COMPLETE

PERFORM EPOXY OVERLAY (6) PER STRUCTURE PLANS.

ONCE EPOXY OVERLAY WORK IS COMPLETE

PERFORM JOINT REPLACEMENT (7) PER STRUCTURE PLANS.

ONCE JOINT REPLACEMENT WORK IS COMPLETE

PERFORM CLEAR SHOULDERS OF DEBRIS AND VEGETATION (3), PROPOSED TYPE III STRUCTURE ANCHOR UNITS (1), PROPOSED STEEL BEAM GUARDRAIL (2), APPROACH ROADWAY MILLING AND RESURFACING (4) PER STRUCTURE PLANS.

AT THE END OF EACH WORK PERIOD REOPEN THE ROADWAY TO TRAFFIC. REPEAT STEP 1 UNTIL ALL WORK IS COMPLETE.

STEP 2:

USE RSD 1101.02 SHEET 4 OF 14 TO INSTALL SHOULDER CLOSURE. USE RSD 1101.04 TO INSTALL SIGNS AND DEVICES TO CLOSE THE CORRESPONDING SHOULDERS OF 195 TO COMPLETE THE FOLLOWING WORK:

PERFORM SUBSTRUCTURE EPOXY RESIN INJECTION (8), SILICONE JOINT SEAL REPLACEMENT AT COLUMN BASES (9) PER STRUCTURE PLANS.

REPEAT STEP 2 UNTIL ALL WORK IS COMPLETE. ONCE ALL WORK IS COMPLETE REMOVE ALL SIGNS AND DEVICES AND REOPEN THE SHOULDERS OF 195.

USE TMP-34 AND TMP-35 TO INSTALL SIGNS AND DEVICES TO CLOSE THE CORRESPONDING LANE OF SR 1207 (MCDONALD RD) WITH A FLAGGING OPERATION.

PERFORM CONCRETE DECK REPAIRS (5) PER STRUCTURE PLANS.

ONCE CONCRETE DECK REPAIR WORK IS COMPLETE

PERFORM POLYESTER POLYMER CONCRETE OVERLAY (6) PER STRUCTURE PLANS.

ONCE POLYESTER POLYMER CONCRETE OVERLAY WORK IS COMPLETE

PERFORM CLEAR SHOULDERS OF DEBRIS AND VEGETATION (3), PROPOSED TYPE III STRUCTURE ANCHOR UNITS (1). PROPOSED STEEL BEAM GUARDRAIL (2), APPROACH ROADWAY MILLING AND RESURFACING (4) PER STRUCTURE PLANS.

AT THE END OF EACH WORK PERIOD REOPEN THE ROADWAY TO TRAFFIC. REPEAT STEP 1 UNTIL ALL WORK IS COMPLETE.

STEP 2:

STEP 1:

USE RSD 1101.02 SHEET 4 OF 14 TO INSTALL SHOULDER CLOSURE. USE RSD 1101.04, TMP-32 AND TMP-33 TO INSTALL SIGNS AND DEVICES TO CLOSE THE CORRESPONDING SHOULDERS OF 195 TO COMPLETE THE FOLLOWING WORK:

PERFORM SUBSTRUCTURE EPOXY RESIN INJECTION (7), SILICONE JOINT SEAL REPLACEMENT AT COLUMN BASES (8), SELECTIVE UNDERGROWTH REMOVAL AT THE END BENT 1 BEARING (9), SLOPE PROTECTION REPAIR AND SILICONE JOINT SEAL REPLACEMENT AT THE TOP OF SLOPE PROTECTION (10) PER STRUCTURE PLANS.


REPEAT STEP 2 UNTIL ALL WORK IS COMPLETE. ONCE ALL WORK IS COMPLETE REMOVE ALL SIGNS AND DEVICES AND REOPEN THE SHOULDERS OF 195.

USE RSD 1101.02 SHEET 4, 9 AND 10 OF 14 AND THE SPECIAL PROVISIONS TO CLOSE RAMPS AS NEEDED AND TO PLACE SIGNS AND DEVICES TO CLOSE THE CORRESPONDING LANE OR RAMP OF 195 FROM THE NORTH CAROLINA STATE BORDER TO THE 174 INTERCHANGE.

PERFORM MILLING AND RESURFACING WORK ON 195 AND THE RAMPS PER ROADWAY PLANS.

AT THE END OF EACH WORK PERIOD COVER DETOUR SIGNS AND DEVICES AND REOPEN THE ROADWAY TO TRAFFIC. REPEAT THIS STEP UNTIL ALL WORK IS COMPLETE.

> APPROVED: Jacob Duke 8/23/2021



PHASING NOTES (3 OF 3)

DOCUMENT NOT CONSIDERED FINAL UNLESS ALL SIGNATURES COMPLETED