



LAT. 8' BASE CHANNEL LOCATION SEQUENCE STA. 13+00 TO STA. 17+20 -LDET- RT UT TO DRIVING CREEK

PROJECT REFERENCE NO. <i>B-5624</i>	SHEET NO. <i>EC-04A/CONST.04</i>
RW SHEET NO.	
ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER

PHASE I

- 1.) UTILIZE SPECIAL STILLING BASIN(S) AS NEEDED THROUGHOUT CHANNEL RELOCATION.
- 2.) INSTALL UPSTREAM PUMP AND TEMPORARY FLEXIBLE HOSE.
- 3.) INSTALL IMPERVIOUS DIKES #1 AND #2 AND BEGIN PUMPING OPERATIONS FOR STREAM DIVERSION.
- 4.) DEWATER CONSTRUCTION AREA, UTILIZING SPECIAL STILLING BASIN(S) FOR PUMPED EFFLUENT.
- 5.) CONSTRUCT LATERAL 8' BASE CHANNEL W/COIR FIBER (BANKS ONLY).
- 6.) EXCAVATE ANY ACCUMULATED SILT AND DEWATER BEFORE REMOVAL OF IMPERVIOUS DIKES.
- 7.) REMOVE IMPERVIOUS DIKES, PUMP, AND TEMPORARY FLEXIBLE HOSE.
- 8.) COMPLETE ROADWAY.



2

15 (-LDET-)