

CHANNEL CHANGE CONSTRUCTION SEQUENCE STA. 20+00 -L-

PHASE I

1. CONSTRUCT TEMPORARY STREAM CROSSING TO ACCESS AREA ACROSS STREAM.
2. UTILIZE SPECIAL STILLING BASIN(S) AS NEEDED THROUGHOUT DITCH CONSTRUCTION.
3. INSTALL TEMPORARY SILT FENCE AROUND DITCH CONSTRUCTION AREA AS NEEDED.
4. CONSTRUCT SECTION OF CHANNEL CHANGE FROM TOP OF BANK OF DUTCH BUFFALO CREEK TO TOP OF BANK OF THE TRIBUTARY.
5. STORE EXCAVATED MATERIAL IN DESIGNATED STOCKPILE AREAS TO BE USED LATER TO FILL EXISTING CHANNEL.
6. DEWATER PROPOSED CHANNEL CHANGE CONSTRUCTION AREA AS NEEDED.
7. STABILIZE EXCAVATED AREA WITH SEED AND MULCH TEMPORARILY.
8. THE EXISTING STREAM SHALL BE MAINTAINED WHILE THE CHANNEL CHANGE SECTION IS CONSTRUCTED.

PHASE II

1. INSTALL IMPERVIOUS DIKES AND USE PUMP AROUND OPERATION TO DIVERT STREAM FLOW AROUND WORK SITE.
2. CONTINUE CONSTRUCTION OF THE CHANNEL CHANGE FROM THE END OF PHASE I TO THE CHANNEL CHANGE INLET.
3. STORE ALL ACCUMULATED EXCAVATED MATERIAL TO BE CLEANED AS DIRECTED IN DESIGN PLANS AND DETAILS.
4. ALL INACTIVE WORK AREAS IMPACTED BY CHANNEL CHANGE CONSTRUCTION SHALL BE STABILIZED BY SEED AND MULCH TEMPORARILY.

