


8/17/99

CHANNEL CHANGE CONSTRUCTION SEQUENCE STA. 20+00 -L-

PHASE III

1. INSTALL SILT FENCE CONNECTING TO TOP OF BANKS OF BOTH STREAMS.
2. INSTALL RIPRAP IN CHANNEL CHANGE TO STABILIZE SLOPES.
3. INSTALL IMPERVIOUS DIKE AT CHANNEL CHANGE OUTLET.
4. CONSTRUCT FINAL SECTION OF THE CHANNEL CHANGE FROM THE TOP OF BANK TO THE OUTLET.
5. REMOVE IMPERVIOUS DIKES AND PUMP AROUND OPERATION.
6. FLOW NOW DIVERTED THROUGH NEW CHANNEL.



3/2/2021
 R:\Environmental\Design\EC_Sheets\B5813_EC_PSH05B.dgn
 Bavaia