


PROJECT REFERENCE NO.	SHEET NO.
A-0009CA	EC-16A/CONST.16
RW SHEET NO.	
ROADWAY DESIGN ENGINEER	HYDRAULICS ENGINEER

# PIPE CONSTRUCTION SEQUENCE STA. 160+36 -L-

1. INSTALL IMPERVIOUS DIKES #1 & #2.
2. BEGIN PUMPING WATER INTO EXISTING DITCHLINE FLOWING TO EXISTING 15" CMP AT APPROX. -L- STA 157+40.
3. DEWATER WORK SITE AS NEEDED INTO SPECIAL STILLING BASIN(S).
4. REMOVE EXISTING 36" CMP.
5. CONSTRUCT 60" RCP-IV (WITH JUNCTION BOX) FROM 1607 TO 1608.
6. STOP PUMP AROUND OPERATION.
7. REMOVE IMPERVIOUS DIKES #1 & #2 AND REESTABLISH STREAM.



CONTRACTOR IS TO USE PUMP AROUND OPERATIONS AS DIRECTED TO MAINTAIN STREAM FLOW.